


# 3334

# HIOKI

# 3334-01

Instruction Manual

# AC/DC POWER HiTESTER



# EN

Sept. 2018 Revised edition 6  
3334A981-06 18-09H





# Contents

Introduction.....	1
Confirming Package Contents.....	1
Safety Information .....	2
Operating Precautions.....	4
<b>Chapter 1</b>	
<b>Overview</b> .....	<b>7</b>
1.1 Product Overview and Features .....	7
1.2 Names and Functions of Parts .....	8
1.3 Measurement Work Flow .....	12
<b>Chapter 2</b>	
<b>Measurement Preparations</b> .....	<b>15</b>
2.1 Installation & Connection Procedures .....	15
2.2 Connecting a Connection Cable .....	16
2.3 Connecting the Power Cord .....	21
2.4 Turning the Power On and Off .....	21
<b>Chapter 3</b>	
<b>Settings and Measurements</b> .....	<b>23</b>
3.1 Pre-Operation Inspection .....	23
3.2 Setup Procedure .....	24
3.2.1 Selecting an item to be displayed .....	24
3.2.2 Selecting Voltage and Current Range .....	26
3.2.3 Selecting the rectifier type .....	29
3.2.4 Displaying average measurement values (AVG: average) .....	30
3.2.5 Setting the VT or CT ratio .....	32
3.3 Integration .....	35
3.3.1 Setting integration time .....	35
3.3.2 Integration Operation .....	36
3.3.3 Notes on Integration .....	39
3.3.4 Display Format of Integration Value .....	40
3.4 Analog Output and Waveform Output .....	41
3.4.1 Analog output .....	42
3.4.2 Waveform output .....	46

3.5	Other functions .....	47
3.5.1	Display hold (Hold) .....	47
3.5.2	Peak value and Maximum value hold (Peak Hold) .....	48
3.5.3	Disables key operations (key lock) .....	49
3.5.4	Initializing (system reset) .....	50
3.6	When PEAK OVER, o.r and units flash .....	52
3.6.1	When the PEAK OVER U and PEAK OVER I LEDs go on ....	52
3.6.2	When o.r (over-range) appears .....	52
3.6.3	When the unit flashes .....	53

## **Chapter 4**

### **RS-232C/ GP-IB Interface** 55

4.1	Overview .....	55
4.2	Connect a cable to the RS-232C connector or GP-IB connector .....	58
4.3	Enter a GP-IB address (3334-01 only) .....	60
4.4	Communication Methods .....	61
4.4.1	Message Format .....	62
4.4.2	Output Queue and Input Buffer .....	66
4.4.3	Status Byte Register .....	67
4.4.4	Event Registers .....	69
4.4.5	Initialization Items .....	74
4.4.6	Command Execution Time .....	75
4.5	Message List .....	76
4.5.1	Standard Commands .....	76
4.5.2	Device-Specific Commands .....	77
4.6	Message Reference .....	81
4.6.1	Standard Commands .....	82
4.6.2	Device-Specific Commands .....	87
4.6.3	Valid Command According to Condition (Standard Command) .....	108
4.6.4	Valid Commands According to Condition (Specific Command) .....	109
4.7	Troubleshooting (Communications) .....	111
4.8	Device Compliance Statement .....	113

## **Chapter 5**

### **Specifications** 117

5.1	General Specifications .....	117
5.2	Basic Specifications .....	118
5.3	Functions .....	121

<b>Chapter 6</b>	
<b>Maintenance and Service</b>	<b>125</b>
6.1 Troubleshooting .....	125
6.2 Error Indication .....	127
6.3 Cleaning .....	127
<b>Chapter 7</b>	
<b>Rack Mounting</b>	<b>129</b>
7.1 Installation Procedure .....	129
7.2 Dimensional Diagram .....	131
<b>Index</b>	<b>Index1</b>

---



## Introduction

Thank you for purchasing the Hioki Model 3334, 3334-01 AC/DC Power HiTester. To obtain maximum performance from the instrument, please read this manual carefully, and keep it handy for future reference.

In this document, the “instrument” means the Model 3334 or 3334-01 AC/DC Power HiTester.

## Confirming Package Contents

When you receive the instrument, inspect it carefully to ensure that no damage occurred during shipping. In particular, check the accessories, panel switches, and connectors. If damage is evident, or if it fails to operate according to the specifications, contact your dealer or Hioki representative.

Confirm that these contents are provided.

- This instrument: Model 3334 or 3334-01  
Power HiTester  
(3334-01: Model with GP-IB interface)




### Accessories

- Instruction Manual ..... 1



- Power Cord ..... 1



### Options

#### Interface Connection Cables

- Model 9637 RS-232C Cable (1.8 m, 9-pin to 9-pin, Cross cable)
- Model 9638 RS-232C Cable (1.8 m, 9-pin to 25-pin, Cross cable)

(3334-01 only)

- Model 9151-02 GP-IB Connector Cable (2 m)
- Model 9151-04 GP-IB Connector Cable (4 m)

#### Other

- Model 9266-01 Outlet Code
- A number 3 Phillips screwdriver

## Safety Information






This instrument is designed to comply with IEC 61010 Safety Standards, and has been thoroughly tested for safety prior to shipment. However, mishandling during use could result in injury or death, as well as damage to the instrument. Using the instrument in a way not described in this manual may negate the provided safety features. Be certain that you understand the instructions and precautions in the manual before use. We disclaim any responsibility for accidents or injuries not resulting directly from product defects.

This manual contains information and warnings essential for safe operation of the instrument and for maintaining it in safe operating condition. Before using it, be sure to carefully read the following safety precautions.

### Safety Symbols



In the manual, the  symbol indicates particularly important information that the user should read before using the instrument.

The  symbol printed on the instrument indicates that the user should refer to a corresponding topic in the manual (marked with the  symbol) before using the relevant function.



Indicates a grounding terminal.



Indicates the ON side of the power switch.



Indicates the OFF side of the power switch.

The following symbols in this manual indicate the relative importance of cautions and warnings.



Indicates that incorrect operation presents an extreme hazard that could result in serious injury or death to the user.



Indicates that incorrect operation presents a significant hazard that could result in serious injury or death to the user.



Indicates that incorrect operation presents a possibility of injury to the user or damage to the instrument.



Indicates advisory items related to performance or correct operation of the instrument.

### Other symbols



Indicates a prohibited action.



Indicates the location of reference information.



Indicates quick references for operation and remedies for troubleshooting.

\*

Indicates that descriptive information is provided below.



Bold alphanumeric characters in this manual indicate key labels.



## Accuracy

We define measurement tolerances in terms of f.s. (full scale), rdg. (reading) and dgt. (digit) values, with the following meanings:

- f.s. (maximum display value or scale length)  
The maximum displayable value or scale length. This is usually the name of the currently selected range.
- rdg. (reading or displayed value)  
The value currently being measured and indicated on the measuring instrument.
- dgt. (resolution)  
The smallest displayable unit on a digital measuring instrument, i.e., the input value that causes the digital display to show a "1" as the least-significant digit.

## Measurement categories

This instrument complies with CAT III safety requirements.

To ensure safe operation of measurement instruments, IEC 61010 establishes safety standards for various electrical environments, categorized as CAT II to CAT IV, and called measurement categories.

CAT II: Primary electrical circuits in equipment connected to an AC electrical outlet by a power cord (portable tools, household appliances, etc.)


CAT II covers directly measuring electrical outlet receptacles.

CAT III: Primary electrical circuits of heavy equipment (fixed installations) connected directly to the distribution panel, and feeders from the distribution panel to outlets.

CAT IV: The circuit from the service drop to the service entrance, and to the power meter and primary overcurrent protection instrument (distribution panel).

Using a measurement instrument in an environment designated with a higher-numbered category than that for which the instrument is rated could result in a severe accident, and must be carefully avoided.

Use of a measurement instrument that is not CAT-rated in CAT II to CAT IV measurement applications could result in a severe accident, and must be carefully avoided.



## Operating Precautions

Follow these precautions to ensure safe operation and to obtain the full benefits of the various functions.

### Before Use

- Before using the instrument the first time, verify that it operates normally to ensure that no damage occurred during storage or shipping. If you find any damage, contact your dealer or Hioki representative.
- Before using the instrument, make sure that the insulation on the connection cable is undamaged and that no bare conductors are exposed. A damaged product could cause an electric shock or short circuits and should be replaced with an undamaged product.

### Instrument Installation

Operating temperature and humidity: 0 to 40°C at 80% RH or less (non-condensating)

Temperature and humidity range for guaranteed accuracy: 23±5°C, 80%RH or less

**Avoid the following locations that could cause an accident or damage to the instrument.**



Exposed to direct sunlight  
Exposed to high temperature



In the presence of corrosive or explosive gases



Exposed to liquids  
Exposed to high humidity or condensation



Exposed to strong electromagnetic fields  
Near electromagnetic radiators




Exposed to high levels of particulate dust



Subject to vibration

### Installation

- Do not install the instrument with any side except the bottom facing down.
- Do not install the product on an unstable or unlevel surface



Use the instrument with the stand extended.  
**See** "How to use the stand" (⇒ p.11)

**⚠ DANGER**

To prevent electric shocks and personal injury, do not directly touch the exposed metallic parts of the input terminals and other wiring materials when the measurement lines connected to the input terminals at the rear panel of the instrument are live lines. In addition, do not allow them to touch or come near metallic parts.

**NOTE**

To meet the measurement accuracy, ensure the surrounding temperature of the instrument does not exceed 23±5°C by keeping it away from heat sources.

## Handling the Instrument

### **DANGER**

To avoid electric shock, do not remove the instrument's case. The internal components of the instrument carry high voltages and may become very hot during operation.

### **WARNING**

- Do not allow the instrument to get wet, and do not take measurements with wet hands. This may cause an electric shock.
- Never modify the instrument. Only Hioki service engineers should disassemble or repair the instrument. Failure to observe these precautions may result in fire, electric shock, or injury.

### **CAUTION**

To avoid damage to the instrument, protect it from physical shock when transporting and handling. Be especially careful to avoid physical shock from dropping.

### NOTE

This instrument may cause interference if used in residential areas. Such use must be avoided unless the user takes special measures to reduce electromagnetic emissions to prevent interference to the reception of radio and television broadcasts.

## Handling the cables

### **CAUTION**

- Avoid stepping on or pinching cables, which could damage the cable insulation.
- To avoid breaking the cables, do not bend or pull them.
- To avoid damaging the power cord, grasp the plug, not the cord, when unplugging it from the power outlet.
- Keep the cables well away from heat sources, as bare conductors could be exposed if the insulation melts.

## Before Connecting

### **WARNING**

- Before turning the instrument on, make sure the supply voltage matches that indicated on the its power connector. Connection to an improper supply voltage may damage the instrument and present an electrical hazard.
- To avoid electrical accidents and to maintain the safety specifications of this instrument, connect the power cord provided only to a 3-contact (two-conductor + ground) outlet.

**See** Connection procedure:"2.3 Connecting the Power Cord"(⇒ p.21)

## Input and Measurement Precautions

### DANGER

- The maximum input voltage and current is 300 V, 30 A. Attempting to measure voltage and current in excess of the maximum input could destroy the instrument and result in personal injury or death.
- The maximum rated voltage between input terminals and ground is 300 V. Attempting to measure voltages exceeding 300V with respect to ground could damage the instrument and result in personal injury.
- This product should only be connected to the secondary side of a breaker, so the breaker can prevent an accident if a short circuit occurs. Connections should never be made to the primary side of a breaker, because unrestricted current flow could cause a serious accident if a short circuit occurs.

### WARNING

#### When connecting wires,

Observe the following to avoid electric shock and short circuits.

- Turn off the power to lines to be measured before making connections to terminals to be measured and turning on the instrument.
- Be sure to connect the voltage input and current input terminals correctly. An incorrect connection could damage or short circuit this instrument.
- Make sure no connecting wires are routed so they short circuit input voltage terminals.

#### When the instrument gives off smoke, a strange odor or makes a strange noise,

Stop measuring immediately. Then perform the following procedure. Continued use under these conditions could result in fire and electric shock.

1. Turn the instrument power switch off.
2. Disconnect the power cord from the wall outlet.
3. Turn off the line to be measured and remove any connections.
4. Contact your dealer (agent) or nearest sales office.

### CAUTION

- For safety reasons, disconnect the power cord when the instrument is not used and before connecting it to a device to be tested.
- To avoid damage to the instrument, do not short circuit or apply an input voltage to output terminals.

### NOTE

- Correct measurement may be impossible in the presence of strong magnetic fields, such as near transformers and high-current conductors, or in the presence of strong electromagnetic fields such as near radio transmitters.

#### To ensure measurements are accurate,

- Warm up the instrument 3 minutes or more before use.
- Pay attention to heat dissipation to maintain accurate measurements.  
Example: Keep the instrument away from heat sources, make sure there is enough free space around the instrument and install a fan when the unit is mounted in a rack.
- The instrument should be calibrated once a year.

# Overview

# Chapter 1

## 1.1 Product Overview and Features

The 3334 and 3334-01 AC/DC Power HiTesters are single-phase wattmeters suited to measurements of household electrical appliances and battery powered devices. One unit enables measurements of voltage, current, active power, apparent power, power factor, frequency, current integration, active power integration, peak voltage value and peak current value. All measurement data is simultaneously displayed. The instrument complies with IEC61010-1 safety standard and guarantees a basic accuracy of  $\pm 0.1\% \text{rdg.} \pm 0.1\% \text{f.s.}$  for a period of one year. It guarantees a basic accuracy of  $\pm 0.1\% \text{rdg.} \pm 0.2\% \text{f.s.}$  for a period of three years.

### Perform the following operations

- Check the power consumption and current of an electrical appliance
- Integrate current and active power
- Import measurement data into the controller
- Connect a DMM or recorder to watch analog output or waveform output.


### Voltage and current input terminals with protective cover attached

The instrument can handle inputs of up to 300 V, 30 A.

**See:** "2.2 Connecting a Connection Cable" ( $\Rightarrow$  p.16)

The protective cover prevents personnel from inadvertently touching the terminals.

The voltage input terminals are insulated from the current input terminals.



### Level output of measurement values (Analog output)


The level of a specified parameter (voltage, current, active power, and one of current integration, active power integration, apparent power or power factor) can be converted to  $\pm 1 \text{ V f.s. DC}$  at the analog output terminal. This output is isolated from voltage and current inputs. From this terminal, long-term measurement changes can be recorded by combining with DMMs, recorders, data loggers and other devices.

**See:** "3.4.1 Analog output" ( $\Rightarrow$  p.42)

### Waveform output

Instantaneous voltage, current and power waveforms can be converted to  $\pm 1 \text{ V f.s.}$  at the waveform output terminal. This output is isolated from voltage and current inputs. From this terminal, measured input waveforms can be observed with an oscilloscope.

**See:** "3.4.2 Waveform output" ( $\Rightarrow$  p.46)




### Display voltage, current, active power, apparent power, power factor, frequency, current integration, active power integration, peak voltage value and peak current value

The instrument can simultaneously display up to four measurements. The user can switch to display the desired value during measurement. Input data is displayed within 0.4 s.

**See:** "3.2.1 Selecting an item to be displayed" ( $\Rightarrow$  p.24)



### Set an external VT (PT) CT ratio



When the voltage or current exceeds the maximum rated input for this instrument, use an external VT (PT) or CT device and set the VT or CT ratio to read measurement values directly.

**See:** "2.2 Connecting a Connection Cable" ( $\Rightarrow$  p.16), "3.2.5 Setting the VT or CT ratio" ( $\Rightarrow$  p.32)

### Display averages for measurements that fluctuate substantially



Set the average times (AVG) of a measurement value to display an average value.

**See:** "3.2.4 Displaying average measurement values (AVG: average)" ( $\Rightarrow$  p.30)

### Connect this instrument to a controller with standard RS-232C capability for data acquisition and remote control

This instrument can be connected to a controller with the RS-232C or GP-IB (3334-01 only) interface to enable control of the device and acquisition of measurement data.

**See:** "4.2 Connect a cable to the RS-232C connector or GP-IB connector" ( $\Rightarrow$  p.58)



## 1.2 Names and Functions of Parts

### Front Panel

Operating Keys  
(⇒ p.10)

**PEAK OVER LED**


**PEAK OVER U** (voltage over-range warning)  
Lights when the input peak voltage value exceeds  $\pm 425$  V or  $\pm 300\%$  of the voltage range.

**PEAK OVER I** (current over-range warning)  
Lights when the input peak current value exceeds  $\pm 54.0$  A or  $\pm 300\%$  of the current range.

See "3.6 When PEAK OVER, o.r and units flash"(⇒ p.52)

Display (LED)(⇒ p.9)

Screen Display



### Setting screen LED

#### SET

Lights when the Setting screen is displayed (after pressing the **SET** key)



### Integrator LED

#### INTEGRATOR

Lights: Integration execution state  
Flashes: Integration stopped state  
Goes out: Integration re-set state



### Rectifier LED

#### RECTIFIER AC+DC

DC and AC LED light when the rectifier type is AC+DC.

#### RECTIFIER DC

DC LED lights when the rectifier type is DC.

#### RECTIFIER AC

AC LED lights when the rectifier type is AC.



### Status LED

Lights when any of the following items is set to something other than 1 (default value).

**AVG** Sets average times(⇒ p.30)

**VT** Sets VT ratio(⇒ p.32)

**CT** Sets CT ratio(⇒ p.32)

### Operating key LEDs

**KEY LOCK** Lights when operating keys are invalid (in key lock state).

To cancel lock:

Hold down the **SHIFT** key and press the **PAGE (KEY LOCK)\*** key(⇒ p.49)

**REMOTE** Lights when this instrument is controlled via an interface (in remote control state).

The operating keys are disabled in this state.

To cancel remote control:

Press the **SHIFT (LOCAL)\*** key.

### \*PAGE (KEY LOCK), SHIFT (LOCAL)

As shown above, use of the functions indicated below the operating keys (key legends in blue or LOCAL) are given in parentheses.

### POWER Switch

Turns the instrument on and off (⇒ p.21)  
( | : Power On    ○ : Power Off )



### Operating key LEDs

#### HOLD (PEAK HOLD)

Lights when the **HOLD** key is pressed to lock a display value (in display hold state).

To cancel display hold:

Press the **HOLD** key again. (⇒ p.47)

Flashes when the **SHIFT** key is pressed and then the **HOLD** key is pressed to lock a peak value and a maximum value (in peak hold state).

To cancel peak value hold:

Press the **SHIFT** key again, and then press the **HOLD** key. (⇒ p.48)

#### SHIFT

Lights when the **SHIFT** key is depressed and the functions in blue under the keys are available.

To cancel the SHIFT function:

Press the **SHIFT** key again.

Display

**Setting items**  
 Lights setting item selected using the **a, b, c** or **d** keys or **BACK** **NEXT** after opening the setting screen with the **SET** key.

**AVG** Sets average times(⇒ p.30)  
**VT** Sets VT ratio(⇒ p.32)  
**CT** Sets CT ratio(⇒ p.32)

3334-01 only  
 GP-IB address setting (⇒ p.60)

Press **PAGE** key to switch setting items.

**TIME** Sets integration time (⇒ p.35)  
 Sets D/A output item (⇒ p.43)

Minus sign

Measurement value

Selected voltage and current range lights(⇒ p.26)

m: 10<sup>-3</sup>  
 k: 10<sup>3</sup>  
 M: 10<sup>6</sup>

**Display items(⇒ p.24)**

Display item selected using the **a, b, c** or **d** keys lights.

- V** Voltage (*U*)
- A** Current (*I*)
- W** Active power (*P*)
- VA** Apparent power (*S*)
- PF** Power ratio ( $\lambda$ )
- Hz** Frequency
- Ah+** Positive current integration
- Ah-** Negative current integration
- Ah** Total current integration
- Wh+** Positive active power integration
- Wh-** Negative active power integration
- Wh** Total active power integration
- Vpk** Peak voltage value
- Apk** Peak current value
- TIME** Integration time

The **a, b, c** and **d** keys select different items

**Setting screen**

**Setting screen**

a AVG | |

b VT | |

c CT | |

d GP-IB.01

**PAGE**

a intEG.t

b TIME 0000.00

c d-A

d VA

**Measurement screen**

**Measurement screen**

a 100.08 V

b 28.78 A

c 2.592 kW

d 0.900 PF

**Other indications**

**Err. 1** Error indication  
 See "6.2 Error Indication"(⇒ p.127)

**o.r** over-range  
 See "3.6 When PEAK OVER, o.r and units flash"(⇒ p.52)

**2000 V** Flashing unit  
 Indicates that an averaged value (o.r.) is included

See "3.6 When PEAK OVER, o.r and units flash"(⇒ p.52)

### Operation Keys

#### Selecting display items or setting items.


Display area	Voltage V	Current A	Active power W	Apparent power VA	Power factor PF	Frequency Hz	Positive current integration Ah+	Negative current integration Ah-	Total current integration Ah
a	●	●	●	●	●	-	-	-	●
b	-	●	●	-	-	-	●	●	●
c	-	-	●	-	●	●	●	●	●
d	●	●	●	●	●	-	-	-	-

Display area	Positive active power integration Wh+	Negative active power integration Wh-	Total active power integration Wh	Peak voltage value Vpk	Peak current value Apk	Integration time TIME
a	-	-	●	-	-	-
b	●	●	●	-	-	●
c	●	●	●	-	-	-
d	-	-	-	●	●	●

In the measurement screen (normal display)  
Select display items (V, A, W, VA, PF, Hz, Ah, Ah+, Ah-, Wh, Wh+, Wh-, Vpk, Apk and TIME) to be displayed in display areas a, b, c and d. The items that can be displayed depend on the display area

In the setting screen  
Press the **SET** key to open the setting screen and select setting items. (Or use the **NEXT** key, **BACK** key to select setting items.)

●: Available, -: Not Available



#### Integration

##### START/STOP

Starts or stops integration.  
To reset the integration value (DATA RESET):  
Hold down the **SHIFT** key and press this key to use this function.

#### Selecting rectifier type

##### DC/AC

Changes the rectifier type.  
Default setting: AC+DC  
Sequentially selects DC, AC and AC+DC with repeated presses.

#### Making settings in the setting screen

- SET** Opens the setting screen.  
Press again to exit the screen.
- BACK** Moves to the previous setting position.
- NEXT** Moves to the next setting position.
- UP** Changes set values and increments numeric values
- DOWN** Changes set values and decrements numeric values.
- PAGE** Changes the Setting screen page.

#### Changes voltage and current range

Lights selected range.

- 15V (AUTO)** Sets the voltage range to auto-range.  
Hold down the **SHIFT** key and press this key to use this function.
- 15V to 300V** Sets respective range.
- 100mA (AUTO)** Sets the current range to auto-range.  
Hold down the **SHIFT** key and press this key to use this function.
- 100mA to 30A** Sets respective range.

#### Measurement range

See "Effective measurement range" (⇒ p.120)

#### SHIFT

Makes available the function printed in blue below the keys.

#### Holding display values, peak values and maximum values

##### HOLD

Holds display values. (display hold state)  
To cancel the display HOLD function:  
Press the **HOLD** key again.

##### HOLD (PEAK HOLD)

Holds peak values and maximum values. (peak hold state)  
Hold down the **SHIFT** key and press this key to use this function.  
To cancel the peak HOLD function:  
Press the **SHIFT** key again, and press the **HOLD** key.

#### Enabling and disabling operating keys

##### PAGE (KEY LOCK)

Disables operating keys. (KEY LOCK state)  
Hold down the **SHIFT** key and press this key to use this function.  
To cancel the KEY LOCK function:  
Hold down the **SHIFT** key again and press this key to cancel this function.

##### SHIFT (LOCAL)

Cancels a remote control state engaged via an interface.  
Press the **SHIFT(LOCAL)** key once to set the instrument to local status.



**NOTE**

This instrument includes a key processing program used in production and for checking (for example, to invoke a mode for making adjustments). Should a key operation open a screen not described in this manual, immediately shut down the instrument and power it up again.

**Rear Panel**

The 3334-01 is illustrated below.

The 3334-01 model comes with a GP-IB interface.

Except for the GP-IB connector, the 3334 and 3334-01 are identical

**Protective cover**

The instrument should be used with a protective cover to prevent personnel from inadvertently touching the terminals. Make sure that no voltage is applied to a line to be measured before installing and removing the protective cover. (⇒ p.16)

**Power Inlet**

Connect the supplied power cord here (⇒ p.21)

**Current input terminal (I)**

Connect a current output to this input. (⇒ p.16)

**Voltage input terminal (U)**


Connect a voltage output to this input. (⇒ p.16)

**GP-IB connector**

(3334-01 only)  
Connect a GP-IB interface communication cable (⇒ p.58)

**RS-232C connector**

Connect an RS-232C interface communication cable. (⇒ p.58)



**ANALOG/WAVEFORM OUTPUT terminal**

Outputs the following voltage values from the connected terminal. (⇒ p.41)

**ANALOG**


- U** Analog output for voltage.
- I** Analog output for current.
- P** Analog output for active power.
- D/A** Analog output of either current integration, active power integration, apparent power or power factor. (⇒ p.43)

**WAVEFORM**

- u** Waveform output for instantaneous voltage.
- i** Waveform output for instantaneous current.
- p** Waveform output for instantaneous power.
- GND** Ground terminal


**Bottom Panel**

**Stand**



Foot

**How to use the stand**



This instrument can be rack mounted.

See "Chapter 7 Rack Mounting"(⇒ p.129)

Parts removed from this instrument should be stored in a safe place to enable future reuse

**CAUTION**

Do not apply heavy downward pressure with the stand extended. The stand could be damaged.

**When using the stand**

Extend the stand until it clicks into place. Make sure to extend both legs of the stand.

**Collapsing the stand**

Fold in the stand until it clicks into place.

## 1.3 Measurement Work Flow

### 1 Installation, Connection and Turning the Power On

#### Installation


See (⇒ p.4)

#### Check!


- Confirm whether the line to be measured is turned off.
- Confirm whether the instrument is turned off and the power cord is disconnected.

#### Connections

See Connection cable (⇒ p.16)



See Power cord (⇒ p.21)



See Using analog output (⇒ p.42) or waveform output (⇒ p.46)

See Communications via RS-232C or GP-IB interface (⇒ p.55)

Connect a cable to the line to be measured and connect the power cord of the instrument

#### Check!

- Confirm whether the instrument is connected to the secondary side of the breaker.
- Confirm that the voltage in the wiring does not exceed 300 V.
- Confirm that the voltage to be measured will not exceed 300 V, and current will not exceed 30 A.  
⇒ If the voltage is exceeded use VT or CT.
- Confirm that the wiring connected to the voltage and current input terminals is made of an appropriate material  
⇒ Use crimp contacts (terminal screw: M6) with insulating coating. Also make sure that the materials used have sufficient withstand voltage and current capacity.
- Confirm that the wiring is not short-circuited
- Confirm that the input terminals are not loose
- Confirm that no connection mistakes have been made

#### Turn the power on

See (⇒ p.21)

(Warm up the instrument for at least 3 minutes.)

Before powering up, make one more check to confirm that all connections are correct

When the initial screen appears, input values are displayed according to current settings.

## 2 Make Instrument Settings (settings can be changed during measuring)

### Select an item to be displayed

See (⇒ p.24)

Default setting:

- a: V
- b: A
- c: W
- d: PF

Select items to be displayed by **a**, **b**, **c** and

**d**

Select up to four items of voltage (V), current (A), active power (W), apparent power (VA) or power factor (PF), frequency (Hz), current integration (Ah), active power integration (Wh), peak voltage value (Vpk) and peak current value (Apk) or Integration time (TIME).



### Select voltage and current range

See (⇒ p.26)

Initial setting: 300V  
: 30 A

Select a voltage range between 15 V to 300 V.

Select a current range between 100 mA to 30 A.

Press the **SHIFT** key, and then press the **15V(AUTO)** key or **100mA(AUTO)** key when the range is not known. The range is automatically changed. (Auto range)



Voltage range

Current range

### Select the rectifier type

See (⇒ p.29)

Make the following settings when required.

When the displayed value fluctuates, display an average value.

### Set the display average times

See (⇒ p.30)

When the voltage exceeds 300 V, select VT (PT) to measure.

### Set the VT ratio

See (⇒ p.32)

When the voltage exceeds 30 A, select CT to measure

### Set the CT ratio

See (⇒ p.32)

When integrating

### Set the integration time

See (⇒ p.35)

When utilizing analog output

Select a D/A output item

See (⇒ p.43)

Using the GP-IB interface (3334-01 only)

Enter a GP-IB address

See (⇒ p.60)


## 3 Starting measurements

Turning on the power to a line to be measured

Measuring and outputting

The measured values appear

The voltage range, current range and items to be displayed can be changed also during measurements



Holding display values  
(⇒ p.47)

Holding peak values  
(⇒ p.48)

HOLD

SHIFT

→

HOLD

PEAK HOLD

## 4 Ending measurements

Turn the power off

See (⇒ p.21)

Disconnect all cables from the device under test before turning the power off

### Regarding measurement values

- Apparent power ( $S$ ) and power factor ( $\lambda$ ) displayed by this instrument are values calculated from measured voltage ( $U$ ), current ( $I$ ) and active power ( $P$ ). For information on the calculation method used, refer to "5.2 Basic Specifications" (⇒ p.120). A measuring instrument using a different operating principle or a different calculation method may therefore produce different values.
- Voltage and current values that are less than 0.5% of their measurement ranges, and peak voltage and peak current values that are less than 0.3% of their peak ranges, are suppressed (forced to display as zero).
- Deviations may occur in the measurement of high-frequency common mode voltages
- This instrument is designed to handle DC and frequencies between 45 Hz to 5 kHz, and cannot measure frequencies outside this range.
- Measurable peak voltage and current values are for DC input and AC input between 45 Hz and 1 kHz. DC peak values and AC values at frequencies outside of the range 45 Hz to 1 kHz cannot be measured correctly.
- The displayed values of voltage and current measurements at different frequencies may be scattered.

# Measurement Preparations

## Chapter 2


### 2.1 Installation & Connection Procedures

Be sure to read the "Operating Precautions" ( $\Rightarrow$  p.4) before installing and connecting this instrument.


1 Install this instrument ( $\Rightarrow$  p.4)




2 Remove the protective covers





3 Connect connection cables to the voltage and current input terminals. ( $\Rightarrow$  p.16)



4 Attach the protective covers



5 Connect the power cord ( $\Rightarrow$  p.21)



Using an interface  
Connect a connection cable to the RS-232C or GP-IB connector (3334-01) ( $\Rightarrow$  p.58)

Using analog output or waveform output  
Connect a cable to the ANALOG/WAVEFORM OUTPUT terminal ( $\Rightarrow$  p.41)

6 Turn the power on ( $\Rightarrow$  p.21)



7 Turn on the power to the line to be measured

When finished measuring, disconnect the cables from the measurement object(s), and turn the power off.

## 2.2 Connecting a Connection Cable



Please read the following before making connections

### **DANGER**

- The maximum input voltage and current is 300 V, 30 A. Attempting to measure voltage in excess of the maximum input could destroy the instrument and result in personal injury or death.
- The maximum rated voltage between input terminals and ground is 300V. Attempting to measure voltages exceeding 300V with respect to ground could damage the instrument and result in personal injury.
- This instrument should only be connected to the secondary side of a breaker  
So the breaker can prevent an accident if a short circuit occurs. Connections should never be made to the primary side of a breaker, because unrestricted current flow could cause a serious accident if a short circuit occurs.
- Confirm that no terminal is loose.  
A connection that becomes disconnected could cause a short circuit or electrical shock. A loose connection will increase the insulation resistance resulting in heat generation, burn damages or fire.  
(Use a torque of 3Nm to secure the input terminals.)

### **WARNING**

- Observe the following to avoid electric shock and short circuits.
- Turn off the power to lines to be measured before making connections to terminals to be measured and before turning on the instrument
  - Be sure to connect the voltage input and current input terminals correctly. An incorrect connection could damage or short circuit this instrument
  - Make sure no connecting wires are routed so they short circuit input voltage terminals
  - Do not move cables around unnecessarily as terminals may become loose.

### Before turning on the power to the line to be measured

### **CAUTION**

Turn on this instrument before turning on the power to the line to be measured. Confirm that no errors are indicated and then turn on the power to the line to be measured.

Powering up the line to be measured before this instrument is turned on may damage the instrument or generate an error when it is powered up

**See** "2.4 Turning the Power On and Off" (⇒ p.21), "6.2 Error Indication" (⇒ p.127)

**Using an external VT (PT) or CT device**

Use an external VT (PT) or CT device to for measurements of a device under test whose voltage exceeds the measurement range of this device. By setting the VT or CT ratio, you can directly read primary side input values

See "3.2.5 Setting the VT or CT ratio" (⇒ p.32)



**To prevent electrical shock and personnel injury, do not touch any input terminals on the VT (PT), CT or the instrument when they are in operation.**



**Do not short circuit the secondary side when using an external VT (PT) device**

Applying a voltage to the primary side when the secondary side is short-circuited will result in the generation of a high current on the secondary side that could lead to burn damages and fire.

**Do not open the secondary side when using an external CT device.**


Applying current to the primary side when open will generate high current in the secondary side and could pose serious danger

**NOTE**

Note that a phase difference in the external VT (PT) or CT device may cause substantial deviations in current measurements.

Use a VT (PT) or CT device with a minimal phase difference in the frequency bandwidth to ensure accurate measurement results.

For reasons of safety, connect the secondary side of a VT (PT) and CT device to ground. (See figure below.)



For other safety precautions, refer to "Operating Precautions" (⇒ p.4)

**For accurate measurements:****NOTE**

Since polarity is an important factor in power measurements, make sure that voltage and current inputs are correctly connected. The instrument will not yield accurate measurement results when incorrectly connected.

Make sure that power lines are routed away from the instrument as the external electromagnetic fields they produce could have a negative effect on operation.

**Wiring material (for voltage and current input terminals)**

**To avoid electric shock and short-circuit accidents, use only solderless terminals whose wires are properly insulated.**

**(Screws for voltage and current input connectors: M6)**



To prevent electrical shock, make sure that the materials used have sufficient withstand voltage and current capacity.

### Connecting procedure


Please read the Section, "Please read the following before making connections" (⇒ p.16).

**Make sure that the power to a line to be measured is turned off before making connections.**

Tools required: a number 3 Phillips screwdriver (optional) or a Phillips screwdriver that has a no. 3 size bit

#### 1. Connect cables to the voltage and current input terminals.

##### Remove the protective covers




##### Connect the cables to the input terminals.

Use solderless terminals with a width of 13 mm or less.

Tighten the screws properly

Be sure to use the screws provided with the input terminals to connect the cables. Use of other screws may damage the connector threads, and it may cause of preventing attachment and disconnection of wires.




- 1 Use a Phillips screwdriver to remove the screw.
- 2 Secure the screw as shown in the wiring diagram.



To avoid electric shock and short-circuit accidents, use only insulated terminals.  
(Screws for voltage and current input connectors: M6)

##### Attach the protective cover



Attach the cover properly.



## 2. Connect to the lines to be measured

Use one of the following two methods to make a connection.

When the voltage or current for the line being measured is within the maximum rated input for this instrument

Connect the device to the instrument for direct measurement.

1

When the voltage or current for the line being measured exceeds the maximum rated input for this instrument



Connect a VT (PT) or CT device.

2



### 1 Connect to the lines to be measured

Refer to "Selecting connection method" (⇒ p.20) to select a connection method to minimize wattmeter loss.

Method 1: Connect the voltage input terminals to the load side



Method 2: Connect the current input terminals to the load side




**NOTE**

If the instrument is affected by common mode voltage, connect an ammeter as shown at B to reduce the error.

**NOTE**

If the connection will be maintained after measurement, perform an inspection (⇒ p.23) before conducting the next measurement. Such an inspection will help prevent electric shock and measurement errors from disconnected cables, short circuits and instrument failure.

### 2 Connect a VT (PT) or CT device



Selecting connection method

Instrument loss in the wattmeter may affect the measurement value depending on the input level.  
Then use method 2 to minimize loss.

**Method 1**  
Connect the **voltage** input terminal to the load side.

Loss = (input voltage [V])<sup>2</sup>/2.4 [MΩ]

Make a power measurement that includes the loss resulting from the input resistance in the voltage input terminals.

**Method 2**  
Connect the **current** input terminal to the load side.

Loss = (input current [A])<sup>2</sup>x10 [mΩ]

Make a power measurement that includes the loss resulting from the input resistance in the current input terminals.

Example:

**When measuring 100 V, 20 A**

Method 1: loss = (100 [V])<sup>2</sup>/2.4 [MΩ] = 0.0042 [VA]

Method 2: loss = (20 [A])<sup>2</sup>x10 [mΩ] = 4 [VA]

Method 1 involves less loss and provides a more accurate measurement.

**When measuring 100 V, 50 mA**

Method 1: loss = (100 [V])<sup>2</sup> /2.4 [MΩ] = 0.0042 [VA]

Method 2: loss = (50 [mA])<sup>2</sup> x10 [mΩ] = 0.000025 [VA]

Method 2 involves less loss and provides a more accurate measurement.

## 2.3 Connecting the Power Cord



### **! WARNING**

- Before turning the instrument on, make sure the supply voltage matches that indicated on the its power connector. Connection to an improper supply voltage may damage the instrument and present an electrical hazard.


Rated power supply voltage (100V AC to 240 V AC), rated power supply frequency (50/60 Hz)

(Voltage fluctuations of  $\pm 10\%$  from the rated supply voltage are taken into account.)

- To avoid electrical accidents and to maintain the safety specifications of this instrument, connect the power cord provided only to a 3-contact (two-conductor + ground) outlet.

### Connection procedure

Rear panel



1. Verify that the instrument's power switch is turned off.
2. Confirm that the mains supply voltage matches the instrument, and connect the power cord to the power inlet on the instrument.
3. Plug the power cord into the mains outlet.

Turn off the power before disconnecting the power cord.

## 2.4 Turning the Power On and Off

### **! WARNING**

Check the following again before turning on the power.

- Confirm that the instrument and all peripheral equipment are correctly connected.
- Confirm that no wires are short-circuiting the voltage input terminals. A short circuit could lead to electric shock and short circuits.

### **! CAUTION**

Turn on the instrument and make sure no errors are indicated before turning on the power to lines to be measured.

Powering up the line to be measured before this instrument is turned on may damage the instrument or generate an error when it is powered up.

**2.4 Turning the Power On and Off**

**Turning Power On**



Power On |

Turn the **POWER** switch on ( | ).

**After Power-On**

A self-test (instrument diagnostic routine) is performed. The self-test lights all LEDs and checks model name, version and saved data.

**Self-test**

	→	
--	---	--

Model no. "3334-01" (or "3334") and version no. appear

<b>OK</b>	<b>Error</b>
	<p>Indicates an error. <b>See</b> "6.2 Error Indication"(⇒ p.127)</p>
<b>Normal display (measurement screen)</b>	

**NOTE**

Do not press an operating key during the self-test.

When the power is turned on, the same setting as when the power was last turned off appears (backup function). When powered up for the first time, the default settings appear(⇒ p.50)

**Before Starting Measurement**

To obtain precise measurements, provide about 3 minutes warm-up after turning power on.

**Turning Power Off**

Power Off ○

Turn the **POWER** switch off ( ○ ).

When power is turned on again, the display appears with the settings that existed when power was last turned off.

# Settings and Measurements

## Chapter 3

For information on measurement work flow, refer to "1.3 Measurement Work Flow" (⇒ p.12)

### 3.1 Pre-Operation Inspection

Before using the instrument the first time, verify that it operates normally to ensure that no damage occurred during storage or shipping. If you find any damage, contact your dealer or Hioki representative.

#### 1 Peripheral Device Inspection

When using connection cables

Is the insulation of the connection cable to be used damaged, or is bare metal exposed?  
Is the input terminal screw loose?

Metal Exposed  
Screw Is Loose

Do not use if damage or short-circuited, or the screw is loose as you could receive an electric shock. Replace the damaged items. Tighten the screw properly.

No Metal Exposed  
Screw Is Properly Tightened.

#### 2 Instrument Inspection

Is damage to the instrument evident?

Yes

If damage is evident, request repairs.

No

Turn on the power

Does the self-test screen appear (model no., version no.)?

No

The power cord may be damaged, or the instrument may be damaged internally. Request repairs.

Yes

Does the measurement screen appear after the self-test?

An error indication occurs (Err)

The instrument may be damaged internally. Request repairs.

See "6.2 Error Indication" (⇒ p.127)

Yes

End of inspection

No measurement value appears  
Measurement values are incorrect

Connected cables may be short-circuited, incorrectly connected or an internal instrument failure may have occurred. Immediately turn the power off and re-inspect. If the wiring is correct, turn the instrument in for repair.

Turn on the DUT.

Allow the instrument to warm up for 3 minutes or more after powering up before use.


Please read the "Operating Precautions" (⇒ p.4) before use.

# 3.2 Setup Procedure

## 3.2.1 Selecting an item to be displayed

Use the **a**, **b**, **c** and **d** keys to select items for display areas a, b, c and d. The items change with each press of the key.

Press the key (**a**, **b**, **c** or **d**) to select item to be displayed.



Default setting:  
 Display area a: Voltage (V)  
 Display area b: Current (A)  
 Display area c: Active power (W)  
 Display area d: Power factor (PF)

**Display sequence**

**a:** V → A → W → VA → Ah → Wh → PF

**b:** A → Ah+ → Ah- → Ah → Wh+ → Wh- → Wh → W → TIME

**c:** W → Wh+ → Wh- → Wh → Ah+ → Ah- → Ah → Hz → PF

**d:** PF → TIME → V → A → W → VA → Vpk → Apk

**Display items**

Display area	Voltage V	Current A	Active power W	Apparent power VA	Power factor PF	Frequency Hz	Positive current integration Ah+	Negative current integration Ah-	Total current integration Ah
<b>a</b>	●	●	●	●	●	–	–	–	●
<b>b</b>	–	●	●	–	–	–	●	●	●
<b>c</b>	–	–	●	–	●	●	●	●	●
<b>d</b>	●	●	●	●	●	–	–	–	–

Display area	Positive active power integration Wh+	Negative active power integration Wh-	Total active power integration Wh	Peak voltage value Vpk	Peak current value Apk	Integration time TIME
<b>a</b>	–	–	●	–	–	–
<b>b</b>	●	●	●	–	–	●
<b>c</b>	●	●	●	–	–	–
<b>d</b>	–	–	–	●	●	●

●: Available, –: Not Available

**NOTE**

Voltage and current are displayed up to 105% of the range.  
Active power is displayed up to 110.25% of the range.

**When the PEAK OVER LED or o.r. goes on**

See "3.6 When PEAK OVER, o.r and units flash" (⇒ p.52)

The integrate elapsed time is displayed as follows;

From 0 minute to 99 hours, 59 minutes  
and 59 seconds

TIME 99.59.59

From 100 to 999 hours and 59 minutes

TIME 999.59.5

From 1000 to 9999 hours and 59 minutes

TIME 9999.59

10000 hours

TIME 10000.0

The frequency measurement is displayed as follows;

From 45 to 99.999 Hz

99.999 Hz

From 100 to 999.99 Hz

999.99 Hz

From 1 to 5 kHz

5.0000 k Hz

### 3.2.2 Selecting Voltage and Current Range




When the input exceeds 300 V or 30 A, Maximum input voltage and maximum input current are 300 V and 30 A, respectively. When the maximum input voltage or current is exceeded, terminate measurements as soon as possible, turn off the measurement line and disconnect all connections. Continuing measurements while maximum input voltage and maximum input current are exceeded will damage the instrument and could lead to injuries.

#### Selecting a range

Press a range key.

The LED for the selected range key lights and measurement values for the selected range appear.



setting: voltage 300 V : current 30 A

Wait (one second or more) until the internal circuit has stabilized after changing a range before reading measurements.

See "Effective measurement range and display range" (⇒ p.27)



Note that the instrument may be damaged if the applied voltage or current exceeds the measurement range.

#### Selecting auto-range

Use auto-range when the range is not known.



Press **SHIFT** and then press **15V AUTO**, auto-range voltage measurement is enabled.

Press **SHIFT** and then press **100mA AUTO**, auto-range current measurement is enabled.

When auto-ranging is enabled, the **AUTO RANGE** LED is lit along with a measuring range LED.

See "Auto-range" (⇒ p.28)

To cancel auto-range:

Press any range key, or press **SHIFT** again and then press **15V AUTO** (voltage range) or **100mA AUTO** (current range).



**NOTE**

When the measurement range is set to auto-range, analog output or waveform output changes the output rate according to changes in range. In measuring a line whose measurement value fluctuates wildly, take care not to mistake the range conversion.

It is recommended that a fixed range be used for such measurements.

**Effective measurement range and display range**

Voltage / Current	15-V range 0.150 to 15.000 V (0.075 to 15.750 V)	30-V range 0.30 to 30.00 V (0.15 to 31.50 V)	150-V range 1.50 to 150.00 V (0.75 to 157.50 V)	300-V range 3.0 to 300.0 V (1.5 to 315.0 V)
<b>100-mA range</b> 1.00 to 100.00 mA (0.50 to 105.00 mA)	1.5-W range 0.000 to 1.5000 W (0.0000 to 1.6538 W)	3-W range 0.000 to 3.000 W (0.000 to 3.308 W)	15-W range 0.000 to 15.000 W (0.000 to 16.538 W)	30-W range 0.00 to 30.00 W (0.00 to 33.08 W)
<b>300-mA range</b> 3.0 to 300.0 mA (1.5 to 315.0 mA)	4.5-W range 0.000 to 4.500 W (0.000 to 4.961 W)	9-W range 0.000 to 9.000 W (0.000 to 9.923 W)	45-W range 0.00 to 45.00 W (0.00 to 49.61 W)	90-W range 0.00 to 90.00 W (0.00 to 99.23 W)
<b>1-A range</b> 0.0100 to 1.0000 A (0.0050 to 1.0500 A)	15-W range 0.000 to 15.000 W (0.000 to 16.538 W)	30-W range 0.00 to 30.00 W (0.00 to 33.08 W)	150-W range 0.00 to 150.00 W (0.00 to 165.38 W)	300-W range 0.0 to 300.0 W (0.0 to 330.8 W)
<b>3-A range</b> 0.030 to 3.000 A (0.015 to 3.150 A)	45-W range 0.00 to 45.00 W (0.00 to 49.61 W)	90-W range 0.00 to 90.00 W (0.00 to 99.23 W)	450-W range 0.0 to 450.0 W (0.0 to 496.1 W)	900-W range 0.0 to 900.0 W (0.0 to 992.3 W)
<b>10-A range</b> 0.100 to 10.000 A (0.050 to 10.500 A)	150-W range 0.00 to 150.00 W (0.00 to 165.38 W)	300-W range 0.0 to 300.0 W (0.0 to 330.8 W)	1.5-kW range 0.0000 to 1.5000 kW (0.0000 to 1.6538 kW)	3-kW range 0.000 to 3.000 kW (0.000 to 3.308 kW)
<b>30-A range</b> 0.30 to 30.00 A (0.15 to 31.50 A)	450-W range 0.0 to 450.0 W (0.0 to 496.1 W)	900-W range 0.0 to 900.0 W (0.0 to 992.3 W)	4.5-kW range 0.000 to 4.500 kW (0.000 to 4.961 kW)	9-kW range 0.000 to 9.000 kW (0.000 to 9.923 kW)

- ( ): Display range
- Substitute VA for the W units in the table to obtain the apparent power values.  
See "5.2 Basic Specifications" (⇒ p.118)

**NOTE**

- Voltage and current are displayed up to 105% of the range.
- Active power is displayed up to 110.25% of the range.
- Numerical values in the displayed range are subject to a  $\pm 1$  dgt. error due to calculation accuracy.

**4-digit and 5-digit indication**

The number of digits in the indications shown by this instrument depends on the numeric value in the most significant digit of the full-scale value.

When the most significant digit is: 1 5-digit indication  
Something other than 1 4-digit indication

**Example: In the 30-A range:**

30.00 A is a 4-digit indication since the figure in the most significant digit of the full-scale value is "3".

**In the 15-W range:**

15.000 W is a 5-digit indication since the figure in the most significant digit of the full-scale value is "1".

**VT ratio 10 at 150-V range, CT ratio 30 at 3-A range (in 135-kW range)**

135.00 kW is a 5-digit indication since the figure in the most significant digit of the full-scale value is "1".

**NOTE**

When the average times is set to a value other than 1 (OFF), voltage, current, active power, apparent power and power factor are indicated in 5 digits.

See "3.2.4 Displaying average measurement values (AVG: average)" (⇒ p.30)




### 3.2.3 Selecting the rectifier type

For voltage measurement this instrument has three rectifier circuits. Before measurement, select the following type.

1. AC+DC: To measure only AC or true RMS value of combined DC and AC
2. DC : To measure only DC (simple average indication)
3. AC : To measure only AC and true RMS

Calculated by:

$$\sqrt{(\text{AC+DC Measured Value})^2 - (\text{DC Measured Value})^2}$$



#### NOTE

- Default setting is AC+DC.
- When DC is selected, the polarities of voltage (  $U$  ) and current (  $I$  ) are indicated. (simple average indication)  
Polarity of the apparent power ( $S=U \times I$ ) is also indicated.
- When AC+DC or AC is selected, the displayed values of voltage and current are always positive.
- During integration (**INTEGRATOR** LED lights or flashes), the rectifier type cannot be changed until the integration value is reset (**INTEGRATOR** LED goes out).("Err.5")  
**See** "To reset the integration value" ( $\Rightarrow$  p.36)
- In display hold state or peak hold state (**HOLD** LED lights or flashes), the rectifier type cannot be changed until these are canceled (**HOLD** LED goes out).("Err.5")  
**See** "Canceling Hold" ( $\Rightarrow$  p.36)

### 3.2.4 Displaying average measurement values (AVG: average)

When the display fluctuates wildly, set the average times for the measurement value to display an average value. This minimizes fluctuations in displayed values. Measurement values are displayed as simple averages.

**Measurement range:**

1 (OFF), 2, 5, 10, 25, 50, 100

Display area a in the setting screen shows the average times.

**Example: set the average times to "2"**

**1** Press **SET** to open the setting screen.

**2** Press **PAGE** to display the setting screen at the left.

**3** Press **a**.

AVG and the average times flash in display area a. (Default setting: 1)

**4** Press **UP** or **DOWN** to set the average times (2).

The **AVG** LED flashes when set to 2 or more.

**5** Press **SET** to exit the setting screen.

The normal measurement screen appears.

This example shows the average value for two data items.

$$\text{Average value} = \frac{\sum_{k=1}^n X_k}{n}$$

X<sub>k</sub>: measurement value every 200 ms  
n: average times

**Interval between display updates**

Average times	1 (OFF)	2	5	10	25	50	100
Display update	200 ms	400 ms	1 s	2 s	5 s	10 s	20 s

Averaging starts over when the range is changed. The data displayed when averaging started remains on until the first average value appears.

The unit may flash during measurement.

**See** "3.6.3 When the unit flashes" (⇒ p.53)

Averaging is performed for voltage, current, active power and apparent power.

The power factor is calculated from the averaged effective and apparent power.

**NOTE**

- In display hold state or peak hold state (**HOLD** LED lights or flashes), the average times cannot be changed until these are canceled (**HOLD** LED goes out). ("Err.5")

**See** "Canceling Hold" (⇒ p.36)

- When the average times is set to a value other than 1 (OFF), voltage, current, active power, apparent power and power factor are indicated in 5 digits.

**See** "4-digit and 5-digit indication" (⇒ p.27)

### 3.2.5 Setting the VT or CT ratio

Use an external VT (PT) or CT device to measure voltage or current values that exceed the maximum rated input for this instrument.

**See** "Connect a VT (PT) or CT device" (⇒ p.19)

By setting the VT or CT ratio in the setting screen, you can directly read primary side input values.

- Measuring voltages exceeding 300 V:  
Connect an external VT (PT) and set the VT ratio.
- Measuring current exceeding 30 A:  
Connect an external CT and set the CT ratio.

**Measurement range:**

VT ratio ..1 (OFF), 2, 4, 10, 20, 30, 60, 100

CT ratio...1 (OFF), 2, 3, 4, 5, 6, 8, 10, 12, 15, 16, 20, 24, 25, 30, 40, 50, 60, 75, 80, 100, 200, 300, 500, 1000, 2000, 3000, 5000, 10000

Set the VT and CT ratios in display area b and c in the setting screen.

**NOTE**

- During integration (**INTEGRATOR** LED lights or flashes), the VT or CT ratio cannot be changed until the integration value is reset (**INTEGRATOR** LED goes out). ("**Err.5**")  
**See** "To reset the integration value" (⇒ p.36)
  - In display hold state or peak hold state (**HOLD** LED lights or flashes), the VT or CT ratio cannot be changed until these are canceled (**HOLD** LED goes out). ("**Err.5**")  
**See** "Canceling Hold" (⇒ p.36)
-


### Setting VT ratio (example: measuring a 600 V line)

Use an external VT (PT) and enter 10:1 (60 V) voltage ratio on this instrument:  
Set the voltage range to "150 V" and the VT ratio to "10".


A voltage of 60 V is input to the instrument, but it displays an input value of 600 V.



1 Press **150V** to set the voltage range to "150 V".



2 Press **SET** to open the setting screen.



3 Press **PAGE** to display the setting screen at the left.


4 Press **b**.

VT and the VT ratio in display area b flashes. (Default setting: 1)



5 Press **UP** or **DOWN** to set the VT ratio (10).

The VT LED flashes when set to 2 or more.



6 Press **SET** to exit the setting screen.

The normal measurement screen appears.

VT indicates the primary side voltage.

### Setting a CT ratio (example: measuring a 100 A line)

Use CT device and set a 10:1 (10 A) current ratio on this instrument:  
 Set the current range to "20 A" and the CT ratio to "10".  
 A current of 10 A is input to the instrument, but it displays an input value of 100 A.

See Range selection: "3.2.2 Selecting Voltage and Current Range"(⇒ p.26)

- 1 Press **10A** to set the current range to "10 A".
- 2 Press **SET** to open the setting screen.
- 3 Press **PAGE** to display the setting screen at the left.
- 4 Press **C**.  
 CT and the CT ratio in display area c flashes. (Default setting: 1)
- 5 Press **UP** or **DOWN** to set the CT ratio (10).  
 The CT LED flashes when set to 2 or more.
- 6 Press **SET** to exit the setting screen.  
 The normal measurement screen appears.

CT indicates the primary side current.


The VT and CT ratios are also used to multiply active power and apparent power.




## 3.3 Integration

This sets integration time. It is possible to integrate current and active power simultaneously. When starting integration, some limitations arise for this instrument. In this section, the integration time settings and the integrating method will be explained.

### 3.3.1 Setting integration time



1 Press **SET** to open the setting screen.




2 Press **PAGE** to display the setting screen at the left.


3 When the D/A output setting item is flashing, press **a** or **b**.

Integration time flashes.


0000 . 00  
hours minutes



4 Press **BACK** or **NEXT** to change the selected (flashing) time digit to be set.



5 Press **UP** or **DOWN** to set the integration time.




6 Press **SET** to exit the setting screen.

The normal measurement screen appears.

**NOTE**

If there is no flashing indication displayed the settings cannot be changed (during **HOLD** or **INTEGRATOR** LED lights or flashes). In this case, return to the measurement screen by pressing the **SET** key, and set again after the integration value is reset or hold state is canceled (DATA RESET).

**To reset the integration value**



**Canceling Hold**

- Press the **HOLD** key when the **HOLD** LED lights.
  - Press the **SHIFT** key and then press the **HOLD(PEAK HOLD)** key when the **HOLD** LED flashes.
- The **HOLD** LED goes out when Hold is canceled.

**3.3.2 Integration Operation**

**Integrating state**

Integration execution state : **INTEGRATOR** LED lights  
 Integration stopped state : **INTEGRATOR** LED flashes  
 Integration reset state : **INTEGRATOR** LED goes out

**The limitations of this instrument due to integration**

Some settings are not available during integration (**INTEGRATOR** LED lights) and when integration is stopped (**INTEGRATOR** LED flashes). When the settings cannot be changed, "**Err.5**" is displayed for a second.

See "3.3.3 Notes on Integration"

"3. The limitations of this instrument due to integration"(⇒ p.39)

**Integration operation**

To start the integration



Press **START/STOP**.

**INTEGRATOR** LED lights and the integration will start.

To stop forcibly the operating integration:  
(**INTEGRATOR** LED lights: Integration execution state)



Press **START/STOP** again.

**INTEGRATOR** LED flashes and the integration operation will stop.

To reset the integration value:  
(**INTEGRATOR** LED flashes: Integration stopped state)



Press **SHIFT** and then press **START/STOP**.



**INTEGRATOR** LED goes out and the integration value is reset.

To add to the previous integration value:  
(INTEGRATOR LED flashes: Integration stopped state)



Press **START/STOP**.



The integration value is added to the previous integration value.

### Integration stop

The integration operation will stop in the following circumstances:

- Reaches the set integration time.
- While the **INTEGRATOR** LED is lit, press the **START/STOP** key, or press the **SHIFT** key and then press the **START/STOP** key.
- When integration time reaches 10000 hours.
- When integration value reaches  $\pm 999999$  MWh.

### 3.3.3 Notes on Integration

1. Current integration effective measurement range :  $\pm 1\%$  to  $\pm 100\%$  of current range  
Active power integration effective measurement range: 0% to  $\pm 100\%$  of active power range
2. When starting integration, auto range setting of voltage and current is canceled and the range at integration starting point is fixed. It is necessary to set the range so that **PEAK OVER U** (voltage over-range warning) LED and **PEAK OVER I** (current over-range warning) LED will not light during integration. When the **PEAK OVER U** or **PEAK OVER I** LED is lit while integrating, the integration value is invalid. In this case, the Ah or Wh unit flashes. This continues flashing until the integration value is reset (DATA RESET).  
(Even when the current or active power measurement value is out of range ("**o.r**"), integration is performed for the measurement values for which the **PEAK OVER U** or **PEAK OVER I** LED is not lit.)
3. The limitations of this instrument due to integration  
The following settings cannot be changed in the integration execution state (**INTEGRATOR** LED lights) or the integration stopped state (**INTEGRATOR** LED flashes). When the settings cannot be changed, "**Err.5**" is displayed for a second.

● : changeable    — : can not change

Items	integration execution state, Integration stopped state ( <b>INTEGRATOR</b> LED lights or flashes)
Range select	—
Rectifier type select	—
Integration time setting and changing	—
D/A output item setting and changing	●
Averaging time setting and changing	●
VT ratio setting and changing	—
CT ratio setting and changing	—
GP-IB address setting and changing (3334-01 only)	●

4. When the integration value reaches  $\pm 999999$  MWh, or when the integration time reaches 10000 hours, integrating cannot restart. ("**Err.6**" is displayed for a second).  
In this case, press the **SHIFT** key and then press the **START/STOP(DATA RESET)** key to reset integration value (**INTEGRATOR** LED goes out), and then restart.
5. When perform a system reset, integration stops and the instrument is reset to initial setting (factory default settings).  
  
**See**"3.5.4 Initializing (system reset)"(⇒ p.50)
6. When the power is cut off during integration, integration starts again after returned.

### 3.3.4 Display Format of Integration Value

The integration reset format is shown in Table 1 and 2. Digits of integration value and integrate range format carry up or down simultaneously.

#### NOTE

The number of digits does not go below that when integration is reset.

Table 1: Format of current integration

Current range	100 mA, 300 mA	1 A, 3 A	10 A, 30 A
Reset value	000.000 mAh	0.00000 Ah	00.0000 Ah

Table 2: Format of active power integration

Current range	100 mA, 300 mA	1 A, 3 A	10 A, 30 A
Voltage range			
15 V, 30 V	0.00000 Wh	00.0000 Wh	000.000 Wh
150 V, 300 V	00.0000 Wh	000.000 Wh	0.00000 kWh

#### Overview of integration reset value

Display format of current range and active power range applies to integration value format under reset condition.

#### Example:

	Display format	Integration value format	Reset value
1.5-W range	1.5000 W	1.50000 Wh	0.00000 Wh
9 kW-range	9.000 kW	9.00000 kWh	0.00000 kWh

The display format when setting VT and CT ratios determines the integration value format.

#### Example:

	Display format	Integration value format	Reset value
300-W range 15 V×10(VT)×100 mA×20(CT)	300.0 W	300.000 Wh	000.000 Wh

## 3.4 Analog Output and Waveform Output




### Wire materials that can be used for connection

	<b>Rated wire</b>	Single wire 1.2 mm in diameter (AWG 16) Stranded wire 1.25 mm <sup>2</sup> (AWG 16), wire diameter 0.18 mm or more
	<b>Range of usable wire</b>	Single wire 0.4 mm in diameter (AWG 26) to 1.2 mm (AWG 16) Stranded wire 0.3 mm <sup>2</sup> (AWG 22) to 1.25 mm <sup>2</sup> (AWG 16), wire diameter 0.18 mm or more
	<b>Standard length of removed wire section</b>	11 mm
	<b>Recommended tools</b>	Phillips screwdriver (3 mm shaft diameter, 2.6 mm blade width)


### Connecting to the ANALOG/WAVEFORM Output Terminal

Connect one wire to the terminal corresponding to the measurement value to be output. Connect the GND terminal of this instrument to the GND terminal of a data logger or recorder to which the data is to be output.

Terminal button



Insert a straight-bladed screwdriver or similar tool into the opening to enable insertion of the wire.



Let go of the button. The wire is now secured.

Connect the wire to the output device.

When the power to the line to be measured is turned on after connection, the voltage is also output to the output device.



To avoid damage to the instrument, do not short circuit or apply an input voltage to output terminals.

### 3.4.1 Analog output

The ANALOG OUTPUT terminal can output measurement values as a level converted voltage.

This output is isolated from voltage and current inputs.


A data logger or recorder can use this data.

Output items: following 4 items

- voltage
- current
- active power
- One of the following:  
current integration, active power integration, apparent power or power factor

See "Selecting the D/A output item" (⇒ p.43)

#### Usage example:



#### Analog output specifications

<b>Output voltage</b>	voltage, current, active power, apparent power : $\pm 2$ V DC for $\pm 100\%$ of range power factor : 0 V at 0.000, +2 V DC at 1.000 current integration, active power integration : $\pm 2$ V DC (range $\times$ set integration time)
<b>Output resistance</b>	100 $\Omega \pm 5\%$ ( $\pm 5\%$ )
<b>Response time</b>	0.5 s or less
<b>Output update rate</b>	200 ms

#### NOTE

- When a VT or CT ratio is used, the range is multiplied by the VT ratio and CT ratio producing +2 V DC.
- When the measurement range is set to auto-range, the analog output changes the output rate according to changes in range. In measuring a line whose measurement value fluctuates wildly, take care not to mistake the range conversion.  
It is recommended that a fixed range be used for such measurements.
- The response time for the analog output of this instrument is 0.5 s.
- Note that a line that fluctuates faster than the output response time of the instrument will produce a deviation in the output voltage.
- The analog output outputs measured instantaneous values every 200 ms. Thus the analog output changes also in the display hold and during an averaging process.



### Selecting the D/A output item

Select the D/A output item.

Choose one of the following four parameters for output:

- Current integration
- Active power integration
- Apparent power
- Power factor




1 Press **SET** to open the setting screen.



2 Press **PAGE** to display the setting screen at the left.

3 Press **c** or **d**.


D/A output item flashes.  
(Default setting: VA)



4 Press **UP** or **DOWN** to set the output item.

The flashing unit symbol indicates the selected D/A output item.

Pressing the **UP** key changes the flashing unit symbol as follows:  
VA → PF → Ah- → Ah+ → Ah → Wh- → Wh+ → Wh  
(Pressing the **DOWN** key changes the symbol in the reverse order.)




5 Press **SET** to exit the setting screen.

The normal measurement screen appears.



## Current integration, Active power integration



- (1) When the integrated value equals a multiple of "the measurement range multiplied by the set integration time", the analog output of the integration value becomes  $\pm 2$  V. For example, if the measurement range is 150 W and the integration time is set to 24 hours, when the integrated value is 3.6 kWh (150 W x 24 hours), 7.2 kWh (150 W x 24 hours x 2), 10.8 kWh (150 W x 24 hours x 3) ... its the analog output will be +2 V. When it is a multiple of -3.6 kWh, the analog output will be -2 V.
- (2) When integration has started, analog output voltage begins to change. When integration has stopped, the last analog output voltage is maintained. When integration has restarted, analog output voltage begins to change again.
- (3) When analog output voltage exceeds  $\pm 2$  V, analog output voltage returns to 0 V and then begins to change again.
- (4) When the integration value is reset, analog output voltage returns to 0 V.


### 3.4.2 Waveform output

The WAVEFORM OUTPUT terminal provides output of instantaneous voltage, current or power.

This output is isolated from voltage and current inputs.

From this terminal, measured input waveforms can be observed with an oscilloscope.

#### Usage example:



#### Waveform specifications

<b>Output voltage</b>	1 V f.s. for 100% of range
<b>Output resistance</b>	100 $\Omega \pm 5\%$
<b>Conversion interval</b>	Approx. 13 $\mu\text{s}$

#### NOTE


- When a VT or CT ratio is used, the range is multiplied by the VT ratio or CT ratio to provide a true RMS value of 1 V.
- When the measurement range is set to auto-range, the waveform output changes the output rate according to changes in range. In measuring a line whose measurement value fluctuates wildly, take care not to mistake the range conversion.  
It is recommended that a fixed range be used for such measurements.
- The waveform output changes also in the display hold and during an averaging process.

## 3.5 Other functions


### 3.5.1 Display hold (Hold)

Pressing the **HOLD** key makes it possible to hold all displayed measurement values (display hold state).

#### Invoking display hold state



#### Canceling display hold state



#### **NOTE**

The following operations are disabled in the hold state.

- Range switching  
**Err.5** appears when a range key is pressed.  
 Range changing is also disabled in auto-range mode. The **HOLD** key locks the current range.
- Changing settings (average times, VT and CT ratio setting)  
 In the setting screen, set items light and cannot be changed.
- Rectifier type switching


To change ranges and settings, press the **HOLD** key to cancel the hold state (**HOLD** LED goes out).

### 3.5.2 Peak value and Maximum value hold (Peak Hold)


Peak waveform values such as device inrush current can be measured. (Peak value hold)

The maximum value of each measurement parameter is available. (maximum value hold)

#### Invoking peak hold state



Press **SHIFT**, and then  
press **HOLD**  
PEAK HOLD



The **HOLD** LED flashes and the Peak Hold function is enabled.

#### Clearing the peak hold value


Press the **HOLD** key while Peak Hold is enabled (**HOLD** LED flashes).

The display is updated with the instantaneous value at that moment, and the Peak Hold function is restarted.

#### Canceling peak hold state



Press **SHIFT** again, and then  
press **HOLD**  
PEAK HOLD



The **HOLD** LED goes out and the normal measurement screen reappears.

#### NOTE

The following operations are disabled in the peak hold state.


- Range switching  
**Err.5** appears when a range key is pressed.(⇒ p.127)  
Range changing is also disabled in auto-range mode. The **HOLD** key locks the voltage and current range.
- Changing settings (integration time, average times, VT and CT ratio setting)  
In the setting screen, set items light and cannot be changed.
- Rectifier type switching
- For all measurement parameters, "o.r" (over-range) is treated as the maximum value. To return to displaying an actual measurement value, clear the Peak Hold value.

To change settings, press the **SHIFT** key, and then press the **HOLD(PEAK HOLD)** key to cancel the peak hold state (**HOLD** LED goes out).

### 3.5.3 Disables key operations (key lock)

This function disables key operations (key lock state) to prevent inadvertent operation during measurement.

#### Invoking key lock state



1 Press **SHIFT**.  
The **SHIFT** LED lights.

2 Press **PAGE**  
**KEY LOCK**.  
The **KEY LOCK** LED lights.  
Keys do not function when pressed.

#### Canceling key lock state

Press **SHIFT** again (the **SHIFT** LED lights) and press **PAGE**  
**KEY LOCK**.  
The **KEY LOCK** LED goes out and operating key functions are again available.

#### NOTE

Communications via an interface in **KEY LOCK** state turns off the **KEY LOCK** LED and engages the remote state (**REMOTE** LED lights).

The remote state also prevents use of the operating keys.


To enable the operating keys, press the **SHIFT (LOCAL)** key to cancel the remote control state.

See "To cancel the Remote state (enter the local state)" (⇒ p.61)

### 3.5.4 Initializing (system reset)

Instrument functions can be returned to their factory defaults (system reset). Perform a system reset during the self-test (the interval until the normal screen appears) after powering up.

Note: On the 3334-01, the display appears as follows.





**Factory default settings (initial setting: system reset)**

Item	Settings
Display area a	Voltage (V)
Display area b	Current (A)
Display area c	Active power (W)
Display area d	Power factor (PF)
Voltage range	300-V range (Auto range OFF)
Current range	30-A range (Auto range OFF)
Rectifier type (RECTIFIER)	AC+DC
D/A output	Apparent power (VA)
VT ratio (VT)	1 (OFF)
CT ratio (CT)	1 (OFF)
Average times (AVG)	1 (OFF)
Display Hold	OFF
Peak hold	OFF
GP-IB address (3334-01 only)	1
Key lock	OFF
Integration time setting	10000 h (Setting screen: "0000.00")
Integration value	0 Wh, 0 Ah
Integration elapsed time	00 h 00 min 00 s (Displays: "0.00.00")

## 3.6 When PEAK OVER, o.r and units flash

### 3.6.1 When the PEAK OVER U and PEAK OVER I LEDs go on



The LEDs go on when the voltage input or the current input waveform peak value exceed the following value.

- The voltage input waveform peak value: when  $\pm 300\%$  of any voltage range and  $\pm 425$  V in a 300 V or 150-V range
- The current input waveform peak value: when  $\pm 300\%$  of any current range and  $\pm 54.0$  A in a 30-A range

When the displayed data is not accurate.

#### Remedy:

- **When the PEAK OVER U LED lights**  
When  $\pm 425$  V is exceeded, stop measuring as quickly as possible, turn off the power to the line being measured, and disconnect all connections. When the LED lights at a lower value, the internal circuit is not operating correctly. Switch over to a range that does not light the PEAK OVER U LED.
- **When the PEAK OVER I LED lights**  
When  $\pm 54.0$  A is exceeded, stop measuring as quickly as possible, turn off the power to the line being measured, and disconnect all connections. When the LED lights at a lower value, the internal circuit is not operating correctly. Switch over to a range that does not light the PEAK OVER I LED.  
[See "3.2.2 Selecting Voltage and Current Range" \(⇒ p.26\)](#)

### 3.6.2 When o.r (over-range) appears



This icon appears when a range is exceeded by 105%.

(For information on ranges: refer to "Effective measurement range" (⇒ p.121))

A calculation based on data that has generated an "o.r" will also produce an "o.r" display.

- When the voltage or current is "o.r", the apparent power, active power and power factor all become "o.r".
- When the apparent voltage is 0, the power factor becomes "o.r".
- However, a power factor that is "o.r" when apparent power is 0 will produce a normal value if the voltage and current inputs are made.

#### Remedy:

- **When the voltage is "o.r",**  
Switch to a range that is not over-range. When "o.r" is displayed with the 300-V range selected, stop measuring as quickly as possible, turn off the power to the line being measured, and disconnect all connections.
- **When the current is "o.r",**  
Switch to a range that is not over-range. When "o.r" is displayed with the 30-A range selected, stop measuring as quickly as possible, turn off the power to the line being measured, and disconnect all connections.
- ["3.2.2 Selecting Voltage and Current Range" \(⇒ p.26\)](#)

### 3.6.3 When the unit flashes



The unit may sometimes flash during an average operation. In some cases, the integration value unit indicator also flashes.

This indicates that the displayed average value contains "o.r".

Along with the integration value, PEAK OVER is indicated when this condition occurs during measurement.

When an over-range ("o.r") measurement occurs, averages are calculated using internal voltage and current data that exceeds 105% of their ranges, and active power and apparent power data that exceeds 110.25% of their ranges.

#### Remedy:

- The LED does not flash when "o.r" does not occur in the average period.
- It does not flash unless PEAK OVER occurred during integration.
- When the voltage flashes:
  - Change the measurement range. If the 300-V range is already selected, stop measuring as quickly as possible, turn off the power to the line being measured, and disconnect all connections.
- When the current, active power or apparent power LED flashes:
  - Switch to a range that does not cause flashing. If the 30-A range is already selected, stop measuring as quickly as possible, turn off the power to the line being measured, and disconnect all connections.
- **See** "3.2.2 Selecting Voltage and Current Range" (⇒ p.26)
- When only the power factor flashes:
  - This happens when the apparent power is 0 and is thought to be caused by load fluctuations. Flashing stops when the apparent power changes to something other than 0.
- When the integration value unit flashes:
  - Reset the integration value, then change the range and restart integration.

## ***3.6 When PEAK OVER, o.r and units flash***

---


---

# RS-232C/ GP-IB Interface

## Chapter 4

The symbol shown below indicates that the following instructions are specific to the RS-232C or the GP-IB interface. Instructions without this symbol are for both the RS-232C and the GP-IB interface.

 : RS-232C only, or devices prepared for RS-232C

 : GP-IB only (3334-01), or devices prepared for GP-IB

### 4.1 Overview

This instrument can be controlled via the RS-232C and GP-IB.



- Complies with the following standard: Applicable standard IEEE 488.1-1987<sup>\*1</sup>
- This instrument is designed with reference to the following standard: Reference standard IEEE 488.2-1987<sup>\*2</sup>
- If the output queue becomes full, a query error is generated and the output queue is cleared. Therefore, clearing the output queue and query error output from the deadlocked condition<sup>\*3</sup> as defined in IEEE 488.2 is not supported.

---

\*1. ANSI/IEEE Standard 488.1-1987, IEEE Standard Digital Interface for Programmable Instrumentation

\*2. ANSI/IEEE Standard 488.2-1987, IEEE Standard Codes, Formats, Protocols, and Common Commands

\*3. The situation in which the input buffer and the output queue become full, so that processing cannot continue.

## Before Use

### 1. Connect to this connector.

Always make use of the connector screws to affix the GP-IB or RS-232C connectors.

**See** "4.2 Connect a cable to the RS-232C connector or GP-IB connector" (⇒ p.58)

### 2.

#### GP-IB

#### Enter a GP-IB address.

Enter a GP-IB address in the setting screen.

**See** "4.3 Enter a GP-IB address (3334-01 only)" (⇒ p.60)

#### RS-232C

**Refer to the table below to set up the communication protocol of the controller so that these settings are identical to those of the instrument.**

**See** "Setting up the communication protocol of the controller" (⇒ p.59)

## The RS-232C interface

### Specifications

Transfer method	Full duplex
Communications Synchronization	Start-stop synchronization
Baud rate	9600 bps
Data length	8 bits
Parity	none
Stop bit	1 bit
Message terminator (delimiter)	Receiving: LF Transmitting: CR + LF (switchable to LF)
Flow control	none
Electrical specification	Input voltage levels    5 to 15 V    : ON -15 to -5 V    : OFF Output voltage levels    +5 V or more : ON -5 V or less    : OFF
Connector	RS-232C Interface Connector Pinout (Male 9-pin D-sub, with #4-40 attachment screws) The I/O connector is a DTE (Data Terminal Equipment) configuration Recommended cables: <ul style="list-style-type: none"> <li>• Model 9637 RS-232C Cable</li> <li>• Model 9638 RS-232C Cable</li> </ul> <b>See</b> "4.2 Connect a cable to the RS-232C connector or GP-IB connector" (⇒ p.58)

Operating Code: ASCII codes

## The GP-IB interface

### Interface Functions

<b>SH1</b>	All Source Handshake functions	Yes
<b>AH1</b>	All Acceptor Handshake functions	Yes
<b>T6</b>	Basic talker functions	Yes
	Serial poll function	Yes
	Talk-only mode	No
	The talker cancel function with MLA (My Listen Address)	Yes
<b>L4</b>	Basic listener functions	Yes
	Listen-only mode	No
	The listener cancel function with MTA (My Talk Address)	Yes
<b>SR1</b>	All Service Request functions	Yes
<b>RL1</b>	All Remote/Local functions	Yes
<b>PP0</b>	Parallel Poll function	No
<b>DC1</b>	All Device Clear functions	Yes
<b>DT1</b>	All Device Trigger functions	Yes
<b>C0</b>	Controller functions	No

Operating Code: ASCII codes

### NOTE

#### Precautions

Use an RS-232C or an GP-IB interface.

Simultaneous use of both interfaces may cause malfunctions such as communication interruptions.

## 4.2 Connect a cable to the RS-232C connector or GP-IB connector



### **! WARNING**



- Always turn both devices OFF when connecting and disconnecting an interface connector. Otherwise, an electric shock accident may occur.
- To avoid damage to the product, do not short-circuit the terminal and do not input voltage to the terminal.
- Connect this instrument to the RS-232C or GP-IB connector on the device to be connected.  
A connection to a connector with different electrical specifications may result in an electric shock or equipment damage hazard.

### **! CAUTION**

- Use a common ground for both the instrument and the computer. Use of different ground circuits will result in a potential difference between the instrument's ground and the computer's ground. If the communications cable is connected while such a potential difference exists, it may result in equipment malfunction or failure.
- Before connecting or disconnecting any the communications cable, always turn off the instrument and the computer. Failure to do so could result in equipment malfunction or damage.
- After connecting the communications cable, tighten the screws on the connector securely. Failure to secure the connector could result in equipment malfunction or damage.

### Connect to the RS-232C connector

RS-232C connector



Male 9-pin D-sub  
#4-40 attaching screws

Connect the RS-232C cable to the RS-232C connector.

To connect the instrument to a controller (DTE), use a crossover cable compatible with the connectors on both the instrument and the controller.

The I/O connector is a DTE (Data Terminal Equipment) configuration.

This instrument uses only pins 2, 3, 5, 7 and 8. The other pins are unconnected.

Pin No.	Mutual connection circuit name		CCITT	EIA	JIS	Signal Name
			Circuit No.	Code Addr.	Code Addr.	
1	Carrier Detect	Carrier Detect	109	CF	CD	DCD
2	Receive Data	Receive Data	104	BB	RD	RxD
3	Transmit Data	Send Data	103	BA	SD	TxD
4	Data Terminal Ready	Data Terminal Ready	108/2	CD	ER	DTR
5	Signal Ground	Signal Ground	102	AB	SG	GND
6	Data Set Ready	DATA Set Ready	107	CC	DR	DSR
7	Request to Send	Request to Send	105	CA	RS	RTS
8	Clear to Send	Clear to Send	106	CB	CS	CTS
9	Ring Indicator	Ring Indicator	125	CE	CI	RI




## 4.2 Connect a cable to the RS-232C connector or GP-IB connector

### Connecting a controller with a 9-pin D-sub male port

Use a crossover cable with female 9-pin D-sub connectors.

Crossover Wiring




### Connecting a controller with a 25-pin D-sub female port

Use a crossover cable with a female 9-pin D-sub and a male 25-pin D-sub connector.

As the figure shows, RTS and CTS pins are shorted together and crossed to DCD in the other connector.

Crossover Wiring



Note that the combination of a dual male 25-pin D-sub cable and a 9- to 25-pin adapter cannot be used.



### Setting up the communication protocol of the controller

Be sure to make set up the controller as shown below.

- Asynchronous communication
- Transfer rate    9600 bps
- Stop bit:        1
- Data length     8
- Parity check:   None

**4.3 Enter a GP-IB address (3334-01 only)**

**Connect to the GP-IB connector**




Connect the GP-IB cable to the GP-IB connector.

Recommended cable:  
 Model 9151-02 GP-IB Connector Cable (2 m)  
 Model 9151-04 GP-IB Connector Cable (4 m)


**4.3 Enter a GP-IB address (3334-01 only)**

Enter the GP-IB address in the setting screen before use of the GP-IB interface.

Settable range: 00 to 30



1 Press **SET** to display the setting screen.




2 Press **PAGE** to display the setting screen at the left.  
 3 Press **d**.

The address digits flash.



4 Use **UP** or **DOWN** to enter the GP-IB address.



5 Press **SET** to exit the setting screen.


The normal measurement screen appears.

## 4.4 Communication Methods


Various messages are supported for controlling the instrument through the interfaces.

Messages can be either program messages, sent from the controller such as PC to the instrument, or response messages, sent from the instrument to the controller.

RS-232C also provides messages that confirm operations to ensure that controller and instrument processing are synchronized.



Message types are further categorized as follows:



When issuing commands that contain data, make certain that the data is provided in the specified format.

### NOTE


During communications, **REMOTE** is lit to indicate the remote control state. Pressing the key except the **SHIFT (LOCAL)** key has no effect.

When the remote control state is invoked and the instrument is in the setting screen, the measurement screen is displayed automatically.

This key is disabled if the GP-IB controller has put the instrument into the local lock out state (LLO: Local Lock Out ( $\Rightarrow$  p.73)). In this case, run the GTL command of the interface function, or reboot the instrument. Then it returns to the local state.

### To cancel the Remote state (enter the local state))

#### Remote state



Press the **SHIFT (LOCAL)** key.  
The **REMOTE** LED goes out.

## 4.4.1 Message Format

### Program Messages

Program messages can be either Command Messages or Query Messages.

- **Command Messages**

Instructions to control the instrument, such as to change settings or reset

Example: instruction to set the measurement range

**:CURRENT:RANGE 0.1**

- **Query Messages**

Requests for responses relating to results of operation or measurement, or the state of instrument settings.

Example: Command for inquiring current measurement range

**:CURRENT:RANGE?**

**For details:**

**See** "Headers" (⇒ p.63), "Separators" (⇒ p.64), "Data Formats" (⇒ p.64)

### Response Messages

When a query message is received, its syntax is checked and a response message is generated.

The "**:HEADer**" command determines whether headers are prefixed to response messages.

Header ON     **:CURRENT:RANGE 0.1**  
 Header OFF   **0.1**  
                   (the current range is 100 mA)

At power-on, Header ON is selected.

If an error occurs when a query message is received, no response message is generated for that query.

There are also messages such as \*TST? that do not have a header.

### Confirmation Messages

**RS-232C**

A confirmation message is created from three-digit numeric data (ASCII code) after analyzing and running 1 line of data (data up to the terminator) from the controller.

This numeric data is returned to the controller. This data makes it possible to synchronize controller and instrument operations. (⇒ p.102)

Example: Confirmation messages

000: Indicates the transferred command ended normally.

001: The command at the beginning (first) of the program message was not correctly processed.

010: The 10th command in the program message was not correctly processed.

**NOTE**

- When a confirmation message is specified, import it after sending the program message as the instrument will not otherwise properly synchronize with the controller. This message also works with GP-IB and must be received. Any query commands should be added at the end of a response message.
- A command that generates command errors, execution errors or device dependent errors is regarded as abnormal.

## Command Syntax

Command names are chosen to mnemonically represent their function, and can be abbreviated. The full command name is called the "long form", and the abbreviated name is called the "short form".

The command references in this manual indicate the short form in upper-case letters, extended to the long form in lower case letters, although the commands are not case-sensitive in actual usage.

<b>DISPLAY</b>	OK (long form)
<b>DISP</b>	OK (short form)
<b>DISPL</b>	Error
<b>DIS</b>	Error

Response messages generated by the instrument are in long form and in upper case letters.

## Headers

Headers must always be prefixed to program messages.

### (1) Command Program Headers

There are three types of commands: Simple, Compound and Standard.

- **Headers for Simple Commands**

This header type is a sequence of letters and digits

**:ESE0 1**

- **Headers for Compound Commands**

These headers consist of multiple simple command type headers separated by colons ":"

**:CURRENT:RANGE**

- **Headers for Standard Commands**

This header type begins with an asterisk "\*", indicating that it is a standard command defined by IEEE 488.2.

**\*RST**

### (2) Query Program Header

These commands are used to interrogate the instrument about the results of operations, measured values and the current states of instrument settings.

As shown by the following examples, a query is formed by appending a question mark "?" after a program header.

**\*TST?**

---

## 4.4 Communication Methods

---

### Message Terminators

This instrument recognizes the following message terminators:

#### GP-IB

- LF
- CR+LF
- EOI
- LF with EOI

#### RS-232C

- LF
- CR+LF

From the instrument's interface settings, the following can be selected as the terminator for response messages.

#### GP-IB

- LF with EOI
- LF with CR and EOI (initial setting)

#### RS-232C

- LF
- CR+LF (initial setting)

See "Set and query the response message terminator" (⇒ p.107)

### Separators

#### (1) Message Unit Separator

Multiple message can be written in one line by separating them with semicolons ";".

```
:CURRENT:RANGE 0.1;:AVERaging 10
```

When messages are combined in this way and if one command contains an error, all subsequent messages up to the next terminator will be ignored.

#### (2) Header Separator

In a message containing multiple data items, commas are required to separate the data items from one another.

```
:CURRENT:RANGE 0.1
```

#### (3) Data Separator

In a message containing multiple data items, commas are required to separate the data items from one another.

```
:MEASure? V,A
```

### Data Formats

The instrument uses character data and decimal numeric data, depending on the command.

#### (1) Character Data

Character data always begins with an alphabetic character, and subsequent characters may be either alphabetic or numeric. Character data is not case-sensitive, although response messages from the instrument are only upper case.

```
:HOLD ON
```

#### (2) Decimal Numeric Data

Three formats are used for numeric data, identified as NR1, NR2 and NR3. Numeric values may be signed or unsigned. Unsigned numeric values are handled as positive values.

Values exceeding the precision handled by the instrument are rounded to the nearest valid digit.

- NR1 Integer data(e.g.: +12, -23, 34)
- NR2 Fixed-point data(e.g.:+1.23, -23.45, 3.456)
- NR3 Floating-point exponential representation data(e.g.:+1.0E-2, -2.3E+4)

The term "NRf format" includes all three of the above numeric decimal formats. The instrument accepts NRf format data.

The format of response data is specified for each command, and the data is sent in that format.

**:AVERAGING** 10



The instrument does not fully support IEEE 488.2. As much as possible, please use the data formats shown in the Reference section.

Also, be careful to avoid constructing single commands that could overflow the input buffer or output queue.

## Compound Command Header Omission

When several commands having a common header are combined to form a compound command (e.g., **:CURRENT:RANGE** and **:CURRENT:AUTO**), if they are written together in sequence, the common portion (here, **:CURRENT:**) can be omitted after its initial occurrence.

This common portion is called the "current path" (analogous to the path concept in controller file storage), and until it is cleared, the interpretation of subsequent commands presumes that they share the same common portion. This usage of the current path is shown in the following example:

### Full expression

**:CURRENT:RANGE 0.1;:CURRENT:AUTO ON**

### Compacted expression

**:CURRENT:RANGE 0.1;AUTO ON**



This portion becomes the current path, and can be omitted from the messages immediately following.

The current path is cleared when the power is turned on, when reset by key input, by a colon ":" at the start of a command, and when a message terminator is detected.

Standard command messages can be executed regardless of the current path. They have no effect upon the current path.

A colon ":" is not required at the start of the header of a Simple or Compound command. However, to avoid confusion with abbreviated forms and operating mistakes, we recommend always placing a colon at the start of a header.



In this instrument, the current path is as follows

**:CURRENT:, :DATAout:, :INTEGrate:, :RS232c:,  
:SCALE:, :TRANsmit:, :VOLTage:**

## 4.4.2 Output Queue and Input Buffer

### Output Queue

Response messages are stored in the output queue until read by the controller. The output queue is also cleared in the following circumstances:

- Power on
- Device clear 
- Query Error 

The output queue capacity of the instrument is 1000 bytes. If response messages overflow the buffer, a query error is generated and the output queue is cleared.

Also, with GP-IB, if a new message is received while data remains in the output queue, the output queue is cleared and a query error is generated.

### Input Buffer

The output queue capacity of the instrument is 500 bytes. When the input buffer receives data that exceeds 500 bytes and becomes full, the GP-IB interface buss waits until buffer space becomes available.

RS-232C does not receive data that exceeds 500 bytes. For example, if it receives 520 bytes from the controller, the 20 bytes from the 501st byte are not received.

#### NOTE

Ensure that the no command ever exceeds 500 bytes.


---



### 4.4.3 Status Byte Register

**GP-IB**

This instrument implements the status model defined by IEEE 488.2 with regard to the serial poll function using the service request line. The term "event" refers to any occurrence that generates a service request.



#### Overview of Service Request Occurrence

The Status Byte Register contains information about the event registers and the output queue. Required items are selected from this information by masking with the Service Request Enable Register. When any bit selected by the mask is set, bit 6 (MSS; the Master Summary Status) of the Status Byte Register is also set, which generates an SRQ (Service Request) message and dispatches a service request.

#### NOTE

SRQ (Service Request) is a GP-IB only function. However, STB (Status Byte Register) data uses the **\*STB?** command, RS-232C can also access this information.

**RS-232C**

RS-232C does not provide a function for issuing service requests. Still, SRER setup and STB reading are available.

## Status Byte Register (STB)

During serial polling, the contents of the 8-bit Status Byte Register are sent from the instrument to the controller.

When any Status Byte Register bit enabled by the Service Request Enable Register has switched from 0 to 1, the MSS bit becomes 1. Consequently, the SRQ bit is set to 1, and a service request is dispatched.

The SRQ bit is always synchronous with service requests, and is read and simultaneously cleared during serial polling. Although the MSS bit is only read by an **\*STB?** query, it is not cleared until a clear event is initiated by the **\*CLS** command.

Bit 7		unused
Bit 6	SRQ	Set to 1 when a service request is dispatched.
	MSS	This is the logical sum of the other bits of the Status Byte Register.
Bit 5	ESB	Standard Event Status (logical sum) bit This is logical sum of the Standard Event Status Register.
Bit 4	MAV	Message available Indicates that a message is present in the output queue.
Bit 3		unused
Bit 2	ESB2	Event Status (logical sum) bit 2 This is the logical sum of Event Status Register 2.
Bit 1	ESB1	Event Status (logical sum) bit 1 This is the logical sum of Event Status Register 1.
Bit 0	ESB0	Event Status (logical sum) bit 0 This is the logical sum of Event Status Register 0.

## Service Request Enable Register (SRER)

This register masks the Status Byte Register. Setting a bit of this register to 1 enables the corresponding bit of the Status Byte Register to be used.

## 4.4.4 Event Registers

### Standard Event Status Register (SESR)

The Standard Event Status Register is an 8-bit register.

If any bit in the Standard Event Status Register is set to 1 (after masking by the Standard Event Status Enable Register), bit 5 (ESB) of the Status Byte Register is set to 1.

**See** "Standard Event Status Register (SESR) and Standard Event Status Enable Register (SESER)" (⇒ p.70)

The Standard Event Status Register is cleared in the following situations:


- When a **\*CLS** command is executed
- When an event register query (**\*ESR?**) is executed
- When the instrument is powered on

Bit 7	PON	Power-On Flag Set to 1 when the power is turned on, or upon recovery from an outage.
Bit 6	URQ	User Request unused
Bit 5	CME	Command error. (The command to the message terminator is ignored.) This bit is set to 1 when a received command contains a syntactic or semantic error: <ul style="list-style-type: none"> <li>• Program header error</li> <li>• Incorrect number of data parameters</li> <li>• Invalid parameter format</li> <li>• Received a command not supported by the instrument</li> </ul>
Bit 4	EXE	Execution Error This bit is set to 1 when a received command cannot be executed for some reason. <ul style="list-style-type: none"> <li>• The specified data value is outside of the set range</li> <li>• The specified setting data cannot be set (Invalid data format)</li> </ul>
Bit 3	DDE	Device-Dependent Error This bit is set to 1 when a command cannot be executed due to some reason other than a command error, a query error or an execution error. <ul style="list-style-type: none"> <li>• Execution is impossible due to an internal instrument fault (Error indication)</li> <li>• The received command cannot be executed during a limited operation (Integration or Hold)</li> <li>• A value outside the range is read in using the "MEASure?" command when "o.r" is on.</li> </ul>
Bit 2	QYE	Query Error (the output queue is cleared) This bit is set to "1" when an abnormality occurs in processing an output queue <ul style="list-style-type: none"> <li>• When an attempt has been made to read an empty output queue (GP-IB only)</li> <li>• When the data overflows the output queue</li> <li>• When the controller sends the next command before reading data from the output queue (GP-IB only)</li> <li>• When a *IDN? query is followed by a query in the same line</li> </ul>
Bit 1	RQC	Controller privilege request unused
Bit 0	OPC	Operation Complete This bit is set to 1 in response to an *OPC command. <ul style="list-style-type: none"> <li>• It indicates the completion of operations of all messages up to the *OPC command</li> </ul>

### Standard Event Status Enable Register (SESER)

Setting any bit of the Standard Event Status Enable Register to 1 enables access to the corresponding bit of the Standard Event Status Register.

#### Standard Event Status Register (SESR) and Standard Event Status Enable Register (SESER)



### Device-Specific Event Status Registers (ESR0, ESR1 and ESR2)

This instrument provides three event status registers for controlling events. Each event register is an 8-bit register.

When any bit in one of these event status registers enabled by its corresponding event status enable register is set to 1, the following happens:

- For Event Status Register 0, bit 0 (ESB0) of the Status Byte Register (STB) is set to 1.
- For Event Status Register 1, bit 1 (ESB1) of the Status Byte Register (STB) is set to 1.
- For Event Status Register 2, bit 2 (ESB2) of the Status Byte Register (STB) is set to 1.

Event Status Registers 0, 1 or 2 are cleared in the following situations:

- When a \*CLS command is executed
- When an Event Status Register query (:ESR0?, :ESR1? or :ESR2?) is executed
- When the instrument is powered on

#### Event Status Register 0 (ESR0)

Bit 7	DS	Data update
Bit 6	FOR	Frequency o.r
Bit 5	–	Held at 0
Bit 4	IE	Integration end
Bit 3	AVG	The averaged data display has been updated, or the averaging time has elapsed during Display Hold.
Bit 2	IDO	Integration value is $\pm 999999M$
Bit 1	PODI	The positive power integration value (including voltage or current peak over)
Bit 0	MODI	The negative power integration value (including voltage or current peak over)

#### Event Status Register 1 (ESR1)

Bit 7	AOW	The average power value (including "o.r")
Bit 6	AOA	The average current value (including "o.r")
Bit 5	AOV	The average voltage value (including "o.r")
Bit 4	OA	OVER-A current peak over
Bit 3	OV	OVER-V v peak over
Bit 2	HW	HIGH-W Power "o.r"
Bit 1	HA	HIGH-A Current "o.r"
Bit 0	HV	HIGH-V Voltage "o.r"


#### Event Status Register 2 (ESR2)

Bit 7	BE	The setting and integration value could not be written to backup memory.
Bit 6	CPODI	The positive current integration value (including current peak over)
Bit 5	CMODI	The negative current integration value (including current peak over)
Bit 4	–	Held at 0
Bit 3	–	Held at 0
Bit 2	–	Held at 0
Bit 1	–	Held at 0
Bit 0	–	Held at 0

4.4 Communication Methods

Event Status Registers 0 (ESR0), 1 (ESR1) and 2 (ESR2), and Event Status Enable Registers 0 (ESER0), 1 (ESER1) and 2 (ESER2)

Status Byte Register (STB)



## Register Reading and Writing

Register	Read	Write
Status Byte Register	*STB?	–
Service Request Enable Register	*SRE?	*SRE
Standard Event Status Register	*ESR?	–
Standard Event Status Enable Register	*ESE?	*ESE
Event Status Register 0	:ESR0?	–
Event Status Enable Register 0	:ESE0?	:ESE0
Event Status Register 1	:ESR1?	–
Event Status Enable Register 1	:ESE1?	:ESE1
Event Status Register 2	:ESR2?	–
Event Status Enable Register 2	:ESE2?	:ESE2

## GP-IB Commands

The following commands can be used for performing interface functions.

Com- mand	Description	
GTL	Go To Local	Cancels the Remote state and enters the Local state.
LLO	Local Lock Out	Disables all keys, including the <b>LOCAL</b> key.
DCL	Device CLear	Clears the input buffer and the output queue.
SDC	Selected Device Clear	Clears the input buffer and the output queue.
GET	Group Execute Trigger	When the display values or the peak values are held, processes one sample.

## 4.4.5 Initialization Items

●: initialized/ –: not initialized

Item	Initialization method	Power on	Key reset (⇒ p.50)	*RST command	Device clear (GP-IB only)	*CLS command	Initial setting
GP-IB address		–	●	–	–	–	1
RS-232C setting (fixed)		–	–	–	–	–	–
Device specific functions (ranges etc.)		–	●	●	–	–	(⇒ p.51)
Output queue		●	●	–	●	–	–
Input buffer		●	●	–	●	–	–
Status byte register		●	●	–	– *1	●*2	–
Event register		●*3	●	–	–	●	–
Enable register		●	●	–	–	–	0
Current path		●	●	–	●	–	–
Headers on/off		●	●	●	–	–	ON
Output items		●	●	●	–	–	All items output
Response message terminator		●	●	–	–	–	CR+LF
Response message separator		●	●	●	–	–	;

\*1. Only the MAV bit (bit 4) is cleared.

\*2. All bits except the MAV bit are cleared.

\*3. Except the PON bit (bit 7).




## 4.4.6 Command Execution Time

Command execution time indicates the time for analyzing and processing long form commands.

However, the command execution time for commands with data is the time described according to the data format specified in the <data portion>, and for query commands it is the time when the header is ON.

### NOTE

- Due to internal processing, there may be a maximum time lag of 50 ms between command reception and analysis in this instrument.
- When an analysis cannot be completed in the time allotted for internal processing, data display is delayed.
- All commands are sequential commands.
- In communications with the controller, time must be added for data transmission.
- GP-IB transfer time depends on the controller.  
The time for RS-232C transfers involving a total of 10 bits (the start bit is 1, data length is 8, no parity, stop bit is 1) is shown below.  
9600 bps: approximately 960 characters/s
- Wait until measurements stabilize after a change before using a setting command.



Command	Execution time
*RST	200 ms or less
*TRG (including GET) *WAI :MEASure? :HOLD :PEAKhold	When measurement values appear: 200 ms or less No indication: wait for a measurement value to appear
:INTEGrate:STATe	250 ms or less
:CURRent:RANGe :VOLTage:RANGe :INTEGrate:TIME :SCALe:CT :SCALe:VT	50 ms or less
*TST?	6 s
Commands other than those above	20 ms or less

## 4.5 Message List

Commands specific to RS-232C or GP-IB are identified by  or , respectively.

### 4.5.1 Standard Commands

Command	Data Formats (Response data if a Query)	Description	Error	Ref page
<b>*CLS</b>		Clears the event registers and the Status Byte Register.	*1	84
<b>*ESE</b>	0 to 255 (NR1)	Sets the contents of the Standard Event Status Enable Register.	*3, *5	85
<b>*ESE?</b>	0 to 255 (NR1)	Queries the Standard Event Status Enable Register.	*2, *5	85
<b>*ESR?</b>	0 to 255 (NR1)	Queries the Standard Event Status Register.	*2	85
<b>*IDN?</b>	<Manufacturer's name>,<Model name>,<Serial number>,<Software version>	Queries the Device ID.	*2, *5	82
<b>*OPC</b>	_____		*1, *5	84
<b>*OPC?</b>	1	Queries execution completion.	*2, *5	84
<b>*RST</b>	_____	Initializes the device.	*1	83
<b>*SRE</b>	0 to 255 (NR1)	Sets the Service Request Enable Register.	*3, *5	86
<b>*SRE?</b>	0 to 255 (NR1)	Queries the contents of the Service Request Enable Register.	*2, *5	86
<b>*STB?</b>	0 to 119 (NR1)	Queries the Status Byte Register.	*2	86
<b>*TRG</b>	_____	Executes one sampling.	*1, *4, *5	86
<b>*TST?</b>	0 to 4 (NR1)	Initiates a self-test and queries the result.	*2	83
<b>*WAI</b>	_____	Wait for operations to finish.	*1, *5	84

Error description (an error occurs when executing messages in the following cases):

- \*1 Command Error.....When data is present after the command
- \*2 Query Error.....When the response message exceeds 1000 bytes, or when a query follows \*IDN?.
- \*3 Execution Error.....When invalid character or numeric data is present
- \*4 Device dependent Error.....When this command is executed at times other than in the hold state
- \*5 Device dependent Error.....When the self-test generates an error

**NOTE:**

- A misspelled message and the presence of data after a query always produce a command error.
- < > = contents of the data portion.  
Numeric data values are indicated by format as (NR1), (NR2) and (NR3), representing integer, fixed-point and floating point decimal data values respectively, or as (NRf), representing any of these formats.
- In GP-IB, Event Status Enable Register and \*SRE can be set to enable SRQ interrupts to the controller.
- When each query ends in some kind of error, no response message is created for the query.

## 4.5.2 Device-Specific Commands

Command	Data Contents ( ) = response data	Description	Error	Ref page
<b>Event registers</b>				
<b>:ESE0</b>	0 to 255	Sets Event Status Enable Register 0.	*3, *5	87
<b>:ESE0?</b>	(0 to 255)	Queries Event Status Enable Register 0.	*2, *5	87
<b>:ESR0?</b>	(0 to 255)	Queries Event Status Register 0.	*2, *5	88
<b>:ESE1</b>	0 to 255	Sets Event Status Enable Register 1.	*3, *5	87
<b>:ESE1?</b>	(0 to 255)	Queries Event Status Enable Register 1.	*2, *5	87
<b>:ESR1?</b>	(0 to 255)	Queries Event Status Register 1.	*2, *5	88
<b>:ESE2</b>	0 to 255	Sets Event Status Enable Register 2.	*3, *5	88
<b>:ESE2?</b>	(0 to 255)	Queries Event Status Enable Register 2.	*2, *5	88
<b>:ESR2?</b>	(0 to 255)	Queries Event Status Register 2.	*2, *5	88
<b>Rectifier type</b>				
<b>:RECTifier</b>	ACDC/ DC/ AC	Sets rectifier type	*3, *4 *5, *6	89
<b>:RECTifier?</b>	ACDC/ DC/ AC	Queries rectifier type	*2, *5	89
<b>Voltage range</b>				
<b>:VOLTage?</b>		Queries voltage setting	*2, *5	90
<b>:VOLTage:AUTO</b>	ON/ OFF	Sets voltage auto-range	*3, *4 *5, *6	90
<b>:VOLTage:AUTO?</b>	(ON/ OFF)	Queries voltage auto-range	*2, *5	90
<b>:VOLTage:RANGe</b>	<Voltage range (NR1)>	Sets voltage range	*3, *4 *5, *6	91
<b>:VOLTage:RANGe?</b>	(<Voltage range (NR1)>)	Queries voltage range	*2, *5	91
<b>Current range</b>				
<b>:CURRent?</b>		Queries current setting	*2, *5	92
<b>:CURRent:AUTO</b>	ON/ OFF	Sets current auto-range	*3, *4 *5, *6	92
<b>:CURRent:AUTO?</b>	(ON/ OFF)	Queries current auto-range	*2, *5	92
<b>:CURRent:RANGe</b>	<Current range(NR2)>	Sets current range	*3, *4 *5, *6	93
<b>:CURRent:RANGe?</b>	(<Current range(NR2)>)	Queries current range	*2, *5	93

Error description (an error occurs when executing messages in the following cases):

- \*1 Command Error..... When data is present after the command
- \*2 Query Error ..... When the response message exceeds 1000 bytes, or when a query follows \*IDN?
- \*3 Execution Error ..... When invalid character or numeric data is present
- \*4 Device dependent Error .... When this command is executed in the hold state (HOLD LED lights or flashes)
- \*5 Device dependent Error .... When the self-test generates an error
- \*6 Device dependent Error .... When this command is executed during integrating (INTEGRATOR LED lights or flashes)

For information on other errors, refer to the notes attached to each command.

### NOTE:

- A misspelled message and the presence of data after a query always produce a command error. (except :MEASure?)
- < > = contents of the data portion.  
[Numeric data values are indicated by format as (NR1), (NR2) and (NR3), representing integer, fixed-point and floating point decimal data values respectively, or as (NRf), representing any of these formats]
- In GP-IB, Event Status Enable Register and \*SRE can be set to enable SRQ interrupts to the controller.
- When each query ends in some kind of error, no response message is created for the query.

## 4.5 Message List

Command	Data Contents ( ) = response data	Description	Error	Ref page
<b>Integration</b>				
<b>:INTEGrate?</b>		Queries integration time and integration condition	*2, *5	94
<b>:INTEGrate:STATe</b>	<Integration condition> <Integration condition> = START/ STOP/ RESET	Sets the condition of the integrate operation	*3, *5	95
<b>:INTEGrate:STATe?</b>		Queries integration condition	*2, *5	95
<b>:INTEGrate:TIME</b>	<hours(NR1)>,<minutes(NR1)>	Sets integration time	*3, *5, *6	95
<b>:INTEGrate:TIME?</b>		Queries integration time	*2, *5	95
<b>Analog output items</b>				
<b>:AOUT</b>	<output item> <output item> = VA/ PF/ PAH/ MAH/ AH/ PWH/ MWH/ WH	Sets analog output item	*3, *5	94
<b>:AOUT?</b>		Queries analog output item	*2, *5	94
<b>Average times (average)</b>				
<b>:AVERaging</b>	1/ 2/ 5/ 10/ 25/ 50/ 100 (NR1)	Sets average times	*3, *4, *5	89
<b>:AVERaging?</b>	(1/ 2/ 5/ 10/ 25/ 50/ 100)	Queries average times	*2, *5	89
<b>VT (PT)/CT ratio</b>				
<b>:SCALE?</b>	(<VT ratio>;<CT ratio>)	Queries VT (PT) and CT ratio settings	*2, *5	104
<b>:SCALE:VT (:SCALE:PT)</b>	1/ 2/ 4/ 10/ 20/ 30/ 60/ 100 (NR1)	Sets VT (PT) ratio	*3,*4 *5, *6	104
<b>:SCALE:VT? (:SCALE:PT?)</b>	(<VT(PT) ratio(NR1)>)	Queries VT (PT) ratio	*2, *5	104
<b>:SCALE:CT</b>	1/ 2/ 3/ 4/ 5/ 6/ 8/ 10/ 12/ 15/ 16/ 20/ 24/ 25/ 30/ 40/ 50/ 60/ 75/ 80/ 100/ 200/ 300/ 500/ 1000/ 2000/ 3000/ 5000/ 10000 (NR1)	Sets CT ratio	*3, *4 *5, *6	105
<b>:SCALE:CT?</b>	(<CT ratio(NR1)>)	Queries CT ratio	*2, *5	105

Error description (an error occurs when executing messages in the following cases):

- \*1 Command Error.....When data is present after the command
- \*2 Query Error.....When the response message exceeds 1000 bytes, or when a query follows \*IDN?
- \*3 Execution Error.....When invalid character or numeric data is present
- \*4 Device dependent Error.....When this command is executed in the hold state (HOLD LED lights or flashes)
- \*5 Device dependent Error.....When the self-test generates an error
- \*6 Device dependent Error.....When this command is executed during integrating (INTEGRATOR LED lights or flashes)

For information on other errors, refer to the notes attached to each command.

**NOTE:**

- A misspelled message and the presence of data after a query always produce a command error. (except :MEASure?)
- < > = contents of the data portion.  
[Numeric data values are indicated by format as (NR1), (NR2) and (NR3), representing integer, fixed-point and floating point decimal data values respectively, or as (NRf), representing any of these formats]
- In GP-IB, Event Status Enable Register and \*SRE can be set to enable SRQ interrupts to the controller.
- When each query ends in some kind of error, no response message is created for the query.

Command	Data Contents ( ) = response data	Description	Error	Ref page
<b>Display items</b>				
<b>:DISPlay</b>	<Display area a>, <Display area b>, <Display area c>, <Display area d> <Display area a> = V/ A/ W/ VA/ PF/ AH/ WH <Display area b> = A/ W/ PWH/ MWH/ WH/ PAH/ MAH/ AH/ TIME <Display area c> = W/ PF/ FREQ/ PWH/ MWH/ WH/ PAH/ MAH/ AH <Display area d> = V/ A/ W/ VA/ PF/ VPK/ APK/ TIME	Sets display item	*3, *5	96
<b>:DISPlay?</b>		Queries display item	*2, *5	96
<b>Hold</b>				
<b>:HOLD</b>	ON/OFF	Sets display hold ON or OFF	*3, *5	97
<b>:HOLD?</b>		Queries whether or not the display is currently held	*2, *5	97
<b>:PEAKhold</b>	ON/OFF	Enables or disables the peak value hold function	*3, *5	97
<b>:PEAKhold?</b>		Queries whether or not the display of peak value is currently held	*2, *5	97
<b>Header</b>				
<b>:HEADer</b>	ON/OFF	Sets header	*3, *5	96
<b>:HEADer?</b>		Queries the header	*2, *5	96
<b>Measurement data</b>				
<b>:MEASure?</b>	<Item 1>, *** <Item 15> V/ A/ W/ VA/ PF/FREQ/ PAH/ MAH/ AH/ PWH/ MWH/WH/ VPK/ APK/ TIME (A total of fifteen items can, but need not, be set.)	Queries set measurement data	*2, *3 *5	98
<b>:DATAout:ITEM</b>	<Item 1 (NR1)>, <Item 2 (NR1)>	Sets ":MEASure?" output item	*3, *5	100
<b>:DATAout:ITEM?</b>		Queries ":MEASure?" output item	*2, *5	100

Error description (an error occurs when executing messages in the following cases):

- \*1 Command Error.....When data is present after the command
- \*2 Query Error .....When the response message exceeds 1000 bytes, or when a query follows \*IDN?
- \*3 Execution Error .....When invalid character or numeric data is present
- \*4 Device dependent Error ....When this command is executed in the hold state (HOLD LED lights or flashes)
- \*5 Device dependent Error ....When the self-test generates an error
- \*6 Device dependent Error ....When this command is executed during integrating (INTEGRATOR LED lights or flashes)

For information on other errors, refer to the notes attached to each command.

**NOTE:**

- A misspelled message and the presence of data after a query always produce a command error. (except :MEASure?)
- < > = contents of the data portion.  
[Numeric data values are indicated by format as (NR1), (NR2) and (NR3), representing integer, fixed-point and floating point decimal data values respectively, or as (NRf), representing any of these formats]
- In GP-IB, Event Status Enable Register and \*SRE can be set to enable SRQ interrupts to the controller.
- When each query ends in some kind of error, no response message is created for the query.

## 4.5 Message List

Command	Data Contents ( ) = response data	Description	Error	Ref page
<b>RS-232C</b>				
	<b>RS-232C</b>			
<b>:RS232c?</b>		Queries RS-232C settings	*2	101
<b>:RS232c:ANSWer</b>	ON/ OFF	Sets confirmation message	*3	102
<b>:RS232c:ANSWer?</b>		Queries confirmation message	*2	102
<b>:RS232c:ERRor?</b>		Queries RS-232C communication error	*2	103
<b>:RS232c:HANDshake</b>	HARD/ OFF	Sets RS-232C communication handshake	*3	103
<b>:RS232c:HANDshake?</b>		Queries RS-232C communication handshake	*2	103
<b>Separator, terminator</b>				
<b>:TRANsmit:SEParator</b>	0/ 1 (NR1)	Sets message unit and separator	*3, *5	106
<b>:TRANsmit:SEParator?</b>	(0/ 1)	Queries message unit and separator	*2, *5	106
<b>:TRANsmit:TERMinator</b>	0/ 1 (NR1)	Set message and terminator	*3	107
<b>:TRANsmit:TERMinator?</b>	(0/ 1)	Queries message and terminator	*2, *5	107

Error description (an error occurs when executing messages in the following cases):

- \*1 Command Error.....When data is present after the command
- \*2 Query Error.....When the response message exceeds 1000 bytes, or when a query follows \*IDN?
- \*3 Execution Error.....When invalid character or numeric data is present
- \*4 Device dependent Error.....When this command is executed in the hold state (HOLD LED lights or flashes)
- \*5 Device dependent Error.....When the self-test generates an error
- \*6 Device dependent Error.....When this command is executed during integrating (INTEGRATOR LED lights or flashes)

For information on other errors, refer to the notes attached to each command.

### NOTE:

- A misspelled message and the presence of data after a query always produce a command error. (except :MEASure?)
- < > = contents of the data portion.  
[Numeric data values are indicated by format as (NR1), (NR2) and (NR3), representing integer, fixed-point and floating point decimal data values respectively, or as (NRf), representing any of these formats]
- In GP-IB, Event Status Enable Register and \*SRE can be set to enable SRQ interrupts to the controller.
- When each query ends in some kind of error, no response message is created for the query.

## 4.6 Message Reference

**< >:** Indicates the contents (character or numeric parameters) of the data portion of a message. Character parameters are returned as all capital letters.

**Numeric Parameters:**

- NRf Number format may be any of NR1, NR2 and NR3
- NR1 Integer data(e.g.: +12, -23, 34)
- NR2 Fixed-point data(e.g.: +1.23, -23.45, 3.456)
- NR3 Floating-point exponential representation data (e.g.: +1.0E-2, -2.3E+4)

Shows the command description.

### Read/Write the Standard Event Status Enable Register (SESER)

Shows the message syntax.

Explains the command data or response message.

**Syntax** Command **\*ESE <0 to 255 (NR1)>**  
 Query **\*ESE?**  
 Response **<0 to 255 (NR1)>**

Describes the message.

**Description** Command The SESER mask is set to the numerical value 0 to 255. The initial value (at power-on) is 0.  
 Query The contents of the SESER, as set by the \*ESE command, are returned as an NR1 value (0 to 255).

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
PON	URQ	CME	EXE	DDE	QYE	RQC	OPC

Shows an example of an actual command application.

(Normally described with HEADER ON, (except the HEADER command itself).)

**Example** Command **\*ESE 36**  
 (Sets bits 5 and 2 of SESER)

## 4.6.1 Standard Commands

Messages specific to the RS-232C or GP-IB interface are identified by their corresponding symbols.

### (1) System Data Command

#### Queries device ID.

<b>Syntax</b>	Query	<b>*IDN?</b>
	Response	<Manufacturer's name>,<Model name>,<Model code>,<Software version>
<b>Example</b>	Response	<b>HIOKI, 3334, 00, V1.00</b> The Device ID is HIOKI, 3334, Model code 00 (standard model), software version 1.00.
	<b>Note</b>	<ul style="list-style-type: none"> <li>• The response message has no header.</li> <li>• In the model code, 00 denotes the standard model (3334) while 01 the model with GP-IB support (3334-01).</li> <li>• "*IDN?" is the last query message of the program messages. Thus a subsequent query on the same line will generate a query error and no response message is output.</li> </ul>



**(2) Internal Operation Command****Initialize Device (system reset)**

<b>Syntax</b>	Command	<b>*RST</b>
<b>Description</b>	Command	Resets instrument settings to factory defaults. Default setting: "4.4.5 Initialization Items" (⇒ p.74)
<b>Note</b>		<ul style="list-style-type: none"> <li>• The GP-IB address is not initialized.</li> <li>• Communication handshake, confirmation message and response message terminator settings are not initialized.</li> <li>• This command runs also in the event of a system error.</li> </ul>

**Execute Self-Test and Query the Result**

<b>Syntax</b>	Query	<b>*TST?</b>
	Response	<0 to 4 (NR1)> 0: No Errors 1: ROM Error 2: RAM Error 3: Control circuit Error 4: Backup data Error
<b>Description</b>		Perform instrument self-test and return the result as numerical value 0 to 4.
<b>Example</b>	Query	<b>*TST?</b>
	Response	<b>1</b> A ROM error occurred.
<b>Note</b>		<ul style="list-style-type: none"> <li>• A header is not added to the response message.</li> <li>• Device dependent error/ If this command is executed during integrating (<b>INTEGRATOR</b> LED lights) and hold state (<b>HOLD</b> LED lights or flashes).</li> <li>• This query runs also in the event of a system error.</li> </ul>

## (3) Synchronization Commands

**Set the OPC bit of SESR When Finished All Pending Operations**

<b>Syntax</b>	Command	<b>*OPC</b>
<b>Description</b>	Sets OPC bit 0 of the Standard Event Status Register (SESR) when all prior commands have finished processing.	
<b>Example</b>	<b>:MEAS? ; *OPC</b>	The OPC bit of the SESR is set after commands MEAS? have finished processing.

**Set 1 in the output queue after completing all running operations**

<b>Syntax</b>	Query	<b>*OPC?</b>
	Response	<b>1</b>
<b>Description</b>	.When the command (of transferred commands) prior to the *OPC command has finished processing, "1" is stored in the output queue.	
<b>Example</b>	<b>:MEAS? ; *OPC?</b>	"1" is stored in the output queue after MEAS? data has been created.
<b>Note</b>	A header is not added to the response message.	

**Wait until display update finishes before executing the next command.**

<b>Syntax</b>	Command	<b>*WAI</b>
<b>Description</b>	No commands after *WAI are run until the next display update completes.	
<b>Example</b>	<b>:MEAS? V,A,W ; *WAI ; :MEAS? V,A,W</b>	Data is imported at each display update.
<b>Note</b>	<ul style="list-style-type: none"> <li>• If this command is executed in the hold state, the displayed data will not change.</li> <li>• If this command is executed during range switching over, no displays change.</li> <li>• The longest possible wait period is 200 ms.</li> </ul>	

## (4) Status and Event Control Commands

**Clear the Status Byte Registers and Event Registers**

<b>Syntax</b>	Command	<b>*CLS</b>
<b>Description</b>	Clears the event registers. Also clears the bit of the Status Byte Register corresponding to event registers.(SESR, ESR0, ESR1, ESR2, RS232c:ERRor)	
<b>Note</b>	<ul style="list-style-type: none"> <li>• The output queue, the various enable registers and MAV bit 4 of the Status Byte Register are unaffected.</li> <li>• This command runs also in the event of a system error.</li> </ul>	

## Read/Write the Standard Event Status Enable Register (SESER)

<b>Syntax</b>	Command	<b>*ESE</b> <0 to 255 (NR1)>
	Query	<b>*ESE?</b>
	Response	<0 to 255 (NR1)>
<b>Description</b>	Command	The SESER mask is set to the numerical value 0 to 255. The initial value (at power-on) is 0. (⇒ p.69) The numerical value can be in NRf format, but any digits after the decimal point will be rounded. Since the 3334 does not use URQ (bit6) and RQC (bit 1), these events do not occur even when they are set to 1.
	Query	The contents of the SESER, as set by the *ESE command, are returned as an NR1 value (0 to 255).

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
PON	URQ	CME	EXE	DDE	QYE	RQC	OPC

<b>Example</b>	Command	<b>*ESE 36</b> Sets bits 5 and 2 of SESER.
	Query	<b>*ESE?</b>
	Response	<b>*ESE 36</b> (Headers: ON) <b>36</b> (Headers: OFF)

## Read and Clear the Standard Event Status Register (SESR)

<b>Syntax</b>	Query	<b>*ESR?</b>
	Response	<0 to 255 (NR1)>
<b>Description</b>		Returns the contents of the SESR as an NR1 value from 0 to 255, then clears register contents. A header is not added to the response message. (⇒ p.69)

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
PON	URQ	CME	EXE	DDE	QYE	RQC	OPC

<b>Example</b>	<b>32</b> Bit 5 of the SESR was set to 1. The command error occurs.
----------------	---

- Note**
- This query runs also in the event of a system error.

## Write and Read the Service Request Enable Register (SRER)

<b>Syntax</b>	Command	<b>*SRE</b> <0 to 255 (NR1)>
	Query	<b>*SRE?</b>
	Response	<0 to 255 (NR1)>
<b>Description</b>	Command	The SRER mask is set to the numerical value 0 to 255. The numerical value can be in NRf format, but any digits after the decimal point will be rounded. Bits 3, 6 and 7 are ignored. The data is initialized to zero at power-on. (⇒ p.68)
	Query	The contents of the SRER, as set by the *SRE command, are returned as an NR1 value (0 to 255).

128 bit 7	64 bit 6	32 bit 5	16 bit 4	8 bit 3	4 bit 2	2 bit 1	1 bit 0
unused	unused	ESB	MAV	unused	ESE2	ESE1	ESE0

<b>Example</b>	Command	<b>*SRE 33</b> Set SRER bits 0 and 5 to 1.
	Query	<b>*SRE?</b>
	Response	<b>*SRE 33</b> (Headers: ON) <b>33</b> (Headers: OFF) SRER bits 0 and 5 have been set to 1.

## Read the Status Byte and MSS Bit

<b>Syntax</b>	Query	<b>*STB?</b>
	Response	<0 to 119 (NR1)>
<b>Description</b>	The contents of the STB are returned as an NR1 value (0 to 119). A header is not added to the response message. (⇒ p.68)	

128 bit 7	64 bit 6	32 bit 5	16 bit 4	8 bit 3	4 bit 2	2 bit 1	1 bit 0
unused	MSS	ESB	MAV	unused	ESE2	ESE1	ESE0

<b>Example</b>	Query	<b>*STB?</b>
	Response	<b>16</b> STB bit 4 has been set to 1.

- Note**
- Bit 6 is the MSS bit.
  - Even if service requests are cleared by serial polling, the MSS bit is not cleared.
  - This command runs also in the event of a system error.

## Request a Sample

<b>Syntax</b>	Command	<b>*TRG</b>
<b>Description</b>	Performs one measurement when the display values or peak values are held.	
<b>Example</b>	<b>:HOLD ON; *TRG; :MEAS?</b>	

## 4.6.2 Device-Specific Commands

### (1) Event Status Register

#### Read and Write Device-Specific Event Status Enable Registers ESER0, ESER1 and ESER2

##### ESER0

**Syntax** Command **:ESE0** <0 to 255 (NR1)>  
 Query **:ESE0?**  
 Response <0 to 255 (NR1)>

**Description** Command Sets the mask pattern in Event Status Enable Register 0 (ESER0) for the Event Status Register.(⇒ p.70)  
 The numerical value can be in NRf format, but any digits after the decimal point will be rounded.  
 Bits 3 and 5 are ignored.

128 bit 7	64 bit 6	32 bit 5	16 bit 4	8 bit 3	4 bit 2	2 bit 1	1 bit 0
DS	FOR	unused	IE	AVG	IDO	PODI	MODI

**Example** Command **:ESE0 4**  
 Set SRER0 bit 2 to 1.  
 Query **:ESE0?**  
 Response **:ESE0 4** (Headers: ON)  
**4** (Headers: OFF)

**Note** Data initializes to zero at power-on.

##### ESER1

**Syntax** Command **:ESE1** <0 to 255 (NR1)>  
 Query **:ESE1?**  
 Response <0 to 255 (NR1)>

**Description** Command Sets the mask pattern in Event Status Enable Register 1 (ESER1) for the Event Status Register.(⇒ p.70)  
 The numerical value can be in NRf format, but any digits after the decimal point will be rounded.

128 bit 7	64 bit 6	32 bit 5	16 bit 4	8 bit 3	4 bit 2	2 bit 1	1 bit 0
AOW	AOA	AOV	OA	OV	HW	HA	HV

**Example** Command **:ESE1 24**  
 Set ESER1 bits 3 and 4 to 1.  
 Query **:ESE1?**  
 Response **:ESE1 24** (Headers: ON)  
**24** (Headers: OFF)

**Note** • Data initializes to zero at power-on.

##### ESER2

### Read and Write Device-Specific Event Status Enable Registers ESER0, ESER1 and ESER2

<b>Syntax</b>	Command	<b>:ESE2</b> <0 to 255 (NR1)>
	Query	<b>:ESE2?</b>
	Response	<0 to 255 (NR1)>
<b>Description</b>	Command	Sets the mask pattern in Event Status Enable Register 2 (ESER2) for the Event Status Register.(⇒ p.70) The numerical value can be in NRf format, but any digits after the decimal point will be rounded. Bits 0 to 4 are ignored.

128 bit 7	64 bit 6	32 bit 5	16 bit 4	8 bit 3	4 bit 2	2 bit 1	1 bit 0
BE	CPODI	CMODI	unused	unused	unused	unused	unused

<b>Example</b>	Command	<b>:ESE2 96</b> Set ESER2 bits 5 and 6 to 1.
	Query	<b>:ESE2?</b>
	Response	<b>:ESE2 96</b> (Headers: ON) <b>96</b> (Headers: OFF)

**Note** Data initializes to zero at power-on.

### Read Device-Specific Event Status Registers ESR0, ESR1 and ESR2

<b>Syntax</b>	Query	<b>:ESR0?</b> <b>:ESR1?</b> <b>:ESR2?</b>
	Response	<0 to 255 (NR1)>
	<b>Description</b>	Query Returns event status register content as a numerical value in the NR1 format. A header is not added to the response message.
<b>Note</b>		<ul style="list-style-type: none"> <li>• Executing ESR0? clears the contents of ESR0.</li> <li>• Executing ESR1? clears the contents of ESR1.</li> <li>• Executing ESR2? clears the contents of ESR2.</li> </ul>

## (2) Rectifier type

### Sets and queries rectifier type

<b>Syntax</b>	Command	<b>:RECTifier</b> <Rectifier type>
	Query	<b>:RECTifier?</b>
	Response	<Rectifier type (NR1)> <Rectifier type (NR1)> = ACDC/ DC/ AC
<b>Description</b>	Command	Sets the rectifier type.
	Query	Returns rectifier type as character data.
<b>Example</b>	Command	<b>:RECT ACDC</b> Sets the rectifier type to AC/DC.
	Query	<b>:RECT?</b>
	Response	<b>:RECTIFIER ACDC</b> (Headers: ON) <b>ACDC</b> (Headers: OFF)

## (3) Average times (average)

### Sets and queries average times

<b>Syntax</b>	Command	<b>:AVERaging</b> <Average times (NR1)>
	Query	<b>:AVERaging?</b>
	Response	<Average times (NR1)> <Average times (NR1)> = 1/ 2/ 5/ 10/ 25/ 50/ 100
<b>Description</b>	Command	Sets the display average times The numerical value can be in NRf format, but any digits after the decimal point will be rounded.
	Query	Returns display average times as a numerical value in NR1 format.
<b>Example</b>	Command	<b>:AVER 10</b> The count for averaging is set to 10.
	Query	<b>:AVER?</b>
	Response	<b>:AVERAGING 10</b> (Headers: ON) <b>10</b> (Headers: OFF)
<b>Note</b>	<ul style="list-style-type: none"> <li>Averaging starts over when the range is changed. <b>See</b> Acquiring the averaged data (⇒ p.112)</li> </ul>	

## (4) Voltage range

## Query the Voltage Range and Auto-Range Setting

<b>Syntax</b>	Query	<b>:VOLTage?</b>
	Response	<Voltage range(NR1)>;<Auto-range ON/OFF>
<b>Description</b>	Query	Returns the voltage range as a numerical value in NR1 format and the auto-range as ON or OFF.
<b>Example</b>	Query	<b>:VOLT?</b>
	Response	<b>:VOLTAGE:RANGE 15;AUTO ON</b> (Headers: ON) <b>15;ON</b> (Headers: OFF)
		Voltage measurement is in auto-range mode in 15-V range.
<b>Note</b>	The :TRANsmit:SEParator command makes it possible to change the message unit separator from a semicolon (;) to a comma (,). (⇒ p.106)	

## Set and Query the Voltage Auto-Range Setting

<b>Syntax</b>	Command	<b>:VOLTage:AUTO &lt;ON/OFF&gt;</b>
	Query	<b>:VOLTage:AUTO?</b>
	Response	<ON/OFF> ON: measures voltage in the auto-range. OFF: ends voltage auto-range operation.
<b>Description</b>	Command	Enables and disables the voltage auto-range.
	Query	Returns the ON/OFF setting of the voltage auto-range setting as ON or OFF.
<b>Example</b>	Command	<b>:VOLT:AUTO ON</b> The voltage auto-range is set to ON.
	Query	<b>:VOLT:AUTO?</b>
	Response	<b>:VOLTAGE:AUTO ON</b> (Headers: ON) <b>ON</b> (Headers: OFF)
<b>Note</b>	Specifying a different range with the VOLTage:RANGe command disables auto-range operation.	



## Set and Query the Voltage Range Setting

**Syntax**

Command **:VOLTage:RANGe** <Voltage range (NR1)>  
 Query **:VOLTage:RANGe?**  
 Response <Voltage range (NR1)>  
 <Voltage range (NR1)> = 15/ 30/ 150/ 300

**Description**

Command Sets the voltage range. (The unit is volt (V))  
 The numerical value can be in NRf format, but any digits after the decimal point will be rounded.  
 The instrument uses <voltage range> to select the optimum range for measurement. However, it goes to the next higher range when measurements are 100% f.s. of the range.

Query Queries the voltage range setting.  
 Returns the voltage range as a numerical value in NR1 format.

**Example**

Command **:VOLT:RANG 15**  
 The 15-V range is set.

Query **:VOLT:RANG?**  
 Response **:VOLTAGE:RANGE 15** (Headers: ON)  
**15** (Headers: OFF)

- Note**
- Do not add a unit to the measurement range.
  - Wait until the internal circuit has stabilized after changing a range before reading measurements.
  - Setting a range disables auto-range.
  - A set negative value is processed as an absolute value.
  - A change in the range when average times is set to something other than 1, restarts averaging.
- See** Acquiring the averaged data (⇒ p.112)
- If a value other than <Voltage range (NR1)> is specified, the specified value is set to a range which can be measured. If, however, the range full scale value is exceeded, then the next higher range is set.

## (5) Current range

## Query the Current Range and Auto-Range Setting

<b>Syntax</b>	Query	<b>:CURRent?</b>
	Response	<Current range(NR2)>;<Auto-range ON/OFF>
<b>Description</b>	Query	Returns the current range as a numerical value in NR2 format and the auto-range as ON or OFF.
<b>Example</b>	Query	<b>:CURR?</b>
	Response	<b>:CURRENT:RANGE 0.1;AUTO ON</b> (Headers: ON) <b>0.1;ON</b> (Headers: OFF) Current measurement is in auto-range mode in 100-mA range.
<b>Note</b>	<ul style="list-style-type: none"> <li>The :TRANsmit:SEParator command makes it possible to change the message unit separator from a semicolon (;) to a comma (.). (⇒ p.106)</li> </ul>	

## Set and Query the Current Auto-Range Setting

<b>Syntax</b>	Command	<b>:CURRent:AUTO &lt;ON/OFF&gt;</b>
	Query	<b>:CURRent:AUTO?</b>
	Response	<ON/OFF> ON: measures current in the auto-range. OFF: ends current auto-range operation.
<b>Description</b>	Command	Enables and disables the current auto-range.
	Query	Returns the ON/OFF setting of the current auto-range setting as ON or OFF.
<b>Example</b>	Command	<b>:CURR:AUTO ON</b> The current auto-range is set to ON.
	Query	<b>:CURR:AUTO?</b>
	Response	<b>:CURRENT:AUTO ON</b> (Headers: ON) <b>ON</b> (Headers: OFF)
<b>Note</b>	Specifying a different range with the CURRent:RANGE command disables auto-range operation.	

## Set and Query the Current Range Setting

**Syntax**

Command    **:CURRENT:RANGE** <Current range (NR2)>  
 Query        **:CURRENT:RANGE?**  
 Response    <Current range (NR2)>  
               <Current range (NR2)> = 0.1/ 0.3/ 1.0/ 3.0/ 10.0/ 30.0

**Description**

Command    Sets the current range. (The unit is ampere (A))  
 The numerical value can be in NRf format, but rounding is performed for figures beyond the last valid decimal place. (Valid digits: 4 digits)  
 The instrument uses <current range> to select the optimum range for measurement. However, it goes to the next higher range when measurements are 100% f.s. of the range.

Query        Queries the current range setting.  
 Returns the current range as a numerical value in NR2 format.

**Example**

Command    **:CURR:RANG 0.1**  
 The 0.1-A range (100-mA range) is set.

Query        **:CURR:RANG?**

Response    **:CURRENT:RANGE 0.1** (Headers: ON)  
**0.1** (Headers: OFF)

- Note**
- Do not add a unit to the measurement range.
  - Wait until the internal circuit has stabilized after changing a range before reading measurements.
  - Setting a range disables auto-range.
  - A set negative value is processed as an absolute value.
  - A change in the range when average times is set to something other than 1, restarts averaging.
- See** Acquiring the averaged data (⇒ p.112)
- If a value other than <Current range (NR2)> is specified, the specified value is set to a range which can be measured. If, however, the range full scale value is exceeded, then the next higher range is set.

## (6) Analog output

## Set and Query Analog output item

<b>Syntax</b>	Command	<b>:AOUT</b> <output item>
	Query	<b>:AOUT?</b>
	Response	<output item> <output item> = VA/ PF/ PAH/ MAH/ AH/ PWH/ MWH/ WH VA : apparent power (also S) PF : power factor PAH : positive current integration (also PIH) MAH : negative current integration, (also MIH) AH : total current integration (also IH) PWH: positive power integration (also PWP or PINTEG) MWH: negative power integration, (also MWP or MINTEG) WH : total power integration (also WP or INTEG)
<b>Description</b>	Command	Sets the analog output item.
	Query	Returns the analog output item as character data.
<b>Example</b>	Command	<b>:AOUT VA</b> The analog output item is set to apparent power.
	Query	<b>:AOUT?</b>
	Response	<b>:AOUT VA</b> (Headers: ON) <b>VA</b> (Headers: OFF)

## (7) Integration

## Queries the integration time and the integration condition

<b>Syntax</b>	Query	<b>:INTEGRate?</b>
	Response	<0000 to 9999 (NR1)>,<00 to 59 (NR1)>;<integration condition>
<b>Description</b>	Query	Queries the integration time (hours, minutes) and the condition of the integration operation and returns them as a numerical value and character data.
<b>Example</b>	Query	<b>:INTEG?</b>
	Response	<b>:INTEGRATE:TIME 0100,00;STATE START</b> (Headers: ON) <b>0100,00;START</b> (Headers: OFF)
<b>Note</b>		The :TRANsmit:SEParator command makes it possible to change the message unit separator from a semicolon (;) to a comma (,). (⇒ p.106)

## Set and Query the integration condition

**Syntax** Command **:INTEGrate:STATE** <integration condition>  
 Query **:INTEGrate:STATE?**  
 Response <integration condition>  
 <integration condition> = START/ STOP/ RESET

**Description** Command Sets the condition of the integration operation.  
 Query Returns the condition of the integration operation as character data.

**Example** Command **:INTEG:STAT START**  
 The integration will start.  
 Query **:INTEG:STAT?**  
 Response **:INTEGRATE:STATE START** (Headers: ON)  
**START** (Headers: OFF)

- Note**
- Device dependent error/ according to the **INTEGRATOR** LED. (Refer to the table below)
  - Device dependent error/  
 When the integration time reached 10000 hours.  
 When the START command is executed with the integration value is  $\pm 999999M$ .

State of 3334 Command	INTEGRATOR LED off	Key input (command)	
		INTEGRATOR LED lights	INTEGRATOR LED flashes
START	●	–	●
STOP	–	●	–
RESET	●	–	●

- : The command is executed.  
 –: A device dependent error is generated.

## Set and Query the integration time

**Syntax** Command **:INTEGrate:TIME** <0 to 9999 (NR1)>,<0 to 59 (NR1)>  
 Query **:INTEGrate:TIME?**  
 Response <0000 to 9999 (NR1)>,<00 to 59 (NR1)>

**Description** Command Sets the integration time (hours, minutes) respectively. Setting limit is from 1 minute to 9999 hours 59 minutes (1 minute step). Specifying 0 hours, 0 minutes sets this setting to 10000 hours.  
 The numerical value can be in NRf format, but rounding is performed for figures beyond the last valid decimal place.  
 Query Returns the integration time (hours, minutes) as NR1 numerical data.

**Example** Command **:INTEG:TIME 100,20**  
 Sets the integration time to 100 hours, 20 minutes.  
 Query **:INTEG:TIME?**  
 Response **:INTEGRATE:TIME 0100,20** (Headers: ON)  
**0100,20** (Headers: OFF)

## (8) Display items

## Set and Query the Display Items

<b>Syntax</b>	Command	<b>:DISPlay</b> <Display a>,<Display b>,<Display c>,<Display d>
	Query	<b>:DISPlay?</b>
	Response	<Display a>,<Display b>,<Display c>,<Display d> <Display a> = V/ A/ W/ VA/ PF/ AH/ WH <Display b> =A/ W/ PWH/ MWH/ WH/ PAH/ MAH/ AH/ TIME <Display c> = W/ PF/ FREQ/ PWH/ MWH/ WH/ PAH/ MAH/ AH <Display d> = V/ A/ W/ VA/ PF/ VPK/ APK/ TIME V: voltage (also U), A: current (also I), W: active power (also P), VA: apparent power (also S), PF: power factor, AH: total current integration (also IH), WH: total power integration (also WP or INTEG), PWH: positive power integration (also PWP or PINTEG), PAH: positive current integration (also PIH), MAH: negative current integration (also MIH), MWH: negative power integration (also MWP or MINTEG), TIME: integration time, FREQ: frequency, VPK: voltage waveform peak (also UP), APK: current waveform peak (also IP)
<b>Description</b>	Command	Sets items in display areas a, b, c and d.
	Query	Returns the displayed parameters as character data.
<b>Example</b>	Command	<b>:DISP V,A,W,TIME</b> The voltage appears in display area a, current in display area b, active power in display area c and integration time in display area d.
	Query	<b>:DISP?</b>
	Response	<b>:DISPLAY V,A,W,TIME</b> (Headers: ON) <b>V,A,W,TIME</b> (Headers: OFF)

## (9) Header

## Enables/disables and queries headers for the response message

<b>Syntax</b>	Command	<b>:HEADer</b> <ON/ OFF>
	Query	<b>:HEADer?</b>
	Response	<ON/ OFF> ON: Headers are prefixed to response messages. OFF: No header is affixed to the response message.
<b>Description</b>	Command	Sets whether or not the instrument will prefix headers to its response messages. When the power is turned on, the data is initially set to ON.
	Query	Returns the setting of headers for the response messages as ON or OFF.
<b>Example</b>	Command	<b>:HEAD ON</b> Headers are prefixed to response messages.
	Query	<b>:HEAD?</b>
	Response	<b>:HEADER ON</b> (Headers: ON) <b>OFF</b> (Headers: OFF)

## (10)Hold

## Set and query display hold

<b>Syntax</b>	Command	<b>:HOLD</b> <ON/ OFF>
	Query	<b>:HOLD?</b>
	Response	<ON/ OFF> ON: holds displayed value (display hold state) OFF: cancels held display value.
<b>Description</b>	Command	Sets display hold (ON) and cancels (OFF) display hold.
	Query	Returns the setting of display hold as ON or OFF.
<b>Example</b>	Command	<b>:HOLD ON</b> Holds displayed values
	Query	<b>:HOLD?</b>
	Response	<b>:HOLD ON</b> (Headers: ON) <b>ON</b> (Headers: OFF) Displayed data is held.
	<b>Note</b>	Device dependent error/ During peak hold (HOLD LED flashes)

## Set and query peak hold

<b>Syntax</b>	Command	<b>:PEAKhold</b> <ON/ OFF/ RESET>
	Query	<b>:PEAKhold?</b>
	Response	<ON/ OFF> ON: displays peak hold value (peak hold state) OFF: displays instantaneous value.
<b>Description</b>	Command	Sets peak value hold (ON) and cancels (OFF) peak value. Clears the peak value and restarts (RESET)
	Query	Returns the setting of peak value hold as ON or OFF.
<b>Example</b>	Command	<b>:PEAK ON</b> Holds peak values
	Query	<b>:PEAK?</b>
	Response	<b>:PEAKHOLD ON</b> (Headers: ON) <b>ON</b> (Headers: OFF) Peak value is held.
	<b>Note</b>	<ul style="list-style-type: none"> <li>• Device dependent error/ During display hold (HOLD LED lights)</li> <li>• Peak hold is always enabled in the 3334. PEAKhold ON displays this internal data. To clear the peak hold value, execute PEAKhold RESET.</li> </ul>

4.6 Message Reference

(11)Measurement data

**Queries measured data**

**Syntax**      Query      **:MEASure?** <Measurement item 1>,...,<Measurement item 15>  
                   Response      (Up to 15 items)  
    <Measurement item 1> <Measurement value>;...;  
    <Measurement item 15> <Measurement value>  
    <Measurement item> = V/ A/ W/ VA/ PF/ FREQ/ PAH/ MAH/ AH/ PWH/ MWH/  
    WH/ VPK/ APK/ TIME  
    V: voltage (also U), A: current (also I), W: active power (also P),  
    VA: apparent power (also S), PF: power factor, FREQ: frequency,  
    PAH: positive current integration (also PIH),  
    MAH: negative current integration (also MIH),  
    AH: total current integration (also IH),  
    PWH: positive power integration (also PWP or PINTEG),  
    MWH: negative power integration (also MWP or MINTEG),  
    WH: total power integration (also WP or INTEG),  
    VPK: voltage waveform peak (also UP),  
    APK: current waveform peak (also IP),  
    TIME: integration time

Output format

Header portion	Data portion
V, A, W, VA, PF, FREQ, VPK, APK	Numerical data in NR3 format (10 fixed characters) 3-digit display data: ±00dddE±e (ddd: 4 numerical value items including decimal point, e: index 0, 3, 6) 4-digit display data: ±0ddddE±e (dddd: 5 numerical value items including decimal point, e: index 0, 3, 6) 5-digit display data: ±dxxxxE±e (xxxxx: 6 numerical value items including decimal point, e: index 0, 3, 6)
PAH, MAH, AH, PWH, MWH, WH	Numerical data in NR3 format (11 fixed characters) ±dxxxxxE±e (xxxxxx: 7 numerical value items including decimal point, e: index 0, 3, 6)
TIME	Numerical data in NR1 format (11 fixed characters) hhhhh, mm, ss (hours, minutes, seconds)

Error data

Error	Header	V, A, W, VA, PF, FREQ, VPK, APK	AH, PAH, MAH, PWH, MWH, WH
over-range		±999.99E+9	No syntax

**Description**      Query      Queries measurement values of measure items and returns them as character data or a numerical value.  
    Set character strings are used as a header. However, U, I, P, S ,etc. are replaced with V, A, W, VA ,etc.. The data is output in the order specified by the <measurement item>.



## Queries measured data

**Example** Query     :MEAS? V,A,W  
 Response  V +150.00E+0;A +020.00E+0;W +03.000E+3  
                   (Headers: ON)  
                   +150.00E+0;+020.00E+0;+03.000E+3 (Headers: OFF)

- Note**
- If measurement item is not specified, produces the measured value set by ":DATAout:ITEM" command. In this case, the output data sequence is V, A, W, VA, PF, VPK, APK, FREQ, PAH, MAH, AH, PWH, MWH, WH, TIME. (The OFF setting is not output.)  
 If all measurement items are set to OFF, the measured values of the displays a, b, c, and d are produced.
  - When this query ends in any error other than out-of-range, no response message is created for this query.
  - The :TRANsmit:SEParator command makes it possible to change the message unit separator from a semicolon (;) to a comma (.). (⇒ p.106)
  - An "o.r", or "-o.r" indication appears as "+999.99E+9" or "-999.99E+9".
  - When the display is blank such as when ranges are switched, a response message cannot be created until measurement data appears. Therefore it is recommended that a fixed range be used.
- See** "No response to the MEASure? command." (⇒ p.112)

### Set and query “:MEASure?” output items

<b>Syntax</b>	Command	<b>:DATAout:ITEM</b> <output item 1 (NR1)>, <output item 2 (NR1)>																																				
	Query	<b>:DATAout:ITEM?</b>																																				
	Response	<output item 1 (NR1)>,<output item 2 (NR1)>																																				
<b>Description</b>	Command	The “:MEASure?” output item is set to the numerical value 0 to 255. The numerical value can be in NRf format, but any digits after the decimal point will be rounded. If no parameters are specified to the :MEASure? command, the items specified here are used to supply the measurement values. If the bit which has no item is selected, no error occur.																																				
	Query	Returns the “:MEASure?” output item as an NR1 numerical value from 0 to 255.																																				
		<table border="1" style="width: 100%; text-align: center; border-collapse: collapse;"> <tr> <td></td> <td>128</td> <td>64</td> <td>32</td> <td>16</td> <td>8</td> <td>4</td> <td>2</td> <td>1</td> </tr> <tr> <td></td> <td>bit 7</td> <td>bit 6</td> <td>bit 5</td> <td>bit 4</td> <td>bit 3</td> <td>bit 2</td> <td>bit 1</td> <td>bit 0</td> </tr> <tr> <td><b>output item 1</b></td> <td>FREQ</td> <td>APK</td> <td>PF</td> <td>unused</td> <td>VA</td> <td>W</td> <td>A</td> <td>V</td> </tr> <tr> <td><b>output item 2</b></td> <td>VPK</td> <td>MAH</td> <td>PAH</td> <td>AH</td> <td>TIME</td> <td>MWH</td> <td>PWH</td> <td>WH</td> </tr> </table> <p>V: voltage, A: current, W: active power, VA: apparent power, PF: power factor, FREQ: frequency, WH: total power integration, PWH: positive power integration, MWH: negative power integration, TIME: integration time, AH: total current integration, PAH: positive current integration, MAH: negative current integration, VPK: voltage waveform peak, APK: current waveform peak</p>		128	64	32	16	8	4	2	1		bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0	<b>output item 1</b>	FREQ	APK	PF	unused	VA	W	A	V	<b>output item 2</b>	VPK	MAH	PAH	AH	TIME	MWH	PWH	WH
	128	64	32	16	8	4	2	1																														
	bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0																														
<b>output item 1</b>	FREQ	APK	PF	unused	VA	W	A	V																														
<b>output item 2</b>	VPK	MAH	PAH	AH	TIME	MWH	PWH	WH																														
<b>Example</b>	Command	<b>:DATA:ITEM 255,128</b> Set V, A, W, VA, PF, VPK, APK and FREQ for “:MEASure?” output items.																																				
	Query	<b>:DATA:ITEM?</b>																																				
	Response	<b>:DATAOUT:ITEM 255,128</b> (Headers: ON) <b>255,128</b> (Headers: OFF)																																				

- Note**
- If all measurement items are set to OFF, the measured values of the displays a, b, c, and d are produced.
  - Unused bits are ignored.

## (12)RS-232C

## Query RS-232C

RS-232C

**Syntax**

Query	<b>:RS232c?</b>
Response	<b>:RS232C:HANDSHAKE &lt;HARD/OFF&gt;;ANSWER &lt;ON/ OFF&gt; &lt;HARD/OFF&gt; ;&lt;ON/ OFF&gt; &lt;HARD/OFF&gt; HARD: hardware handshake OFF: no hardware handshake &lt;ON/ OFF&gt; ON: outputs a confirmation message. OFF: does not output a confirmation message.</b>

**Description**

Query	Returns current RS-232C communication handshake setting and confirmation message setting as character data.
-------	---

**Example**

Query	<b>:RS232?</b>
Response	<b>:RS232C:HANDSHAKE OFF;ANSWER OFF (Headers: ON) OFF;OFF (Headers: OFF)</b>


- Note**
- This query runs also in the event of a system error.
  - The :TRANsmit:SEParator command makes it possible to change the message unit separator from a semicolon (;) to a comma (.). (⇒ p.106)
  - Queries are available also in GP-IB.

## Sets and queries a confirmation message

RS-232C

<b>Syntax</b>	Command	<b>:RS232c:ANSWer</b> <ON/ OFF>	
	Query	<b>:RS232c:ANSWer?</b>	
	Response	<ON/ OFF>	ON: outputs a confirmation message(⇒ p.62) OFF: does not output a confirmation message.
<b>Description</b>	Command	Determines whether or not a confirmation message is to be output. This command runs also in the event of a system error.	
	Query	Returns ON or OFF to a confirmation message setting.	
<b>Example</b>	Command	<b>PRINT #1,":RS232:ANSW ON"</b>	[Result] (comment)
		<b>INPUT #1,A\$</b>	
		<b>PRINT A\$</b>	000(OK)
		<b>PRINT #1,"CUR:RANG 10.0"</b>	
		<b>INPUT #1,A\$</b>	
		<b>PRINT A\$</b>	001("CUR:RANG" is an error)
	<b>PRINT #1,"CURR:RANG?"</b>		
	<b>INPUT #1,A\$</b>		
	<b>PRINT A\$</b>	<b>:CURRENT:RANGE</b>	
		<b>30.0;000</b>	
			↑(Query data is OK) Confirmation messages
<b>Note</b>	<ul style="list-style-type: none"> <li>• These command and query run also in the event of a system error.</li> <li>• When set to ON, operation may become unstable if the message is not received.</li> <li>• This command is used for synchronizing with the controller in RS-232C, but can be used also in GP-IB. However, be sure to import this message.</li> </ul>		

## Queries RS-232C communication error data



**Syntax** Query **:RS232c:ERRor?**  
 Response <Communication error data (NR1)>  
 <Communication error data (NR1)> = 0 to 6


**Description** Query Returns RS-232C communication error data as NR1 numerical data and clears the contents.  
 The \*CLS command sets the communication error data to 0.  
 A header is not added to the response message.  
 Bit 2: overrun error (data loss)  
 Bit 1: framing error (incorrect data read)

128 bit 7	64 bit 6	32 bit 5	16 bit 4	8 bit 3	4 bit 2	2 bit 1	1 bit 0
unused	unused	unused	unused	unused	Overrun	Framing	unused

**Example** Query **:RS232:ERR?**  
 Response **4**  
 An overrun error has occurred.

- Note**
- This query runs also in the event of a system error.
  - Queries are available also in GP-IB.

## Set and query RS-232C communication handshake



**Syntax** Command **:RS232c:HANDshake <HARD/ OFF>**  
 Query **:RS232c:HANDshake?**  
 Response <HARD/ OFF>  
 HARD: hardware handshake (using RTS/CTS)  
 OFF: no hardware handshake

**Description** Command Sets a communication handshake  
 This command runs also in the event of a system error.  
 When HARD is set, the screen stops when the content of the input buffer exceeds 375 bytes. The screen is restored when input buffer content goes below 125 bytes. In the 3334, processing of commands reduces buffer space. However, communications are not restored until buffer content goes below 125 bytes. The **SHIFT(LOCAL)** key allows the user to reset the handshake to resolve situations like this.  
 To prevent communications from stopping, command length should be less than 125 bytes and never exceed 375 bytes.

Query Returns the contents of a communication handshake as character data.

**Example** Command **:RS232:HAND HARD**  
 Sets a hardware handshake (HARD).  
 Query **:RS232:HAND?**  
 Response **:RS232C:HANDSHAKE HARD** (Headers: ON)  
**HARD** (Headers: OFF)

- Note**
- These command and query run also in the event of a system error.
  - Setup and queries are available also in GP-IB.

## (13)VT and CT ratio

## Queries VT (PT) and CT ratio

<b>Syntax</b>	Query	<b>:SCALE?</b>
	Response	<VT ratio (NR1)>;<CT ratio (NR1)> <VT ratio (NR1)> = 1/ 2/ 4/ 10/ 20/ 30/ 60/ 100 <CT ratio (NR1)> = 1/ 2/ 3/ 4/ 5/ 6/ 8/ 10/ 12/ 15/ 16/ 20/ 24/ 25/ 30/ 40/ 50/ 60/ 75/ 80/ 100/ 200/ 300/ 500/ 1000/ 2000/ 3000/ 5000/ 10000
<b>Description</b>	Query	Returns current VT and CT ratios as NR1 numerical data.
<b>Example</b>	Query	<b>:SCAL?</b>
	Response	<b>:SCALE:VT 2;CT 3</b> 2 is set as the VT (PT) ratio and 3 is set as the CT ratio.
<b>Note</b>		<ul style="list-style-type: none"> <li>The :TRANsmit:SEParator command makes it possible to change the message unit separator from a semicolon (;) to a comma (,). (⇒ p.106)</li> </ul>

## Set and query VT (PT) ratio

<b>Syntax</b>	Command	<b>:SCALE:VT</b> <VT ratio (NR1)> (also :SCALE:PT?)
	Query	<b>:SCALE:VT ?</b> (also :SCALE:PT?)
	Response	<VT ratio (NR1)> <VT ratio (NR1)> = 1/ 2/ 4/ 10/ 20/ 30/ 60/ 100
<b>Description</b>	Command	Sets a VT (PT) ratio The numerical value can be in NRf format, but any digits after the decimal point will be rounded.
	Query	Returns the VT (PT) ratio setting as an NR1 value.
<b>Example</b>	Command	<b>:SCAL:VT 10</b> Sets a VT (PT) ratio of 10.
	Query	<b>:SCAL:VT?</b>
	Response	<b>:SCALE:VT 10</b> (Headers: ON) <b>10</b> (Headers: OFF)
<b>Note</b>		A change in VT ratio when average times is set to something other than 1, restarts averaging. <b>See</b> Acquiring the averaged data (⇒ p.112)

## Set and query CT ratio

**Syntax**

Command    **:SCALE:CT** <CT ratio (NR1)>

Query        **:SCALE:CT?**

Response    <CT ratio (NR1)>

              <CT ratio (NR1)> = 1/ 2/ 3/ 4/ 5/ 6/ 8/ 10/ 12/ 15/ 16/ 20/ 24/ 25/ 30/ 40/ 50/  
60/ 75/ 80/ 100/ 200/ 300/ 500/ 1000/ 2000/ 3000/ 5000/  
10000

**Description**

Command    Sets a CT ratio.  
The numerical value can be in NRf format, but any digits after the decimal point will be rounded.

Query        Returns the CT ratio setting as an NR1 value.

**Example**

Command    **:SCAL:CT 2**  
Sets a CT ratio of 2.

Query        **:SCALE:CT?**

Response    **:SCALE:CT 2** (Headers: ON)  
**2** (Headers: OFF)

**Note**        A change in CT ratio when average times is set to something other than 1, restarts averaging.  
[See](#) Acquiring the averaged data (⇒ p.112)

## (14)Message

## Set and query a message unit separator

<b>Syntax</b>	Command	<b>:TRANsmit:SEParator</b> <0/ 1>	
	Query	<b>:TRANsmit:SEParator?</b>	
	Response	<0/ 1>	
		When header is set to OFF, the following message unit separator is set. 0: semicolon ";" 1: comma ","	
<b>Description</b>	Command	Sets the message unit separator for the response message. The numerical value can be in NRf format, but any digits after the decimal point will be rounded. This command runs also in the event of a system error.	
	Query	Returns the message unit separator for the response message as 0 or 1.	
<b>Example</b>	Command	<b>:TRAN:SEP 0;:HEAD OFF;:MEAS? V,A</b> (specify ;)	
	Response	+0101.2E+0 ; +02.120E+0 (; is produced)	
	Command	<b>:TRAN:SEP 1;:HEAD OFF;:MEAS? V,A</b> (specify ,)	
	Response	+0101.2E+0 , +02.120E+0 (, is produced)	
	Command	<b>:TRAN:SEP 0;:HEAD ON;:MEAS? V,A</b> (specify ;)	
	Response	V +0101.2E+0 ; A +02.120E+0 (; is produced)	
	Command	<b>:TRAN:SEP 1;:HEAD ON;:MEAS? V,A</b> (specify ,)	
	Response	V +0101.2E+0 ; A +02.120E+0 (, is not produced)	
			When header is set to ON, a comma "," message unit separator setting is converted to a semicolon ";".
		Query	<b>:TRAN:SEP?</b>
	Response	<b>:TRANSMIT:SEPARATOR 1</b> (Headers: ON) <b>1</b> (Headers: OFF)	
<b>Note</b>	Be sure to turn the header off when changing a message unit separator. (:HEAD OFF)		



## Set and query the response message terminator

**Syntax** Command **:TRANsmit:TERMinator** <0/ 1>  
 Query **:TRANsmit:TERMinator?**  
 Response <0/ 1>

A terminator has the following format

	RS-232C	GP-IB
0:	LF	EOI with LF
1:	CR+LF	CR+EOI with LF

**Description** Command Sets a response message terminator. The numerical value can be in NRf format, but any digits after the decimal point will be rounded.

Query Returns the response message terminator setting as 0 or 1.

**Example** Command **:TRAN:TERM 0**  
 Sets the terminator to EOI with LF.

Query **:TRAN:TERM?**  
 Response **:TRANSMIT:TERMINATOR 1** (Headers: ON)  
**1** (Headers: OFF)

**Note** This command runs also in the event of a system error. (However, the query is not run.)

### 4.6.3 Valid Command According to Condition (Standard Command)

Cont: Continue  
 ●: can be executed / -: cannot be executed

Condition \ Command	Integration reset		Integration START		Integration STOP		System error
	Cont	HOLD	Cont	HOLD	Cont	HOLD	
*CLS	●	●	●	●	●	●	●
*ESE	●	●	●	●	●	●	-
*ESE?	●	●	●	●	●	●	-
*ESR?	●	●	●	●	●	●	●
*IDN?	●	●	●	●	●	●	-
*OPC	●	●	●	●	●	●	-
*OPC?	●	●	●	●	●	●	-
*RST	●	●	●	●	●	●	●
*SRE	●	●	●	●	●	●	-
*SRE?	●	●	●	●	●	●	-
*STB?	●	●	●	●	●	●	●
*TRG	-	●	-	●	-	●	-
*TST?	●	-	-	-	●	-	●
*WAI	●	●	●	●	●	●	-

#### Explanations for conditions

- Integration reset : Integration is stopped and integration time and value is reset (INTEGRATOR LED off)
- Integration START : Integration is in progress (INTEGRATOR LED lights)
- Integration STOP : Integration is stopped (INTEGRATOR LED flashes)
- Continue : Display is being updated at the sampling (continuous display)
- HOLD : Display is on hold (HOLD LED lights or flashes)
- System error : Err.1 to 4 are displayed

## 4.6.4 Valid Commands According to Condition (Specific Command)

Cont: Continue / ●: can be executed / -: cannot be executed

Command \ Condition	Integration reset		Integration START		Integration STOP		System error
	Cont	HOLD	Cont	HOLD	Cont	HOLD	
AOUT	●	●	●	●	●	●	-
AOUT?	●	●	●	●	●	●	-
AVERaging	●	-	●	-	●	-	-
AVERaging?	●	●	●	●	●	●	-
CURRent?	●	●	●	●	●	●	-
CURRent							
:AUTO	●	-	-	-	-	-	-
:AUTO?	●	●	●	●	●	●	-
:RANGe	●	-	-	-	-	-	-
:RANGe?	●	●	●	●	●	●	-
DATAout							
:ITEM	●	●	-	-	●	●	-
:ITEM?	●	●	●	●	●	●	-
DISPlay	●	●	●	●	●	●	-
DISPlay?	●	●	●	●	●	●	-
ESE0	●	●	●	●	●	●	-
ESE0?	●	●	●	●	●	●	-
ESE1	●	●	●	●	●	●	-
ESE1?	●	●	●	●	●	●	-
ESE2	●	●	●	●	●	●	-
ESE2?	●	●	●	●	●	●	-
ESR0?	●	●	●	●	●	●	-
ESR1?	●	●	●	●	●	●	-
ESR2?	●	●	●	●	●	●	-
HEADer	●	●	●	●	●	●	-
HEADer?	●	●	●	●	●	●	-
HOLD *1	●	●	●	●	●	●	-
HOLD?	●	●	●	●	●	●	-

\*1: During peak value hold, the command is invalid.

Cont: Continue / ●: can be executed / –: cannot be executed

Command \ Condition	Integration reset		Integration START		Integration STOP		System error
	Cont	HOLD	Cont	HOLD	Cont	HOLD	
INTEGrate?	●	●	●	●	●	●	–
INTEGrate							
:STATe							
START	●	●	–	–	●	●	–
STOP	–	–	●	●	–	–	–
RESET	●	●	–	–	●	●	–
:STATe?	●	●	●	●	●	●	–
:TIME	●	–	–	–	–	–	–
:TIME?	●	●	●	●	●	●	–
MEASure?	●	●	●	●	●	●	–
PEAKhold	●	●*2	●	●*2	●	●*2	–
PEAKhold?	●	●	●	●	●	●	–
RECTifier	●	–	–	–	–	–	–
RECTifier?	●	●	●	●	●	●	–
RS232c? *3	●	●	●	●	●	●	●
RS232c							
:ANSWer *3	●	●	●	●	●	●	●
:ANSWer? *3	●	●	●	●	●	●	●
:ERRor? *3	●	●	●	●	●	●	●
:HANDshake *3	●	●	●	●	●	●	●
:HANDshake? *3	●	●	●	●	●	●	●
SCALE?	●	●	●	●	●	●	–
SCALE							
:CT	●	–	–	–	–	–	–
:CT?	●	●	●	●	●	●	–
:VT	●	–	–	–	–	–	–
:VT?	●	●	●	●	●	●	–
TRANsmit							
:SEParator	●	●	●	●	●	●	●
:SEParator?	●	●	●	●	●	●	–
:TERMinator	●	●	●	●	●	●	●
:TERMinator?	●	●	●	●	●	●	–
VOLTage?	●	●	●	●	●	●	–
VOLTage							
:AUTO	●	–	–	–	–	–	–
:AUTO?	●	●	●	●	●	●	–
:RANGe	●	–	–	–	–	–	–
:RANGe?	●	●	●	●	●	●	–

\*2: During display hold, the command is invalid.

\*3: Command for RS-232C.

## 4.7 Troubleshooting (Communications)

When the 3334 is malfunctioning, attempt checking and troubleshooting according to the instructions shown below.

The causes/treatments without marks ( **GP-IB** / **RS-232C** ) are common to both the RS-232C and GP-IB.

Symptom	Cause / Treatment
The RS-232C/ GP-IB has stopped working completely.	<ul style="list-style-type: none"> <li>• Are the cables properly connected?(⇒ p.58)</li> <li>• Are all the devices powered on?</li> <li>• Are correct cables used? (⇒p.58 to 60)</li> <li>• Has the communication condition been correctly set? <b>RS-232C</b> (⇒ p.59)</li> <li>• Is the device address for the instrument set correctly? <b>GP-IB</b> (⇒ p.60)</li> <li>• Does some other device have the same device address? <b>GP-IB</b></li> </ul>
Communication failure with RS-232C/GP-IB.	<ul style="list-style-type: none"> <li>• Do the instrument and controller have the same settings (baud rate, data length, parity, and stop bit)? <b>RS-232C</b> (⇒ p.59)</li> <li>• Ensure the message terminators (delimiters) for the controller are same as the instrument. <b>GP-IB</b></li> </ul> <p><b>See</b> "Message Terminators" (⇒ p.64)</p>
After transmission on the RS-232C/ GP-IB bus, the keys on the instrument freeze up and have no effect.	<ul style="list-style-type: none"> <li>• Press the <b>SHIFT(LOCAL)</b> key on the front panel of the instrument to release the remote state.(⇒ p.61)</li> <li>• Has a LLO (Local Lock-Out) command been transmitted? Transmit a GTL command to put the instrument into the local state. <b>GP-IB</b></li> </ul>
When attempting to read data using a BASIC INPUT statement, the RS-232C bus hangs. <b>RS-232C</b>	<ul style="list-style-type: none"> <li>• Be sure to transmit one query before each INPUT statement.</li> <li>• Have any of these transmitted queries resulted in an error?</li> </ul>
When attempting to read data using a HP-Basic ENTER statement, the GP-IB bus hangs. <b>GP-IB</b>	<ul style="list-style-type: none"> <li>• Be sure to transmit one query before each ENTER statement.</li> <li>• Have any of these transmitted queries resulted in an error?</li> </ul>
Although a command has been transmitted, nothing has happened.	<ul style="list-style-type: none"> <li>• Using the <b>*ESR?</b> query, inspect the standard event status register, and check what type of error has occurred.⇒Check error content. (⇒ p.85)</li> <li>• Using the <b>RS232c:ERROR?</b> query, and check whether transmission error occurred on the RS-232C. <b>RS-232C</b> (⇒ p.103)</li> <li>• Set the <b>RS232c:ANSWER</b> to ON and check execution. <b>RS-232C</b> (⇒ p.102)</li> </ul>
Sending several queries, produces only one response.	<ul style="list-style-type: none"> <li>• Has an error occurred?</li> <li>• Send the queries one at a time, and read the responses individually. When you want to read them in all at once, try doing so by putting them all on one line separated by the message separator character.</li> <li>• Have you used the <b>*IDN?</b> query? The query command is not executed after <b>*IDN?</b>.</li> </ul>
The response message to a query differs from the display on the front panel.	<ul style="list-style-type: none"> <li>• Due to the response message being produced at the instant that the instrument receives the query, there is a possibility that it may not agree with the display at the instant that the controller reads it in.</li> </ul>

#### 4.7 Troubleshooting (Communications)

Symptom	Cause / Treatment
Sometimes service requests are not generated. <b>GP-1B</b>	<ul style="list-style-type: none"> <li>Have the service request enable register and the various event status enable registers been correctly set? (⇒p.85 to 88)</li> <li>Clear all the event registers at the end of SRQ processing subroutines by using the <b>*CLS</b> command. If an event bit is not cleared, no service request will be generated for that event.(⇒ p.84)</li> </ul>
Averaged data cannot be acquired.	<p>A change in current range, average times, VT ratio and CT ratio restarts averaging process and indicates the instantaneous value measured when starting. To obtain an average value, wait for the first average process to end (See "Interval between display updates" (⇒ p.31) or monitor the ESR0? AVG flag described below.</p> <ol style="list-style-type: none"> <li>Clear the event flag and wait for the first indication to appear after a change in range : CURR:RANG 1, *WAI; *CLS (example: when changing to the 1-mA range) To change to VT ratio range, change the :CURR:RANG command to the SCAL:VT command; to change to CT ratio, change to the SCAL:CT command; to change to average times, change to the AVER command.</li> <li>Check that the AVG flag becomes 1 Use :ESR0? to read 0 into the event status register Repeat until the AVG flag (bit 3) becomes 1</li> <li>Import data when the AVG flag becomes 1 :MEAS?</li> </ol>
No response to the MEASure? command.	<p>The MEASure? command does not generate a response message until display data is created when a flag is displayed to notify a change in range. In the 3334, a flag is displayed during a 0.6 s interval after a change in range and no response message is returned in this interval. In auto range operation, when ranges change irregularly and changes often involve multiple ranges, no response message may be returned during these changes. To prevent this, use a fixed range or monitor the ESR0? DS flag (bit 7) and obtain the data when the DS flag becomes 1.</p> <p>Example:</p> <ol style="list-style-type: none"> <li>Clear the *CLS event register</li> <li>Use :ESR0? to read 0 into the event status register Repeat until the DS flag (bit 7) becomes 1</li> <li>Import data when the DS flag becomes 1 :MEAS?</li> </ol>

## 4.8 Device Compliance Statement



Information on compliance to standards" based on the IEEE 488.2 standard

### (1) IEEE 488.1 interface functions

See "The GP-IB interface" (⇒ p.57)

### (2) Operation with a device address other than 0 through 30

A setting outside the 0 to 30 range cannot be made.

### (3) Timing of changed device address recognition

A change of address is recognized immediately after changing.

### (4) Device settings at power on

The status information is cleared, and all other items are preserved. However, the header on/off setting, and response message separator and terminator are all reinitialized.

### (5) List of message exchange options

- Input buffer capacity and operation  
See "Input Buffer" (⇒ p.66)
- Queries to which multiple response message units are returned
 

<b>:VOLTagE?</b>	.....	2
<b>:CURRent?</b>	.....	2
<b>:INTEGrate?</b>	.....	2
<b>:MEASure?</b>	.....	1 to 15
<b>:SCALE?</b>	.....	2
<b>:RS232c?</b>	.....	2
- Queries producing responses as syntax checking is performed:  
All queries produce responses when syntax checking is performed.
- Whether any queries produce responses when read:  
There are no queries which produce response messages at the instant they are read in by the controller.
- Whether any commands are coupled:  
There are no relevant commands.

**(6) Summary of functional elements for use when constructing device specific commands, and whether compound commands or program headers can be used:**

The followings can be used

- Program message
- Program message terminator
- Program message unit
- Program message unit separator
- Command message unit
- Query message unit
- Command program header
- Query program header
- Program data
- Character program data
- Decimal program data
- Compound commands and program headers

**(7) Buffer capacity limitations for block data**

Block data is not used.

**(8) Summary of program data elements used in expressions, and deepest nesting level allowable in sub-expressions, including syntax restrictions imposed by the device.**

Sub-expressions are not used. Character data and decimal data are the only program data elements used.

(excluding **\*IDN?**)

**(9) Response syntax for queries**

See "4.6 Message Reference"(⇒ p.81)

**(10) Transmission congestion relating to device-to-device messages which do not conform to the general principles for basic response messages**

There are no device to device messages.

**(11) Response capacity for block data**

Block data does not appear in responses.

**(12) Summary of standard commands and queries used**

See "4.5 Message List"(⇒ p.76)

**(13) Device state after a calibration query has been completed without any problem**

The "**\*CAL?**" query is not used.

**(14) Existence/nonexistence of "**\*DDT**" command**

The "**\*DDT**" command is not used.

---



**(15) Existence/nonexistence of macro command**

Macros are not used.

**(16) For queries related to identification, explanation of the response to the "\*IDN?" query**

See "4.6.1 Standard Commands" (⇒ p.82)

**(17) Capacity of the user data storage area reserved for when the "\*PUD" command and the "\*PUD?" query are being executed**

The "\*PUD" command and the "\*PUD?" query are not used.

Further, there is no user data storage area.

**(18) Resources when the "\*RDT" command and the "\*RDT?" query are being used**

The "\*RDT" command and the "\*RDT?" query are not used.

Further, there is no user data storage area.

**(19) Conditions which are influenced when "\*RST", "\*LRN?", "\*RCL?", and "\*SAV" are used**

"\*LRN?", "\*RCL?", and "\*SAV" are not used. The "\*RST" command returns the unit to its initial state.

See "4.6.1 Standard Commands" (⇒ p.83)

"4.4.5 Initialization Items" (⇒ p.74)

**(20) Scope of the self-testing executed as a result of the "\*TST?" query**

See "4.6.1 Standard Commands" (⇒ p.82)

**(21) Additional organization of the status data used in a device status report**

See "4.4.4 Event Registers" (⇒ p.69)

**(22) Whether commands are overlap or sequential type**

All the commands are sequential commands.

**(23) Criterion relating to the functions required at the instant that the termination message is produced, as a response to each command**

Termination occurs when the command has been parsed.

The **:MEASure?** query will run only when there is no valid data available and run until valid data is created. The **\*TRG** command ends processing when the measurement data is ready.



# Specifications

# Chapter 5

## Accuracy

We define measurement tolerances in terms of f.s. (full scale), rdg. (reading) and dgt. (digit) values, with the following meanings:

- f.s. (maximum display value or scale length)  
The maximum displayable value or scale length. This is usually the name of the currently selected range.
- rdg. (reading or displayed value)  
The value currently being measured and indicated on the measuring instrument.
- dgt. (resolution)  
The smallest displayable unit on a digital measuring instrument, i.e., the input value that causes the digital display to show a "1" as the least-significant digit.

## 5.1 General Specifications

<b>Operating environment</b>	Indoors, up to 2000 m (6562-ft.) ASL, Pollution degree 2
<b>Operating temperature and humidity</b>	0 to 40°C (32 to 104°F) 80% RH or less (non-condensating)
<b>Storage temperature and humidity</b>	-10 to 50°C (14 to 122°F) 80% RH or less (non-condensating)
<b>Dielectric strength (50/60 Hz, for 15 seconds)</b>	<ul style="list-style-type: none"> <li>• 4.290 kVrms (Current sensitivity: 5 mA) Between voltage and current input terminals and the case, interface and output terminals Between voltage and current input terminals and the power supply</li> <li>• 2.570 kVrms (Current sensitivity: 1 mA) Between voltage input terminal and current input terminal</li> <li>• 1.690 kVrms (Current sensitivity: 10 mA) Between power supply and the case, interface and output terminals</li> </ul>
<b>Rated supply voltage</b>	100 to 240 V AC (Voltage fluctuations of $\pm 10\%$ from the rated supply voltage are taken into account.) Anticipated transient overvoltage 2500 V
<b>Rated supply frequency</b>	50/60 Hz
<b>Maximum rated power</b>	20 VA
<b>Dimensions</b>	Approx. 210W x 100H x 245D mm (8.27"W x 3.94"H x 9.65"D) (not including protrusions)
<b>Mass</b>	Approx. 2.5 kg (88.2 oz.)
<b>Applicable Standards</b>	Safety EN61010 EMC EN61326 Class A EN61000-3-2 EN61000-3-3
<b>Accessories</b>	<ul style="list-style-type: none"> <li>• Instruction Manual ..... 1</li> <li>• Power Cord ..... 1</li> </ul>
<b>Options</b>	<ul style="list-style-type: none"> <li>• Model 9637 RS-232C Cable (1.8 m, 9-pin to 9-pin, Cross cable)</li> <li>• Model 9638 RS-232C Cable (1.8 m, 9-pin to 25-pin, Cross cable)</li> <li>• Model 9151-02 GP-IB Connector Cable (2 m)</li> <li>• Model 9151-04 GP-IB Connector Cable (4 m)</li> </ul> <p><b>Others</b></p> <ul style="list-style-type: none"> <li>• A number 3 Phillips screwdriver</li> </ul>
<b>Product warranty period</b>	3 years

## 5.2 Basic Specifications

<b>Measurement line type</b>	Single-phase 2-wire (AC, DC)
<b>Input methods</b>	Voltage Isolation input, resistance potential division method Current Isolation input, shunt input method
<b>Measurement method</b>	Simultaneous digital sampling of voltage and current Sampling frequency : Approx. 74.4 kHz A/D converter resolution : 16 bits
<b>Rectifier type</b>	True RMS indication : AC + DC measurement (RECTIFIER AC + DC) AC measurement (RECTIFIER AC) Simple average indication : DC measurement (RECTIFIER DC)
<b>Input resistance (50/60 Hz)</b>	Voltage 2.4 MΩ ±0.12 MΩ Current 10 mΩ or less
<b>Maximum rated voltage to earth</b>	300 V (50/60 Hz) Measurement category III (anticipated transient overvoltage 4000 V)
<b>Maximum input voltage</b>	300 V, ±425 V <sub>peak</sub>
<b>Maximum input current</b>	30 A, ±54.0 A <sub>peak</sub>
<b>Measurement items</b>	Voltage, current, active power, apparent power, power factor, frequency, current integration, active power integration, voltage waveform peak, current input waveform peak
<b>Display</b>	LED Display
<b>No. of displayed items</b>	Four items
<b>Screen update rate</b>	200 ms±50 ms (approx. 5 times/s) to 20s (varies with average times setting)

### Range configuration

Voltage \ Current	15 V	30 V	150 V	300 V
100 mA	1.5 W	3 W	15 W	30 W
300 mA	4.5 W	9 W	45 W	90 W
1 A	15 W	30 W	150 W	300 W
3 A	45 W	90 W	450 W	900 W
10 A	150 W	300 W	1.5 kW	3 kW
30 A	450 W	900 W	4.5 kW	9 kW

Note 1: Substitute VA for the W units in the table above for information on apparent power.

Note 2: Auto-range

- Up : Automatically changes to the next higher range when inputs exceed 100% of range or a peak over occurs
- Down : Goes to a lower range when input is less than 25% (less than 15% from 150-V range) of current range  
A change to a lower range is not made when a peak over occurs in the lower range.

**Period of guaranteed accuracy** 3 years (However, accuracy figures after 1 year and 3 years differ)

**Measurement accuracy (1 year)** When input is less than 50% of range

Frequency (f)	Voltage, Current, Active power
DC	$\pm 0.1\% \text{rdg.} \pm 0.2\% \text{f.s.}$
45 Hz $\leq$ f $\leq$ 66 Hz	$\pm 0.1\% \text{rdg.} \pm 0.1\% \text{f.s.}$
66 Hz $<$ f $\leq$ 1 kHz	$\pm 0.1\% \text{rdg.} \pm 0.2\% \text{f.s.}$
1 kHz $<$ f $\leq$ 5 kHz	$\pm 3.0\% \text{f.s.}$

When input is 50 to 100% of range

Frequency (f)	Other than 30-A range Voltage, Current, Active power	30-A range Current, Active power	
		15 A $\leq$ Input $\leq$ 20 A	20 A $<$ Input $\leq$ 30 A
DC	$\pm 0.1\% \text{rdg.} \pm 0.2\% \text{f.s.}$	$\pm 0.1\% \text{rdg.} \pm 0.2\% \text{f.s.}$	$\pm 0.1\% \text{rdg.} \pm 0.2\% \text{f.s.}$
45 Hz $\leq$ f $\leq$ 66 Hz	$\pm 0.2\% \text{rdg.}$	$\pm 0.2\% \text{rdg.}$	$\pm 0.2\% \text{rdg.}$
66 Hz $<$ f $\leq$ 1 kHz	$\pm 0.3\% \text{rdg.}$	$\pm 0.3\% \text{rdg.}$	-----
1 kHz $<$ f $\leq$ 5 kHz	$\pm 3.0\% \text{rdg.}$	$\pm 3.0\% \text{rdg.}$	-----

Add  $\pm 50 \mu\text{A}$  for DC current measurement accuracy

Add  $(\pm 50 \mu\text{A}) \times (\text{voltage reading})$  for DC active power measurement accuracy

**Measurement accuracy (3 year)** When input is less than 50% of range

Frequency (f)	Voltage, Current, Active power
DC	$\pm 0.1\% \text{rdg.} \pm 0.35\% \text{f.s.}$
45 Hz $\leq$ f $\leq$ 66 Hz	$\pm 0.1\% \text{rdg.} \pm 0.2\% \text{f.s.}$
66 Hz $<$ f $\leq$ 1 kHz	$\pm 0.1\% \text{rdg.} \pm 0.35\% \text{f.s.}$
1 kHz $<$ f $\leq$ 5 kHz	$\pm 4.5\% \text{f.s.}$

When input is 50 to 100% of range

Frequency (f)	Other than 30-A range Voltage, Current, Active power	30-A range Current, Active power	
		15 A $\leq$ Input $\leq$ 20 A	20 A $<$ Input $\leq$ 30 A
DC	$\pm 0.1\% \text{rdg.} \pm 0.35\% \text{f.s.}$	$\pm 0.1\% \text{rdg.} \pm 0.35\% \text{f.s.}$	$\pm 0.1\% \text{rdg.} \pm 0.35\% \text{f.s.}$
45 Hz $\leq$ f $\leq$ 66 Hz	$\pm 0.3\% \text{rdg.}$	$\pm 0.3\% \text{rdg.}$	$\pm 0.3\% \text{rdg.}$
66 Hz $<$ f $\leq$ 1 kHz	$\pm 0.45\% \text{rdg.}$	$\pm 0.45\% \text{rdg.}$	-----
1 kHz $<$ f $\leq$ 5 kHz	$\pm 4.5\% \text{rdg.}$	$\pm 4.5\% \text{rdg.}$	-----

Add  $\pm 50 \mu\text{A}$  for DC current measurement accuracy

Add  $(\pm 50 \mu\text{A}) \times (\text{voltage reading})$  for DC active power measurement accuracy

**Conditions of Guaranteed Accuracy**

- Temperature and humidity for guaranteed accuracy: 23 $\pm$ 5°C, 80%RH or less
- Warm-up time: 3 minutes
- Input: Sine-wave input, Power factor = 1, Common mode voltage = 0 V

**Temperature characteristic**  $\pm 0.03\% \text{f.s.}/^\circ\text{C}$  or less

**Power factor influence**  $\pm 0.4\% \text{rdg.}$  or less (45 to 66 Hz, power factor = at 0.5)

**Maximum effective peak voltage**  $\pm 300\%$  of each voltage range, but the 150-V range and 300-V range have a peak of  $\pm 425$  V

**Maximum effective peak current**  $\pm 300\%$  of each current range, but the 30-A range has a peak of  $\pm 54.0$  A

**Effect of common mode voltage**  $\pm 0.1\% \text{f.s.}$  or less  
(300 V, 50/60 Hz, when applied between an input terminal and the case)

**Effect of external magnetic field**  $\pm 1.5\% \text{f.s.}$  or less (400 A/m DC, in a 50/60 Hz magnetic field)

## 5.2 Basic Specifications

### Effective measurement range

Voltage, Current : 1 to 100% of range  
 Active power : 0 to 100% of range

( ) : Display range

Voltage \ Current	15-V range 0.150 to 15.000 V (0.075 to 15.750 V)	30-V range 0.30 to 30.00 V (0.15 to 31.50 V)	150-V range 1.50 to 150.00 V (0.75 to 157.50 V)	300-V range 3.0 to 300.0 V (1.5 to 315.0 V)
<b>100-mA range</b> 1.00 to 100.00 mA (0.50 to 105.00 mA)	1.5-W range 0.0000 to 1.5000 W (0.0000 to 1.6538 W)	3-W range 0.000 to 3.000 W (0.000 to 3.308 W)	15-W range 0.000 to 15.000 W (0.000 to 16.538 W)	30-W range 0.00 to 30.00 W (0.00 to 33.08 W)
<b>300-mA range</b> 3.0 to 300.0 mA (1.5 to 315.0 mA)	4.5-W range 0.000 to 4.500 W (0.000 to 4.961 W)	9-W range 0.000 to 9.000 W (0.000 to 9.923 W)	45-W range 0.00 to 45.00 W (0.00 to 49.61 W)	90-W range 0.00 to 90.00 W (0.00 to 99.23 W)
<b>1-A range</b> 0.0100 to 1.0000 A (0.0050 to 1.0500 A)	15-W range 0.000 to 15.000 W (0.000 to 16.538 W)	30-W range 0.00 to 30.00 W (0.00 to 33.08 W)	150-W range 0.00 to 150.00 W (0.00 to 165.38 W)	300-W range 0.0 to 300.0 W (0.0 to 330.8 W)
<b>3-A range</b> 0.030 to 3.000 A (0.015 to 3.150 A)	45-W range 0.00 to 45.00 W (0.00 to 49.61 W)	90-W range 0.00 to 90.00 W (0.00 to 99.23 W)	450-W range 0.0 to 450.0 W (0.0 to 496.1 W)	900-W range 0.0 to 900.0 W (0.0 to 992.3 W)
<b>10-A range</b> 0.100 to 10.000 A (0.050 to 10.500 A)	150-W range 0.00 to 150.00 W (0.00 to 165.38 W)	300-W range 0.0 to 300.0 W (0.0 to 330.8 W)	1.5-kW range 0.0000 to 1.5000 kW (0.0000 to 1.6538 kW)	3-kW range 0.000 to 3.000 kW (0.000 to 3.308 kW)
<b>30-A range</b> 0.30 to 30.00 A (0.15 to 31.50 A)	450-W range 0.0 to 450.0 W (0.0 to 496.1 W)	900-W range 0.0 to 900.0 W (0.0 to 992.3 W)	4.5-kW range 0.000 to 4.500 kW (0.000 to 4.961 kW)	9-kW range 0.000 to 9.000 kW (0.000 to 9.923 kW)

- Note 1: The effective measurement range of active power is valid when voltage and current are within their effective measurement ranges
- Note 2: Other measurement items depend on the effective measurement ranges of voltage, current and active power
- Note 3: Values of voltage and current less than 0.5% of their ranges are suppressed (forced to display as zero)
- Note 4: Numerical values in the displayed range are subject to a  $\pm 1$  dgt. error due to calculation accuracy.
- Note 5: When the average times is set to a value other than 1 (OFF), voltage, current, active power, apparent power and power factor are indicated in 5 digits.  
(Example: In the 45-W range; 45.00 W  $\rightarrow$  45.000 W)

### Calculation method

Measurement item	Calculation method
Apparent power (S)	$S = U \times I$
Power factor ( $\lambda$ )	$\lambda =  P/S $
Current integration	$\frac{(\text{Total } I \text{ from start of integration})}{(\text{Number of values per hour})}$
Active power integration	$\frac{(\text{Total } P \text{ from start of integration})}{(\text{Number of values per hour})}$

- Note 1:  $U$ ,  $I$  and  $P$  indicate the measured values for voltage, current and active power, respectively. None of the values have been rounded (deviation  $\pm 1$  dgt.)
- Note 2: The accuracy of values calculated from measurement values is  $\pm 1$  dgt.
- Note 3: When  $|P| > S$ ,  $S$  values replace  $|P|$ . (Except when the RECTIFIER setting is DC)
- Note 4: Even when  $I$  and  $P$  values are "o.r.", integration is performed for measured values within the range for which "PEAK OVER U" and "PEAK OVER I" are not lit.

## 5.3 Functions

Note 1: Each numerical value in the specifications is subject to  $\pm 1$  dgt. error due to calculation accuracy.

Note 2: When the average times is set to a value other than 1 (OFF), voltage, current, active power, apparent power and power factor are indicated in 5 digits.

### Voltage measurement (Displays: V)

<b>Total display area</b>	$\pm 0.5\%$ to $\pm 105\%$ of range (less than 0.5% is processed as 0) VT ratio enables indication of up to $\pm 31.50$ kV
<b>Over-range indication</b>	"o.r." (over-range) is indicated for inputs that exceed $\pm 105\%$ of the input range
<b>Over-range warning</b>	The <b>PEAK OVER U</b> LED lights when the input peak voltage value exceeds $\pm 425$ V or exceeds $\pm 300\%$ of the input range.
<b>Threshold voltage for lamp lighting</b>	150-V, 300-V range: $\pm 425$ V to $\pm 433.5$ V Other ranges: $\pm 300\%$ to $\pm 302\%$ of range

### Current measurement (Displays: A)

<b>Total display area</b>	$\pm 0.5\%$ to $\pm 105\%$ of range (less than 0.5% is processed as 0) CT ratio enables indication of up to $\pm 315.0$ kA
<b>Over-range indication</b>	"o.r." is indicated for inputs that exceed $\pm 105\%$ of the input range
<b>Over-range warning</b>	The <b>PEAK OVER I</b> LED lights when the input peak current value exceeds $\pm 54.0$ A or exceeds $\pm 300\%$ of the input range.
<b>Threshold current for lamp lighting</b>	30-A range: $\pm 54.0$ A to $\pm 54.6$ A Other ranges: $\pm 300\%$ to $\pm 302\%$ of range

### Active power measurement (Displays: W)

<b>Total display area</b>	0% to $\pm 110.25\%$ of range The VT and CT ratios permit indication of up to $\pm 9923$ MW
<b>Over-range indication</b>	"o.r." is indicated for inputs that exceed $\pm 110.25\%$ of the input range

### Apparent power measurement (Display: VA)

<b>Total display area</b>	0% to $\pm 110.25\%$ of range The VT and CT ratios permit indication of up to $\pm 9923$ MVA
<b>Over-range indication</b>	"o.r." is indicated when the voltage or current input exceeds the range.
<b>Measurement accuracy</b>	$\pm 1$ dgt. for values calculated from measurement values

### Power factor measurement (Display: PF)

<b>Total display area</b>	0.000 to 1.000 (No polarity)
<b>Over-range indication</b>	"o.r." is indicated when the voltage or current input exceeds the range. "o.r." is indicated for 0 apparent power
<b>Measurement accuracy</b>	$\pm 1$ dgt. for values calculated from measurement values

### Frequency measurement (Display: Hz)

<b>Measurement method</b>	Reverse calculation from the input waveform cycle (reciprocal method)
<b>Measurement accuracy</b>	$\pm 0.1\%$ rdg. $\pm 1$ dgt. (0 to 40°C, sine-wave input)
<b>Effective measurement range</b>	10 to 100% of voltage, current range
<b>Total display area</b>	45.000 to 5.0000 kHz
<b>Over-range indication</b>	"o.r." is indicated when outside of the overall display area.

### 5.3 Functions

#### Peak voltage value measurement (Display: Vpk)

<b>Measurement method</b>	The peak voltage of the sampled instantaneous voltage value (both polarities) is measured														
<b>Range configuration</b>	<table border="1"> <tr> <td>Voltage range</td> <td>15 V</td> <td>30 V</td> <td>150 V</td> <td>300 V</td> </tr> <tr> <td>Voltage peak range</td> <td>45.0 V</td> <td>90.0 V</td> <td>450 V</td> <td>900 V</td> </tr> </table>					Voltage range	15 V	30 V	150 V	300 V	Voltage peak range	45.0 V	90.0 V	450 V	900 V
Voltage range	15 V	30 V	150 V	300 V											
Voltage peak range	45.0 V	90.0 V	450 V	900 V											
<b>Measurement accuracy</b>	For DC and 45 Hz to 1 kHz, $\pm 1.2\%$ f.s. (f.s. is that of the voltage peak range)														
<b>Effective measurement range</b>	$\pm 5$ to $\pm 100\%$ of voltage peak range (up to $\pm 425$ V)														
<b>Total display area</b>	$\pm 0.3$ to $\pm 102\%$ of voltage peak range (less than $\pm 0.3\%$ is processed as 0) Depending on the VT ratio setting, up to $\pm 91.8$ kVpk can be displayed.														
<b>Over-range indication</b>	"o.r" is indicated for inputs that exceed $\pm 102\%$ of voltage peak range														

#### Peak current value measurement (Display: Apk)

<b>Measurement method</b>	The peak current of the sampled instantaneous current value (both polarities) is measured																				
<b>Range configuration</b>	<table border="1"> <tr> <td>Current range</td> <td>100 mA</td> <td>300 mA</td> <td>1 A</td> <td>3 A</td> <td>10 A</td> <td>30 A</td> </tr> <tr> <td>Current peak range</td> <td>300 mA</td> <td>900 mA</td> <td>3.00 A</td> <td>9.00 A</td> <td>30.0 A</td> <td>90.0 A</td> </tr> </table>							Current range	100 mA	300 mA	1 A	3 A	10 A	30 A	Current peak range	300 mA	900 mA	3.00 A	9.00 A	30.0 A	90.0 A
Current range	100 mA	300 mA	1 A	3 A	10 A	30 A															
Current peak range	300 mA	900 mA	3.00 A	9.00 A	30.0 A	90.0 A															
<b>Measurement accuracy</b>	For DC and 45 Hz to 1 kHz, $\pm 1.2\%$ f.s. (f.s. is that of the current peak range)																				
<b>Effective measurement range</b>	$\pm 5$ to $\pm 100\%$ of current peak range (up to $\pm 54.0$ A)																				
<b>Total display area</b>	$\pm 0.3$ to $\pm 102\%$ of current peak range (less than $\pm 0.3\%$ is processed as 0) Depending on the CT ratio setting, up to $\pm 918$ kApk can be displayed.																				
<b>Over-range indication</b>	"o.r" is indicated for inputs that exceed $\pm 102\%$ of current peak range																				

#### Current integration (Integration time: TIME)

<b>Measurement method</b>	Total current integration value (Display: Ah), Positive current integration value (Display: Ah+), Negative current integration value (Display: Ah-) Six items integrated simultaneously (Ah, Ah+, Ah-, Wh, Wh+, Wh-)
<b>Measurement accuracy</b>	Integration value: measurement accuracy of current $\pm 1$ dgt. Integration time: $\pm 100$ ppm $\pm 1$ s (0 to 40°C)
<b>Effective measurement range</b>	Effective measurement range of current
<b>No. of displayed digits</b>	Six digits
<b>Integration time</b>	1 min to 10000 h (1 min step)
<b>Error alarm</b>	The unit (Ah, Ah+, Ah-) flashes when "PEAK OVER I" occurs during integration.
<b>Functions</b>	Stop integration by timer, Display elapsed integration time, Additive integration by repeated Start/Stop, Resume integration upon recovery from power outages, Integration value and elapsed integration time are backed up during power outages, INTEGRATOR LED lights when integration is in process, it flashes when integration is stopped, and it goes out when integration is in the reset state.



**Active power integration (Integration time: TIME)**

<b>Measurement method</b>	Total active power integration value (Display: Wh), Positive active power integration value (Display: Wh+), Negative active power integration value (Display: Wh-) Six items integrated simultaneously (Ah, Ah+, Ah-, Wh, Wh+, Wh-)
<b>Measurement accuracy</b>	Integration value: measurement accuracy of active power $\pm 1$ dgt. Integration time: $\pm 100$ ppm $\pm 1$ s (0 to 40°C)
<b>Effective measurement range</b>	Effective measurement range of active power
<b>No. of displayed digits</b>	Six digits
<b>Integration time</b>	1 min to 10000 h (1 min step)
<b>Error alarm</b>	The unit (Wh, Wh+, Wh-) flashes when "PEAK OVER U" or "PEAK OVER I" occurs during integration.
<b>Functions</b>	Stop integration by timer, Display elapsed integration time, Additive integration by repeated Start/Stop, Resume integration upon recovery from power outages, Integration value and elapsed integration time are backed up during power outages, INTEGRATOR LED lights when integration is in process, it flashes when integration is stopped, and it goes out when integration is in the reset state.

**Rectifier type changing**

<b>Rectifier type</b>	AC+DC :For AC + DC measurements (true RMS display of voltage and current) DC :For DC measurements (simple average display of voltage and current) AC :For AC measurements (true RMS display of voltage and current) (Calculated by: $\sqrt{(AC+DC \text{ Measured Value})^2 - (DC \text{ Measured Value})^2}$ )
-----------------------	--

**Average (the AVG LED goes on when average times is something other than 1)**

<b>System</b>	Simple average							
<b>Average times and display update rate interval</b>	Average times	1(OFF)	2	5	10	25	50	100
	Interval between display updates	200 ms	400 ms	1 s	2 s	5 s	10 s	20 s
<b>Number of digit indication for measurement value</b>	When the average times is set to a value other than 1 (OFF), voltage, current, active power, apparent power and power factor are indicated in 5 digits. (Example: In the 45-W range; 45.00 W $\rightarrow$ 45.000 W)							
<b>Error alarm</b>	The unit flashes when data used for calculating averages contain "o.r" data							

**VT/CT Ratio (the VT LED or CT LED lights when respective ratio is something other than 1)**

<b>VT ratio</b>	1(OFF), 2, 4, 10, 20, 30, 60, 100
<b>CT ratio</b>	1(OFF), 2, 3, 4, 5, 6, 8, 10, 12, 15, 16, 20, 24, 25, 30, 40, 50, 60, 75, 80, 100, 200, 300, 500, 1000, 2000, 3000, 5000, 10000

**Analog Output**

<b>Configuration</b>	12bit D/A converter, 4channels
<b>Output items</b>	<i>U</i> : Voltage, <i>I</i> : Current, <i>P</i> : Active power D/A: Select an item from current integration, active power integration, apparent power, power factor
<b>Output accuracy</b>	(Measurement accuracy for each output) + ( $\pm 0.5\%$ f.s.) (23 $\pm$ 5°C)
<b>Temperature characteristic</b>	$\pm 0.05\%$ f.s./°C or less
<b>Output voltage</b>	Voltage, Current, Active power, Apparent power: $\pm 2$ Vf.s. DC at $\pm 100\%$ of range Power factor : 0 V at 0.000, +2 V DC at 1.000 Current integration, Active power integration: $\pm 2$ V DC (range $\times$ set integration time) (Outputs maximum output voltage when "o.r" is on or when "PEAK OVER U" and "PEAK OVER I" are lit.)
<b>Maximum output voltage</b>	Voltage, Current, Current integration, Active power integration : $\pm 2.1$ V DC ( $\pm 105\%$ of the measurement range) Active power, Apparent power : $\pm 2.205$ V DC ( $\pm 110.25\%$ of the measurement range) Power factor : +2.1 V DC
<b>Output update rate</b>	200 ms $\pm$ 50 ms (approx. 5 times/s) (fixed)
<b>Response time</b>	0.5 s or less (the time it takes for indication to stabilize within an accurate range for fluctuations of 0 $\rightarrow$ 90% and 100 $\rightarrow$ 10% of input range)
<b>Output resistance</b>	100 $\Omega$ $\pm$ 5 $\Omega$

## 5.3 Functions

### Waveform output

<b>Configuration</b>	12bit D/A converter, 3channels
<b>Output items</b>	u: Instantaneous voltage waveform i : Instantaneous current waveform p: Instantaneous power waveform
<b>Output accuracy</b>	(Measurement accuracy for each output) + (±1.0%f.s.) (23±5°C) Instantaneous voltage, Instantaneous current : True RMS level Instantaneous power : Average level
<b>Temperature characteristic</b>	±0.05%f.s./°C or less
<b>Output voltage</b>	1 Vf.s. at ±100% of range
<b>Maximum output voltage</b>	Approx. ±5 V
<b>Conversion interval</b>	Approx. 13 μs (= A/D conversion interval of input circuit)
<b>Output resistance</b>	100 Ω±5 Ω

### External Interface

<b>RS-232C Interface</b>	Standard equipment <ul style="list-style-type: none"> <li>Asynchronous communication: Full duplex</li> <li>Baud rate: 9600 bps (fixed)</li> <li>Stop bit: 1 (fixed)</li> <li>Data length: 8 (fixed)</li> <li>Parity: none</li> <li>Remote control from controller (REMOTE LED lights)</li> <li>Use <b>SHIFT (LOCAL)</b> key to cancel remote state (REMOTE LED goes out)</li> </ul>
<b>GP-IB Interface</b>	Specify when placing order (Model 3334-01) <ul style="list-style-type: none"> <li>Complies with IEEE 488.1 1987, refer to IEEE 488.2 1987</li> <li>Interface functions: SH1, AH1, T6, L4, SR1, RL1, PP0, DC1, DT1, C0</li> <li>Remote control from controller (REMOTE LED lights)</li> <li>Use <b>SHIFT (LOCAL)</b> key to cancel remote state (REMOTE LED goes out)</li> </ul>

### Other functions

<b>Display hold</b>	Disables display updates for all measurement values (HOLD LED lights)
<b>Maximum value hold</b>	Detects the maximum values of voltage, current, active power, apparent power, power factor, and frequency, and retains (holds) those values on the display. (HOLD LED flashes) Any measurement that exceeds the absolute value of the previous measurement is held on the display.
<b>Peak value hold</b>	Detects the maximum values of peak voltage value, peak current value, and then hold displays. (HOLD LED flashes) The largest positive or negative polarity value, or the absolute value, is held on the display
<b>Key-lock</b>	Disables all keys other than <b>SHIFT</b> and <b>KEY LOCK</b> (KEY LOCK LED lights) at measurement state.
<b>Backup function</b>	Backup the various settings and integration data. If there is a power failure during integration, the instrument will resume integration after the power is restored.
<b>System reset</b>	Returns all settings to factory defaults

### Operations limited by instrument status

Changes to settings are limited by the hold state (display, maximum value, peak value) and integration. When hold and integration are both enabled, the "cannot change" condition has priority.  
 —: cannot change, ●: changeable

	Hold state	Integration is in process, Integration is stopped
Range changing	—	—
Rectifier type changing	—	—
Average (AVG)	—	●
VT ratio	—	—
CT ratio	—	—
Integration time	—	—
D/A output	●	●
GP-IB address	●	●

# Maintenance and Service

## Chapter 6

### 6.1 Troubleshooting

#### Inspection and Repair

Refer to "6.2 Error Indication" (⇒ p.127) for error messages.

#### CAUTION

Never modify the instrument. Only Hioki service engineers should disassemble or repair the instrument. Failure to observe these precautions may result in fire, electric shock, or injury.

#### NOTE

- If damage is suspected, check the "Before returning for repair" (⇒ p.126) section before contacting your dealer or Hioki representative.

#### Transporting

Use the original packing materials when transporting the instrument, if possible. Pack the instrument so that it will not sustain damage during shipping, and include a description of existing damage. We cannot accept responsibility for damage incurred during shipping.

#### Replaceable Parts

Certain parts require replacement periodically and at the end of their useful life: (Useful life depends on the operating environment and frequency of use. Operation cannot be guaranteed beyond the following periods)

Part	Remarks Life	Remarks
Electrolytic Capacitors	Approx. 10 years	The instrument contains many electrolytic capacitors. The useful life of electrolytic capacitors varies greatly according to the operating environment. In severe operating environments (40°C ambient temperature), degradation occurs in about ten years, so they should be replaced periodically.

The fuse is housed in the power unit of the instrument. If the power does not turn on, the fuse may be blown. If this occurs, a replacement or repair cannot be performed by customers. Please contact your dealer or Hioki representative.

### Before returning for repair

Symptom	Check Item, or Cause	Remedy and Reference
The display does not appear when you turn the power on.	Is the power cord disconnected? Are connections made correctly?	Verify that the power cord is connected properly. <b>See</b> "2.3 Connecting the Power Cord"(⇒ p.21)
Keys do not work.	<ul style="list-style-type: none"> <li>Check whether the instrument is in the key lock state.</li> </ul>	Cancel key lock status <b>See</b> "3.5.3 Disables key operations (key lock)"(⇒ p.49)
	<ul style="list-style-type: none"> <li>Check whether the REMOTE LED is on.</li> </ul>	The instrument is controlled by a controller. End control and cancel remote control. <b>See</b> "Before Use" (⇒ p.4), "1.2 Names and Functions of Parts"(⇒ p.8)

### When no apparent cause can be established

Perform a system reset.

This will return all settings to their factory defaults.







**See** "3.5.4 Initializing (system reset)"(⇒ p.50)

## 6.2 Error Indication

An error is displayed when a fault occurs during the power on self test, and when keys are non-responsive due to the operating state of the instrument.

Errors (4, 5 and 6) that occur as a result of key operations are display for only one second. Errors 1 through 4 that occur as a result of failure of the self test are displayed continuously. (A system reset can clear the error, but operation is not guaranteed.) "Initializing (system reset)" (⇒ p.50))

### Error indication list

Error indication	Description	Remedy
	ROM error	Requires repair. (instrument circuit failure)
	RAM error	
	Control circuit error	
	Backup data error (When a setting is changed, it appears for about 1 s.)	
	Invalid key is pressed (Appears for about 1 s)	Key input is limited during integration or hold operation. This error is cleared when integration is reset or hold is canceled.
	Invalid key is pressed (Appears for about 1 s)	This error is displayed when attempting to resume integration after reaching 10000 hours or ±999999 MWh. This error is cleared when integration is reset.

**Contact your dealer (agent) or local sales office if a repair should become necessary.**

### NOTE

Powering up the line to be measured before this instrument is turned on may damage the instrument or generate an error when it is powered up.

Be sure to turn on the instrument and check that no errors are indicated before turning on the power to lines to be measured.

## 6.3 Cleaning

### NOTE

To clean the instrument and input modules, wipe it gently with a soft cloth moistened with water or mild detergent. Never use solvents such as benzene, alcohol, acetone, ether, ketones, thinners or gasoline, as they can deform and discolor the case.



# Rack Mounting

# Chapter 7

## 7.1 Installation Procedure


By removing the screws on the sides, this instrument can be installed in a rack mounting plate.




Observe the following precautions regarding the mounting screws to avoid instrument damage and electric shock accidents.

- When installing the Rack Mounting Plate, the screws must not intrude more than 6 mm into either side of the instrument.
- When removing the Rack Mounting Plate to return the instrument to stand-alone use, replace the same screws that were installed originally.  
(Feet: M3 x 6 mm, Sides: M4 x 6 mm)

### Rack Mounting Plate Template Diagram




### Installation Procedure




**1.** Remove the feet from the bottom of the instrument, and the screws from the sides (four near the front).

**2.** Installing the spacers on both sides of the instrument, affix the Rack Mounting Plate with the M4 x 10 mm screws.






**When installing into the rack, reinforce the installation with a commercially available support stand.**





# 7.2 Dimensional Diagram





# Index

## A

Analog Output .....	41
ANALOG/WAVEFORM OUTPUT Terminal ..	11, 41
Auto-Range .....	26, 28
Average .....	30
AVG .....	8, 30

## B

Backup Function .....	22
Before Connecting .....	5

## C

Command	
Device-Specific Commands .....	77, 87
List .....	76
Standard Commands .....	76, 82
Command Execution Time .....	75
Command Message .....	62
Command Syntax .....	63
Confirmation Messages .....	62
Connection .....	15
Connection Method .....	20
CT .....	17, 19
CT Ratio .....	32
Current Range .....	26

## D

D/A Output .....	43
Damage .....	125
Data Formats .....	64
Device Clear .....	66
Device Compliance Statement .....	113
Device-Specific Commands .....	77, 87
Dimensional Diagram .....	131
Display .....	9
Display Hold .....	47
Display Items .....	9

## E

Error Indication .....	127
Event Status Register	
Device-Specific .....	70
Standard .....	69

## F

Factory Default Settings .....	51
Fixed-point Data .....	65
Floating-Point Exponential Representation Data	65

## G

GP-IB .....	55
GP-IB Address .....	60
GP-IB Connector .....	11, 60

## H

Headers .....	62, 63
Omission .....	65
HOLD .....	8, 47

## I

IEEE 488.2 .....	55, 65
Initialization Items .....	74
Initializing .....	50
Input Buffer .....	66
Instrument installation .....	4
Instrument Loss .....	20
Integer Data .....	65
Integration .....	35
Integration Time .....	35
Interface .....	55
Item to be Displayed .....	13, 24

## K

KEY LOCK .....	8, 49
----------------	-------

## L

LOCAL .....	8, 61
-------------	-------

## M

Maximum Value .....	10, 48
Measurement Range .....	27
Measurement Work Flow .....	12
Message Terminators .....	64

## N

NR1 .....	65
-----------	----

# Index<sup>2</sup>

## Index

---

---

NR2 .....	65
NR3 .....	65
NRf .....	65

## O

---

o.r .....	52
Operation Keys .....	10
Operation Overview .....	12
Output Queue .....	66

## P

---

PEAK HOLD .....	8, 48
PEAK OVER .....	8, 52
Peak Value .....	10, 48
Power .....	21
Power Cord .....	15, 21
Power Inlet .....	21
POWER Switch .....	8, 22
Pre-Operation Inspection .....	23
Program Messages .....	62
Protective Cover .....	15, 18

## Q

---

Query Error .....	55, 66
Query Message .....	62

## R

---

Rack Mounting .....	129
Rectifier Type .....	29
Regarding Measurement Values .....	14
REMOTE .....	8, 61
Repair .....	125
Replaceable Parts .....	125
Response Messages .....	62
RS-232C .....	55
RS-232C Connector .....	11, 58

## S

---

Self-Test .....	50
Separators .....	64
Setting Screen .....	9
Specifications .....	117
Stand .....	11
Standard Commands .....	76, 82, 76
Status Byte Register .....	67
System Reset .....	50

## T

---

To Cancel the Remote State .....	61
Transporting .....	125

TRG .....	86
-----------	----

## U

---

Unit Flashes .....	53
--------------------	----

## V

---

Voltage Range .....	13, 26
VT .....	17, 19
VT Ratio .....	32

## W

---

Waveform Output .....	41, 46
Wiring Material .....	17

---

# Warranty Certificate

# HIOKI

Model	Serial number	Warranty period Three (3) years from date of purchase ( ___ / ___ )
-------	---------------	--

Customer name: \_\_\_\_\_  
Customer address: \_\_\_\_\_

## Important

- Please retain this warranty certificate. Duplicates cannot be reissued.
- Complete the certificate with the model number, serial number, and date of purchase, along with your name and address. The personal information you provide on this form will only be used to provide repair service and information about Hioki products and services.

This document certifies that the product has been inspected and verified to conform to Hioki's standards. Please contact the place of purchase in the event of a malfunction and provide this document, in which case Hioki will repair or replace the product subject to the warranty terms described below.

## Warranty terms

1. The product is guaranteed to operate properly during the warranty period (three [3] years from the date of purchase).  
If the date of purchase is unknown, the warranty period is defined as three (3) years from the date (month and year) of manufacture (as indicated by the first four digits of the serial number in YYMM format).
2. If the product came with an AC adapter, the adapter is warranted for one (1) year from the date of purchase.
3. The accuracy of measured values and other data generated by the product is guaranteed as described in the product specifications.
4. In the event that the product or AC adapter malfunctions during its respective warranty period due to a defect of workmanship or materials, Hioki will repair or replace the product or AC adapter free of charge.
5. The following malfunctions and issues are not covered by the warranty and as such are not subject to free repair or replacement:
  - 1. Malfunctions or damage of consumables, parts with a defined service life, etc.
  - 2. Malfunctions or damage of connectors, cables, etc.
  - 3. Malfunctions or damage caused by shipment, dropping, relocation, etc., after purchase of the product
  - 4. Malfunctions or damage caused by inappropriate handling that violates information found in the instruction manual or on precautionary labeling on the product itself
  - 5. Malfunctions or damage caused by a failure to perform maintenance or inspections as required by law or recommended in the instruction manual
  - 6. Malfunctions or damage caused by fire, storms or flooding, earthquakes, lightning, power anomalies (involving voltage, frequency, etc.), war or unrest, contamination with radiation, or other acts of God
  - 7. Damage that is limited to the product's appearance (cosmetic blemishes, deformation of enclosure shape, fading of color, etc.)
  - 8. Other malfunctions or damage for which Hioki is not responsible
6. The warranty will be considered invalidated in the following circumstances, in which case Hioki will be unable to perform service such as repair or calibration:
  - 1. If the product has been repaired or modified by a company, entity, or individual other than Hioki
  - 2. If the product has been embedded in another piece of equipment for use in a special application (aerospace, nuclear power, medical use, vehicle control, etc.) without Hioki's having received prior notice
7. If you experience a loss caused by use of the product and Hioki determines that it is responsible for the underlying issue, Hioki will provide compensation in an amount not to exceed the purchase price, with the following exceptions:
  - 1. Secondary damage arising from damage to a measured device or component that was caused by use of the product
  - 2. Damage arising from measurement results provided by the product
  - 3. Damage to a device other than the product that was sustained when connecting the device to the product (including via network connections)
8. Hioki reserves the right to decline to perform repair, calibration, or other service for products for which a certain amount of time has passed since their manufacture, products whose parts have been discontinued, and products that cannot be repaired due to unforeseen circumstances.

**HIOKI E.E. CORPORATION**

<http://www.hioki.com>

18-07 EN-3





# HIOKI

<http://www.hioki.com>



**Our regional  
contact  
information**

**HEADQUARTERS**

81 Koizumi  
Ueda, Nagano 386-1192 Japan

**HIOKI EUROPE GmbH**

Rudolf-Diesel-Strasse 5  
65760 Eschborn, Germany  
[hioki@hioki.eu](mailto:hioki@hioki.eu)

1808EN

Edited and published by HIOKI E.E. CORPORATION

Printed in Japan

- CE declarations of conformity can be downloaded from our website.
- Contents subject to change without notice.
- This document contains copyrighted content.
- It is prohibited to copy, reproduce, or modify the content of this document without permission.
- Company names, product names, etc. mentioned in this document are trademarks or registered trademarks of their respective companies.